


BEECO




KITCHEN COMPOSTER

QUICK USER MANUAL


1

THE COMPOSTER AND ITS COMPONENTS



2

BUTTONS



• THE OPEN BUTTON

Touch the "Open" button to open the feeding cover, and touch the "Open" button again to close the feeding cover, after which the composter will run automatically.

• THE OPERATE BUTTON

When you touch the Operate button, the composter will switch between Breakdown Mode and the Sleep Mode. When the button is touched, the composter will voice the current mode it is in.

• THE PACK BUTTON

Touch the Pack button to pack the decomposed fertilizer. You will hear a voice prompt when the fertilizer has been packed.

• THE CHILD LOCK BUTTON

Press the Child Lock button for up to 5 seconds, until you hear the voice prompt "The Child Lock is turned on", then press the Child Lock button again for 5 seconds, until you hear the voice prompt "The Child Lock is turned off". If the composter is in Child Lock mode prior to a power interruption, the Child Lock will revert to the Child Lock Off mode once power is restored.

3

DIRECTIONS FOR USE

• CULTURING THE MICROBIAL STARTERS

Turn on the power, and once the composter has booted up (about 30 seconds), touch the Open button (or move your hand over the infrared sensing area) to open the feeding cover. Place 2.5kg of microbial starters into the waste treatment chamber and add 50-100ml of water, then touch the Open button again to close the feeding cover. The composter will start to run automatically and culture the microbial starters.

• FEEDING IN THE FOOD WASTE

About half an hour after the microbial starters and water have been fed in, the cultivation of the microbial starters will complete, and the composter can be used normally. After this, you can open the feeding cover to feed in food waste at any time. The amount of food waste input should not exceed 2.5kg a day.

• READY-TO-USE ORGANIC FERTILIZER

The treatment of the food waste will be complete eight hours after it is been fed in. At that time, the composter will go into the Sleep mode. Touch the Pack button to pack the organic fertilizer. Packing the fertilizer once every two weeks is recommended. Recommended values of by-products:



• ADDING MORE MICROBIAL STARTERS

The first time the composter is used, you need to start with 2.5kg of microbial starters at one time. Thereafter you need to replenish the composter with 200-300g of microbial starters every 30 days for daily use, to ensure effective waste decomposition.

Tel: +1 484-601-2807
3400 Cottage Way, Suite G2 #6327 Sacramento, California 95825 USA
Website: <https://www.beecolab.com/>

4

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

5

210*148MM