

CH1 Connecting to the first LED indicator
To activate the [LED] CH1 indicator, turn the mode switch to the position shown below.
[Auto] → LED lighting (ready to go) → Activate the LED indicator function by pressing the [LED] button.
[Auto] → Fan New (CH1 or CH2) → [LED] (pin cut)

CH2 Connecting to the second LED indicator
To activate the [LED] CH2 indicator, turn the mode switch to the position shown below.
[Auto] → LED lighting (ready to go) → Activate the LED indicator function by pressing the [LED] button.
[Auto] → Fan New (CH1 or CH2) → [LED] (pin cut)

CH3 Connecting to the third LED indicator
To activate the [LED] CH3 indicator, turn the mode switch to the position shown below.
[Auto] → LED lighting (ready to go) → Activate the LED indicator function by pressing the [LED] button.
[Auto] → Fan New (CH1 or CH2) → [LED] (pin cut)

An LED will appear illuminated at the corresponding channel (cooling/heating) side of the control panel depending on the time period set in the timer. The LED will also light up if there is a power outage.

[illegible]

Ensure that the keyboard and the device to be used are connected to each other as follows:

- Android: USB → Windows
- iOS: MFI → iOS

Some keys may stop working depending on the device and system. Use the OS connected to each device. In addition, some keys may not work depending on the system.

Backlight settings

Some keys may stop working depending on the device and system. Use the OS connected to each device. In addition, some keys may not work depending on the system.

When the device is connected to the keyboard, the backlight settings can be changed. The settings are as follows:

- Press the **Fn** key and the **Backlight** key to turn the backlight on or off.
- Press the **Fn** key and the **Backlight** key to change the brightness.
- Press the **Fn** key and the **Backlight** key to change the color.
- Press the **Fn** key and the **Backlight** key to change the mode.

To use the device, please turn the display on and press the **Power** key.

18 function keys (12 hot keys)

[illegible]

- **Power on / off**
 - **Power on** - Push the power button to the right to turn on the power.
 - **Power off** - Push the power button to the left to turn off the power.
- **Charging method**
 - Connect the supplied USB to C cable to the charging port.
 - Charging starts when the USB port is connected to the charging cable.
- **How to do a factory reset**
 - If you press the **F10** key for about 10 seconds.
 - If you press the **Fn** key for 4 seconds.
 - If you press the **Fn** key for 4 seconds connected to a network (LAN).

[illegible]

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. The equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If interference does occur, you may wish to take one or more of the following measures to resolve the problem: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and the receiver. (3) Plug the equipment into a different outlet or a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: A20-8761

www.aicfro.com