


evatronic

SOUNDBAR



✉ support@evatronic.co

🌐 www.evatronic.co

🏠 Manufacturer: Shenzhen NearbyExpress
Technology Development Co.,Ltd.
Address: Floor 7, Building E, Galaxy World
Phase II, Shenzhen, China



ET-SK008
User Manual

CONTENT

SAFETY INSTRUCTIONS

KNOWING YOUR SOUNDBAR

USING YOUR SOUNDBAR

CLEANING AND MAINTENANCE


WARRANTY

SAFETY INSTRUCTIONS

Please read the instructions thoroughly before using this product and retain it for future reference.

- To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Keep the device away from extreme heat and humidity, and do not expose to direct sunlight.
- Do not install near any heat sources such as radiators, heat registers, stoves, etc.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the device.
- Use only attachments/accessories specified by manufacturer.
- Use only with the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the device. When a cart or rack is used, use caution when moving the cart/device combination to avoid injury from tip-over.
- Avoid dropping.
- Unplug this device during lightning storms or when unused for long periods of time.
- Close attention is needed when using near children.
- Unauthorized disassembly of any parts of this device is forbidden.
- Always ask a professional technician or authorized personnel for repair.

KNOWING YOUR SOUNDBAR



Remote Control

Power ON/OFF

Power on/
standby mode.



Mute

Mute/unmute.



EQ

Select music, movie
and game equalizer
mode.



Previous Track

Skip to the previous
track.



Play / Pause

Play/pause audio.

Volume Up

Increase the volume.



Next Track

Skip to the next track.

Volume Down

Decrease the volume.



USB

Switch to USB mode.



HDMI ARC

Switch to HDMI ARC
connection.

Optical

Switch to the optical
connection.



AUX

Switch to AUX input
mode.



Bluetooth

- Switch to Bluetooth mode.
- Press and hold to activate the pairing function in Bluetooth mode or disconnect the existing paired Bluetooth device.

Specifications

Bluetooth Version	V5.0
Power	DC 18V/3A Adapter
Rated Output	50W
Dimensions	780x60x60mm

SAFETY INSTRUCTIONS


Placing Your Soundbar

1. Place this unit on a flat and level surface.
2. Optionally, mount the unit on the wall.


Note:

- Improper wall mounting may result in accident, injury or damage.
- If you have any queries, contact Customer Care Centre in your country.
- Before wall mounting, make sure the wall can support the weight of your soundbar.
- Make sure that you use the screws of suitable length and diameter depending on the wall type.

- a) Drill two holes on the wall.
- b) Secure the dowels and screws (not included) in the holes.
- c) Hang the soundbar on the fastening screws.



Step 1




Step 2

Connections


Note:

Ensure the power adapter is plugged into the outlet and the soundbar before all audio connections.



USB

1. Insert the USB device.
2. Press  repeatedly on the unit or press the USB button on the remote control to select USB mode.
3. Play audio located on the USB device through the soundbar.


AUX / OPTICAL / HDMI ARC

1. Connect the unit to the TV or audio device with the corresponding cables.
2. Press  repeatedly on the unit or press the LINE IN / OPTICAL / HDMI ARC button on the remote to select the desired mode.
3. Operate your audio device directly for playback features.


Bluetooth

1. Press  repeatedly on the unit or press  on the remote control to switch the soundbar to Bluetooth mode.
2. On the Bluetooth device, switch on Bluetooth, search for and select "Evatronic SK008" to start connection.
3. Wait until you hear a voice prompt "Connected" from the soundbar.
4. Select and play audio files or music on your Bluetooth device.

Note:

- When the soundbar is on, it will automatically connect to the device last paired if any. Otherwise, it will enter the pairing mode.
- This soundbar automatically switches to standby after 10 minutes of button inactivity and no audio/video play from a connected device.
- To change the connection, press and hold  on the remote control to enter the pairing mode and connect another device.

Restore Factory Settings

In any source mode, long press and hold  on the soundbar until it automatically switches off. All of your personalized settings will be removed from the soundbar.

CLEANING AND MAINTENANCE

- Clean the device on a regular basis.
- Use dry and soft cotton cloth to wipe the unit.
- Keep away from sharp objects to avoid scratches.
- Put the unit in a dry and shady place if it is to be idle for a long time.
- Do not clean the product with detergent or chemicals.

WARRANTY

This product is covered with Evatronic product and labor warranty for 12 months from the date of its original purchase.

The warranty will not apply in cases of:

- Accident, misuse, or repairs performed by unauthorized personnel.
- Any unit that has been tampered with or used for commercial purpose.
- Normal wear and tear of wearable parts.
- Use of force, damage caused by external influences.
- Damage caused by non-observance of the User Manual, e.g. connection to an unsuitable mains supply or non-compliance with the instructions.
- Partially or completely dismantled appliances.
- Defects caused by or resulting from damages from shipping or from repairs, service, or alteration to the product or any of its parts that have been performed by a repair person not authorized by Evatronic.

We can only provide after sales service for products that are sold by Evatronic or Evatronic authorized retailers and distributors. If you have purchased your unit from a different place, please contact your seller for return and warranty issues.

- * Please have your invoice and order ID ready before contacting Customer Support.



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sunvalleytek International Inc. is under license. Other trademarks and trade names are those of their respective owners.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm between the radiator & your body.



WEEE Compliance

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

尺寸:85*120mm

装订成册

材质:封面128克铜版纸 内页80克书纸