

Bluetooth headset user manual

BOTH EARS ARE PAIRED AND CONNECTED

1. Open the charging box, turn on both ears and automatically match each other (blue light flash). When the match is successful, the blue light of the main earphone flashes, and the blue light of the second earphone goes off.

2. Open the device wireless list and search for "MD198".

3. Click to complete the connection (the blue light goes off).

If the connection fails, place the headset back in the charging case and close the cover. Repeat the procedure. When both ears leave the device at the same time and exceed the distance, the earphones will enter the pairing state and re-connecting. If there is no re-connecting to the previous earphones, the earphones will automatically shut down.

After the first connection, the headset will automatically connect back to the previous pairing device after restarting the headset (wireless devices need to be turned on)

PAIRING NAME

DM-6



1

蓝牙耳机使用说明书

双耳配对连接

1. 打开充电盒，双耳耳机自动匹配(蓝灯闪烁)，匹配成功，主耳机蓝灯闪烁，副耳机蓝灯熄灭。

2. 打开设备无线列表搜索；


3. 点击完成连接(蓝灯熄灭)。

如果连接失败，将耳机放回充电盒后重启，重复上述操作。

双耳同时离开设备并超过距离，耳机进入回连无线状态，3分钟内如果没有回连到设备，双耳耳机自动关机。

首次连接后，耳机重新开机后自动回连上一次对设备(需开启无线设备)

配对名称 DM-6



1

MODE OF OPERATION

1. THE BOOT

- (1) Open the cover of the charging case, and the headset will start automatically immediately, and the voice prompts "start up", and the blue light of the headset will flash.
- (2) When the headset is off, touch the touch button for 1-2 seconds, and the voice prompts "power on".

2. TO TURN IT OFF

- (1) Put the headset back to the charging case and close the cover, and the voice prompt "power off".
- (2) When the earphone is turned on, the 3-second long-touch earphone will be turned off, and the voice prompts to turn it off.

3. CLEAR THE TWS PAIRING RECORD

The headset has four modes: music mode, call mode, game mode and touch the headset for 3 seconds to release and switch.

INSTRUCTIONS FOR

The volume+
Click the left ear 3 times
under music status

Play the previous song
Click the right ear twice
in the music state

Answer and hang up
Touch once

The volume-
Click the right ear 3 times
under music status

Play the next song
Click the left ear twice
under music state

GAME MODE

When the ear is connected to the phone, long touch the right earphone for about 2 seconds, and there will be a prompt sound. Long press again to exit.

1. Game mode: The headset indicator shows the breathing state.

2. Music mode: the light flashes slowly.

3. Call mode: the headset indicator shows the breathing state.

PRODUCT INTRODUCTION

1. Charging box*1

2. Left and right earphones *1

3. Size of ear cap *1 pair

CONFIGURATION PARAMETER

4. Data line*1

5. Product Specifications*1

Chip version: 5.2

Standby time: 240 hours

Talk time:

about 48 hours

Charging time: about 1-2h

3

操作方式

1.开机

- (1)打开充电盒盖，其立即自动启动，语音提示“开机”，耳机蓝灯快闪。
- (2)耳机关机状态时，触摸按键1-2秒，语音提示“开机”。

2.关机

- (1)将耳机放回充电盒并关上盖，语音提示“关机”。
- (2)在耳机开机情况下，长按的那部分3秒耳机关机，语音提示关机。
- (3)耳机有音乐模式、通话模式、游戏模式、这4种模式，触摸耳机3秒松开切换一种模式。

操作说明



游戏模式 音乐模式 通话模式

1. 游戏模式：耳机指示灯为呼吸灯效果。

2. 通话模式和音乐模式：耳机指示灯为慢闪。

3. 连续触碰4次启动语音控制。

产品介绍

1. 充电盒*1

2. 左右耳机*1

3. 小耳帽*1对

4. 数据线*1

5. 产品说明书*1

配置参数

芯片版本:5.2

通话时间:约48H

充电时间:约1-2H

待机时间:240小时

耳机电池30毫安、充电仓300毫安。

3

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.