

WirelessKTVMicrophone

User Manual

CATALOGUE GUIDE

1. Product Introduction	2
2. Product Specification	2
3. Packing List	3
4. How to use	4
5. UI Functions	6
6. Trouble Shooting	8
7. How to Care	10
8. Product Warranty	11

1. Product Introduction

Thanks for purchasing wireless microphone, please read the following instructions carefully before use.

- The product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required.
- The clip-on transmitter has a great sounding built-in mic and it is small and light enough to clip to shirts and clothing.
- It can be used in different circumstances such as Live, Video Recording, Interviewing, online Teaching, KTV and others.

2. Product Specification

SYSTEM SPECIFICATIONS

Frequency range: 2400~2483.5MHz

Frequency Response : 75Hz ~ 35kHz +/- 3dB

Signal to noise ratio: -90dB

Transmission delay: 9mS

The sampling rate: 48KHz

The bit depth: 24bit

Transfer longest distance: 49-65ft (barrier-free working distance)
32-49ft (obstacle distance or the noise is loud)

Charging input voltage: DC 4.8~5.4V

TRANSMITTER

Microphone type: built-in polymer battery

Built-in battery capacity: 100mAh 3.7V

Working Hour: 4 - 5 hours after fully charged

Charging Time : About 1 hour (5V/1A)

CHARGING CASE

Power Capacity : 450mAh

Charging Time : 1 hour

Note: After using the mic set, please put it in the storage and charging box in time to avoid the loss.

3. Packing List

Number	Product picture	Text explanation
1		Charging box
2	Power button Charging port/ Monitor earphone port	Microphone transmitter
3		TYPE-C charging cable

4




**TYPE-C audio
conversion line or
Lighting audio
conversion line**

4. How to use

Step1: Preparation before the first use, Charge the charging box and transmitter for 1 hours



Small icon display on the phone



1..Press the powerkey
2..then blue light flashes



Plug Analog earphone to monitor at this Port





During live broadcasting,
charge the mobile phone
quickly at the same time

Note:

As shown in the figure above, this product has the monitor function, if the does not need to monitor, it can plug in the charging cable to quickly charge the mobile phone at the same time

This product has three selection of scene mode. Please select different scene mode according to the actual situation and your need.

Operation

In the connection state, short press the power button of the transmitter

The indicator flashes once in red and then turns blue—the Original mode .the sound quality of the recording is the best when used in a quiet environment

The indicator flashes twice in red and then turns blue—the Noise reduction mode. It will reduce the noise when used in a noisy environment

The indicator flashes three times in red and then turns blue—the KTV mode When you need to sing (The effect is better when the microphone is within 5cm from the mouth)

5. UIFunctions

Microphone Transmitter

Function	Operation	Light
Power on	Long press the power button for 3s to turn on	Blue light flashes slowly
Pairing	Automatically search for pairing once starting up	Blue light flashes

Paired	Auto pairing	Red light on
Poweroff	Long press the power button for 3s or Automatic turn off after 1 min without connection	/
Three selection of scene mode	Short press the switch when connected	The flashes times of the Red light reprise different scene mode, then turn blue
Clear the pairing and Re set	Turn on the Transmitter, then press the power button twice quickly, then Press power button for 3-5s immediately, don't release until the light turns from purple to blue.	Blue light flashes slowly, then Blue turns purple; then purple turns blue
Lowbattery alarm	Battery is below 20%	Red light on

Charging box

Function	Operation	Light
Charging box with type-C	Plug the TYPE-C Charging cable	The blue light flashes, and the four running lights represent 25 / 50 / 75 / 100 power
The charging box is fully charged	/	All four blue lights are on
The charging box charges the microphone	Put the microphone into the charging BOX	the blue light in the charging BOX is always on, and the red light of the microphone is always on
The microphone is fully charged	/	the blue light in the charging BOX is off, and the red light of the microphone is off.

6.TroubleShooting

If the problem still cannot be solved,

Please contact customer service

NO.	Common issues	Possible Cause	Solutions
1	The signal cuts in andout	other devices are working at the same frequency	If you have more than one microphones or some other devices, please make sure other sets are powered off to avoid interferences. Or try to pair again.
2	The lapel mic has to be very close to mouth in order to pick up myvoice	KTV reverberation mode may be enabled	Suggested to close to mouth and point the lapel mic to your mouth.
3	There is always harsh sound or loopback.		Don't be too close to the audio device. harshsound orloopback.
4	Can I use two sets together? Is there any interference with eachother?		Yes. But please stagger the pairing time of the two sets of mic. Otherwise it will interfere with each other and need to reset and pair again
5	The Transmitter/ Charging box can't charge	May have triggered the battery protection mechanism. Need to activate battery.	First, it must be charged for 10 minutes, then unplug and then plugged in for another ten minutes, please repeat several times until it returnsto normallycharging.

6	The charging Case has power, but the microphone cannot be charged.	Displacement of charging electric shock/greasy stain or Oxidation on the charging contact spots.	Make sure that align the charging contacts on the Transmitter with the charging pins on the case, Please wipe/friction the charging contacts pots.
---	--	--	--

7. How to Care

1. READ/KEEP/FOLLOW these instructions
2. Use and store the system only in room temperature environments.
3. Do not attempt to modify this product. Doing so could result in product failure.

8. Product Warranty Certificate

We hereby guarantee and warrant function and finishing of all products under normal installation and usage for a period of (one) year from the date of purchase.

We will replace any defective product at no additional charge to the product owner.

To file a warranty claim, please take photographs showing the damage to your product from various angles, for us to conduct a proper assessment of your warranty claim.

Please write a brief description explaining how the damage occurred to the product, along with your order ID.

Then, to send a claim via email contact us

Please write your claim summary in the body of the email and attach digital photographs and a scanned image of your dated sales receipt.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Please READ and KEEP these instructions.
If you have any problem, please contact us