

User Manual

TXCRCHRGEG-123

(Fold Inward) →

(Back Cover)

(Front Cover)

Controlling Volume & Playback

- Press the [Multi] button on the earbud to pause and resume audio playback.
- **Press + hold the [Multi] button to skip to the next track.**
- **2x Press the [Multi] button to increase volume.**

Phone Calls

- Press the [Multi] button on the earbud to **answer** an incoming phone call. Press again to **end** the phone call.
- **Press + hold the [Multi] button on either earbud to reject an incoming phone call.**
- **4x Press the [Multi] button to dial the last outgoing number.**

Activating Voice Assistant

If you have a voice assistant on your paired device, you can activate it using the controls on the earbud or the controls on your device.

- **3x press** the earbud's [Multi] button to **activate** the voice assistant.

FCC Information

This device complies with Part 15 of the FCC Rules. Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Compliance Information

90-Day Limited Warranty

This product is supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

LIMITED WARRANTY TO ORIGINAL CONSUMER

• Visit our customer support portal: www.customersupport123.com

To obtain warranty service:

- Select "Brand and Model" of your device
- Select "Get Support" and fill out the form to begin your inquiry
- Exchanges require dated proof of purchase from an authorized retailer

• Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty does not cover

• This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE, NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, OR ENTITY WHATSOEVER TO THE CONSUMER SHALL BE ENFORCED. THE EXCLUSIVE REMEDY FOR ANY DEFECTIVE PRODUCT IS THE EXCHANGE OR REFUND OF THE ORIGINAL PURCHASE PRICE, AT DISTRIBUTOR'S SOLE DISCRETION. ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN EVENT THIS WARRANTY IS EXHAUSTED, DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, LOSS OF DATA, LOSS OF USE OF THE PRODUCT, OR LOSS OF INVESTMENT IN PURCHASE OF THE PRODUCT, EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXPEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Radiation Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-Ion Battery Inside

The product is fitted with a Li-Ion battery. Do not damage, open, or dismantle the battery and do not use it in cold or hot extreme conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F),

Rating Label

Definitions

RECYCLE This symbol signifies the product must not be disposed as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

RC This symbol signifies that this equipment has battery charging which complies with California CEC and energy efficiency.

Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology.

FCC This symbol represents FCC Declaration of Conformity and compliance.

Warranty Information

TRAXX

Instruction Manual

2-in-1 USB Car Charger with Wireless Earpiece

TXCRCHRGEG-123

Printed in China
v1.12-2021

Before You Begin...

READ THIS MANUAL CAREFULLY AND SAVE FOR FUTURE REFERENCE

Caution

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- **Do not submerge in water**.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge the earbud.
- If the earbud is in a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc.
- Store only safe, dry location, away from sources of water, light, heat, and dust. The device is best stored in an airtight box or bag (not included).
- Clean by wiping with a clean dry microfiber cloth ONLY. Do not clean with water or any sort of cleaning liquid or detergent.
- The earbud contains built-in batteries and should not be disposed of with regular household waste. Please consult local authorities on the correct way to dispose of this device.

Customer Support

For any questions or problems with your product, please visit our website at customersupport123.com.

In the Box

- Car Charger (x1)
- Wireless Earbud (x1)
- Instruction Manual (x1)

Location of Controls

Plugging In

Plug the smaller end of the car charger into the cigarette lighter power port in your car.

Getting Started

Charging the Earbud

1. Plug the charger into your car's cigarette lighter power port.
2. Slide the included earbud into the earbud charging port on the charger.
3. The LED indicator will light up RED while charging and turn OFF when finished charging.

A tone will be heard when the earbud is low on battery. Please recharge when this happens.

Powering the Earbud On/Off

- Remove the earbud from the charger to automatically power it ON. A voice will be heard, and the earbud will enter Bluetooth pairing mode.
- Insert the earbud into the charger to automatically power it OFF.
- The earbud can also be powered OFF by **touching + holding** the [Multi] button for **8 seconds** (power OFF).

Note: The earbuds will automatically power OFF if they are not paired to a Bluetooth device after 2 minutes, or if the paired device is out of Bluetooth range (10 m / 30 ft) for 2 minutes.

Bluetooth Pairing

1. Power the earbud ON. A voice will be heard indicating the earbud is in pairing mode.
2. Open your device's Bluetooth menu, and search for new devices. Select **TXCRCHRGEG** when it appears on the list of found devices.
3. Another voice will be heard, indicating that the earbud is successfully connected to your device. The LED indicator on the earbud will turn OFF.

See earbud controls on the next page.