

Smart Toilet Instructions

Safety Note


Please read and follow the instructions carefully for installation. Save the instructions in proper place and do not loss it. In order to ensure the safety and avoid the loss, please follow the instructions as below.

Warning Show how to avoid the injury.

Caution Show what you should follow and not to do.

Sign	Note
	Forbidden
	Must Follow
	WARNING <ul style="list-style-type: none"> • Do not replace or remould the product are forbidden or else you will get an electric shock or causes fire. • Drop the lighting cables and burning objects into toilet bowl are forbidden or else you will causes fire. • Do not water and drain open on the seat cover and plug are forbidden or else you will get an electric shock or causes fire. • Do not touch the plug with wet hands to avoid getting an electric shock. • The portable or tottering plug is forbidden or else you will get an electric shock or causes fire. • Do not replace the wire yourself while it is broken. The correct way is to call the professional maintenance staff to handle it.
	<ul style="list-style-type: none"> • Smart toilet belongs electric product. Do not use it in wet environment. • Make sure the voltage and plug can match the product or else it would be broken. • Drop the water and drain open on the seat cover and plug are forbidden or else you will get an electric shock or causes fire. • The portable or tottering plug is forbidden or else you will get an electric shock or causes fire. • Do not replace the plug with wet hands to avoid getting an electric shock. • Make sure the ground lead wire can match the standard of law or else it is forbidden to use the product. • Ensure install the product with the pipe and fittings which is combined in the packing or else the product would be leaking. • Ensure the power and water connection is off while installing, dismantling and repairing. • Suggest clean out the water from product with room temperature below zero so as to avoid freezing. • People with disabilities or mental disabilities require using the product under supervision. • Read the cardpathow use the product with caution. • Do not allow children to play with the product.
	<ul style="list-style-type: none"> • Cut the power and pull out the plug during thunder. • Do not wipe the product with thinner, petrol, detergent and insecticide. • Adjust the seat cover to be minimum while seat on toilet cover in a long time, or else the product would be leaking. • Do not turn the product upside down while the power is working but without water supply or else the heating device would be broken. • Make sure the water is clean. Do not use the process water, waste water and sea water and re-collect water. • Do not place product in direct sunlight or else the product would discolor and causes burns. • Do not turn your back to the cover while it is working or else the cover would be broken. • Do not press the cover strongly or else the soft down device would be broken.

Side Button Instructions




Drying

Press this button to start drying while there is people sitting on and you can cut the running by **Stop** button.



Press this button to start drying while there is people sitting on the seat cover bowl. The drying will finish in 3 minutes. It also can be stopped by **Stop** button.

Indicating Light Instructions




(Indicating light on the top of seat cover)

ECO light


The product is under energy saving mode when the light is on. The product is out of ECO mode when the light is off.

LED Display Instructions




(LED display on the top of seat cover)

List



Fittings



Rear

The rear flushing function will be run by press this button while people sitting on the seat cover bowl. And press this button again can root the moving mode.

You can cut the running by **Stop** button. And the washing will also stop itself after people leaving the seat.

Stop

The product will stop working by pressing this button while it is in use.

And it will also stop itself after people leaving the seat.

Flush

Flushing once.

The rear flushing function will be run by press this button while people sitting on the seat cover bowl. And press this button again can root the moving mode.

You can cut the running by **Stop** button. And the washing will also stop itself after people leaving the seat.

Water Temp. light

Water temperature can be adjusted for 4 grades.

Green light means low temp..

Purple light means middle temp..

Red light means high temp..

Light off means home temp..

Power light

The red light means the product is in working mode.

The light off means out of power.

Bidet

The lady's flushing function will be run by press this button while people sitting on the seat cover bowl. And press this button again can root the moving mode.

You can cut the running by **Stop** button. And the washing will also stop itself after people leaving the seat.

Seat Temp. light

Light on means people are in the sensor area and the function of washing & drying can be rooted if need.

Light off means people have left and the function of washing & drying can not be rooted.

Forward & Backward

Water temperature can be adjusted for 4 grades.

Green light means low temp..

Purple light means middle temp..

Red light means high temp..

Light off means home temp..

Seat Temp. light

Water temperature can be adjusted for 4 grades.

Green light means low temp..

Purple light means middle temp..

Red light means high temp..

Light off means home temp..

Water Temp. light

Light on means people are in the sensor area and the function of washing & drying can be rooted if need.

Light off means people have left and the function of washing & drying can not be rooted.

This function can be rooted without seating on the sensor area.

ECO & Extended press

Press once to root the product.

Extended press to shut down the power.

Press once to root the 8 hours electric save mode while the power is on.

The electric save mode will be off in 8 hours or be off while there is people sitting on the seat cover.

Forward & Backward

The position of nozzle can be adjusted by these two button while the washing function is working.

Water Temp.

Water temperature can be adjusted for 4 grades.

Light off means home temp..

Light on means low grade, and more lights means higher strength.

Water strength ADJ

Press this button to adjust the strength of spray in 4 grades.

One light means low grade, and more lights means higher strength.

Seat Temp.

Press this button to adjust seat cover temperature in 4 grades.

Light off means home temp..

Open/Close Cover lid

Press open/close button to operate.

The lid will close itself in 1.5 minutes while there is not any other operation.

Body Identification

Feet Sensor Flushing

While there is people sitting on the toilet bowl seat, it can flush once after your feet meeting the area of sensor.

Feet Sensor Cover

While there is people sitting on the toilet bowl seat, the cover can be opened by meeting the area of sensor.

The cover will close itself in 1.5 minutes while there is not any other operation.

Inductive Auto Cover

The cover will open itself while people meet the inductive area.




The cover will close itself in 1.5 minutes with any other operation.

Smart Toilet Instructions

Remote Control Instructions

Note: Please pair the code following the way below if the controller is not working at the first time in use.

- Press on side button both **Stop** and **Bidet** for 3-5 seconds. Press any button on controller when you hear a beep sounds.
- Press any button on controller when you hear a beep sounds.
- The code will be paired when hear a beep sounds again.



CAUTION

PREPARE GET HURT IN BURNS

- Please do remember to shut down seat temp. and drying temp. so as to prevent get hurt in burns in the situation as below:
- ▲ The people who can not adjust the temperature as like as children, elder, etc..
- ▲ The patients, disabled people or impaired physical mobility.
- ▲ People who took the sleeping pills or over drinking or weary or drowsiness.

Drying

Press this button to start drying while there is people sitting on the seat cover bowl.

The drying will finish in 4 minutes. It also can be stopped by **Stop** button.

The drying temperature can be adjusted in 4 grades by temperature adjusting button.

The drying will stop itself after leaving the seat.

Lighting & Defecation assist

Press this button to root defecation assist while there is people sitting on the seat cover bowl.

The water pressure is on high grade.

The working can be ended by **STOP** button.

While the bidet washing is running, press this button can root the moving mode.

During the washing, you can adjust the strength of spray.

The washing will stop itself after people leaving the seat.

Drying Temp.

Press this button to adjust the temperature in 5 grades while the drying function is working.

Light off means home temp..

Light on means high temp..

Seat Temp.

Press this button to adjust seat cover temperature in 4 grades.

Light off means home temp..

Light on means high temp..

Open/Close Cover Seat

Press open/close button to operate.

The lid will close itself in 1.5 minutes while there is not any other operation.

Inductive Auto Cover

(only for 2206C)

The cover will open itself while people meet the inductive area.

The cover will close itself in 1.5 minutes with any other operation.

Smart Toilet Instructions

Installation of smart toilet

CAUTION


The electric plug must follow the rule as below:

- Do not touch the electric plug with wet hands.
- The plug and product should be close to product for easy installation and dismantling.
- Suggest to use the water proof plug and do not use the portable plug.
- Install and use the product in correct way or else you will get electric shock or causes fire.

Required tools



Step of Installation



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2A3RV-2208C