

# ShineTech Smart Security SSV-AL8911-IPV2


## BULLET CAMERA

Quick Manual for Android and iOS

SSV-AL8911HDV2 · CM-AL8911 · PIR-AL8911 · KIPPU-HDV2 · KASPU-HDV2 · VK-TWIPW200A · IP302PIR · SSV-IP2058S2 · SSV-HD2058V2V12 · SSV-6503VH8 · SSV-6924VH8 · SSV-6711VH8 · SSV-1016 · SSV-781V3 · SSV-6209WF · SSV-6309WF · SSV-6509WF · SSV-6809WF · SSV-6238WL · SSV-HD6238 · SSV-6320LR · SSV-HD6268 · SSV-HD6260 · SSV-HD6233


### Packing list

After open packing list box, please check product body and accessories as below:



### Interface

Before use, please pay attention to the interface and button of camera.




**Note:**  
Reset button : Long press to restore the camera to factory settings.

### Operation

#### 1.Download APP

Tips one: Scan QR code.



Tips two: Search "iCSee" in the App store and download.

#### 2.Power on

Use the power adapter to connect the camera power interface and the power socket, As shown in the figure below.



**Note:**  
If you need local storage, please install the memory card firstly, then power on the device (the memory card does not support hot swapping, please plug and unplug the memory card when the device is powered off). Cloud storage is recommended, which is safe and convenient. Details See "Step 4" for operation.

### 3.Camera configuration

#### 1.Wireless network configuration:

##### 01.User login

- Connect your phone to WiFi.
- Open the iCSee app, register an account and login(Figure 1).

Figure 1





Figure 2



Figure 3



#### 02.Quick configuration

- After successful login, Click the "+" button (Figure 2).
- Click the "WiFi Camera" ( Figure 3 ) .
- Set network configuration according to the camera's voice prompts and the APP interface step-by-step guide. When the camera emits a "Connect router successfully" prompt, it means that the camera has successfully configured the network.

Figure 4



Figure 5




Figure 6



Figure 7



Figure 8



Figure 9



Figure 10



Figure 11



Figure 12



Figure 13



Figure 14



Figure 15



Figure 16



Figure 17



Figure 18



Figure 19



Figure 20



Figure 21



Figure 22



Figure 23



Figure 24



Figure 25



Figure 26



Figure 27



Figure 28



Figure 29



Figure 30



Figure 31



Figure 32



Figure 33



Figure 34



Figure 35



Figure 36



Figure 37



Figure 38



Figure 39



Figure 40



Figure 41



Figure 42



Figure 43



Figure 44



Figure 45



Figure 46



Figure 47



Figure 48



Figure 49



Figure 50



Figure 51



Figure 52



Figure 53



Figure 54



Figure 55



Figure 56



Figure 57



Figure 58



Figure 59



Figure 60



Figure 61



Figure 62



Figure 63



Figure 64



Figure 65



Figure 66



Figure 67



Figure 68



Figure 69



Figure 70



Figure 71



Figure 72



Figure 73



Figure 74



Figure 75



Figure 76



Figure 77



Figure 78



Figure 79



Figure 80



Figure 81



Figure 82



Figure 83



Figure 84



Figure 85



Figure 86



Figure 87



Figure 88



Figure 89



Figure 90



Figure 91



Figure 92



Figure 93



Figure 94



Figure 95



Figure 96



Figure 97



Figure 98



Figure 99



Figure 100



Figure 101



Figure 102



Figure 103



Figure 104



Figure 105



Figure 106



Figure 107



**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body:

Use only the supplied antenna.

FCC ID: 2A3SH-SSV-8911