


DREO

Humidifier

USER MANUAL



”

Thanks for Choosing DREO!

Your support means the world to us.
We hope you enjoy our product as much as
we did creating it.

CONTENTS

01

IMPORTANT SAFETY
INSTRUCTIONS

1-2

02

KNOWING YOUR
APPLIANCE

3-6

03

CONNECTING TO
YOUR APPLIANCE

7

04

USING YOUR
APPLIANCE

8-9

05

CLEANING AND
MAINTENANCE

10-14

06

TROUBLESHOOTING

15-16

07

DREO CUSTOMER
CARE

17-18

IMPORTANT SAFETY INSTRUCTIONS

01



READ ALL CAUTIONARY
MARKINGS ON THE
APPLIANCE AND
SAFETY INSTRUCTIONS
IN THE USER MANUAL
BEFORE USE.



DO NOT
block or
cover the
nozzle while
in operation.

DO NOT
touch or hold
the mains
plug with wet
hands.

DO NOT
let children
or pets play
with this
appliance.

General Safety

1. Children shall not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
2. Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Operation Safety

1. Always place this appliance on a firm, flat and level surface to avoid dropping or tilt.
2. Always place this appliance 60 cm above the floor, 30 cm away from the wall or wooden furniture.
3. DO NOT move this appliance while it is on.
4. DO NOT attempt to repair any parts on this appliance. Doing so will void your warranty. The inside of this appliance contains no user serviceable parts. All servicing should be performed by qualified personnel only.
5. Never leave water in the reservoir when the appliance is not in use.
6. Do not permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the humidifier down. If the humidifier output volume cannot be turned down, use the humidifier intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
7. Do not immerse in water and any other liquids.

8. Do not use the appliance until the base is installed.
9. Do not insert your fingers, pencil and any other objects into the grilles while in operation.
10. Warning: Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.

Electricity Safety

1. Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
2. Always unplug before cleaning or leaving the appliance unused for a long period of time. Keep your hands dry when plugging/unplugging.
3. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
4. Do not use this appliance if the cord has been damaged to avoid fire or electric hazard.
5. Keep the cord out of heavy traffic areas and where it will not be tripped over.
6. Do not operate any humidifier with a damaged cord or plug. Discard the appliance or return to an authorized service facility for examination and/or repair.
7. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
8. WARNING: To reduce the risk of fire or electric shock, do not use this humidifier with any solid-state speed control device.
9. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

READ AND SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

Gentle Reminder



Check the appliance regularly and refer to TROUBLESHOOTING or contact our customer support if it shows any of the following signs:

- Power cord or plug is damaged.
- Loud noise, unusual smell or excessive heat.


Specifications

Model No.	DR-HHM015S
Input	120V~60Hz
Rated Power	26W
Water Tank Capacity	4.2 Gal (16L)


KNOWING YOUR APPLIANCE

02


Package Contents




Water Inlet Tank



Base Chamber



Main Water Tank



User Manual




Remote control



2x AAA Batteries



Quick Start Guide



Power Adapter



Cartridge



Cleaning Brush

Control Panel



Power Button

- Turn the humidifier on/off.
- Long press for 7 seconds to restore WiFi and factory settings.



Manual Mode Button

Switch between Low/Medium/High mist level



Auto Mode Button


- Turn Auto Mode on/off.
- Long press for 5 seconds to enter WiFi setting.
- When first activated, the screen will display the target humidity.
- Tap the  button to increase the target humidity by 5% (target humidity ranges from 30% to 90%).
- In Auto Mode, mist level is adjusted according to your target humidity.
- Press the Manual Mode Button  to exit Auto Mode.



Ambient Light Button

- Touch to turn on/off the ambient light, LED display light, and beep sounds.
- When the ambient light turns off, touch any button to wake up the LED display (auto-off after 5 seconds without operation).
- Long press for 5 seconds to set a timer (0-12h).


LED Display



Note:

- When humidity levels are below 10%, the display will show "LO".
- When humidity levels are above 90%, the display will show "HI".
- When the water is low, the Low Water Level Indicator will flash for 5 seconds then the humidifier will switch to standby.
- When receiving Software upgrades, the display will show "UP", and the humidifier can't be operated until the upgrade ends.

Ambient Light



The ambient light color will change according to your room humidity level.

Light Color	Humidity Level
Yellow	$\leq 30\%$
Green	31% - 60%
Blue	$\geq 61\%$

CONNECTING TO YOUR APPLIANCE

03



Before connecting the appliance to your mobile device, please scan the QR code on the left or go to the app store and search “DREO”, then select and download the app.



Look for “HM000S” when connecting your new humidifier.



You can use the DREO app to connect your smart appliance to **Amazon Alexa** or **Google Home**. Please follow the in-app instruction to set up your voice assistant.

NOTE: You must create a DREO account to access voice assistants.

- 1 Launch DREO and sign in or create account by following in-app instructions.
- 2 Enable Bluetooth on your mobile device and plug in your humidifier.
- 3 Hold  for 5 seconds to start WiFi connection settings.
(Tip: The WiFi icon  will keep flashing when pairing.)
- 4 Tap **+ Add Device** and select **HM000S**.
- 5 Follow in-app instructions to complete WiFi connection.
- 6 You're now ready to control the appliance on your app.
(Tip: To restart connection settings, hold  again for 5 seconds)

Long press  for 7 seconds to unpair WiFi and restore factory settings.


USING YOUR APPLIANCE

04

Before Use


When using your humidifier for the first time, remove the wraps and follow the steps below.

1




Remove the cover, water inlet tank, humidifier base, and main water tank, then clean thoroughly.

2




Fill the main water tank with water, making sure the water doesn't pass the MAX line.

3



Put the water inlet tank and humidifier base back in place, and close the top cover.

4




Place the humidifier on a flat, level surface, keeping at least 30 cm/12 inch away from walls or any major obstacles.

ATTENTION:

- It is recommended to add purified or distilled water to prevent white powder residue from forming.
- Do not add essential oil into the water tank to avoid damage to the tank.
- Direct the mist away from walls, furniture and electrical appliances.
- It is recommended to place a water-resistant mat under the humidifier to catch spills and droplets.
- Empty and clean the humidifier before storage. Clean the humidifier before next use.
- Be aware that high humidity levels may encourage the growth of biological organisms in the environment.

Remote Control




Battery Replacement

1. Remove the battery cover in the direction indicated by the arrow.
2. Replace with two new AAA 1.5V batteries. Make sure that the positive (+) and negative (-) terminals are positioned correctly.
3. Push the battery cover back into place.



WARNING

- Replace with new batteries of the same type when replacement is required.
- Remove the batteries when the remote control is unused for long period of time.
- Do not attempt to dismantle the batteries.
- Do not dispose the batteries in fire, batteries may explode or leak.
- Chemical burn hazard. Keep batteries away from children.
- Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.



CLEANING AND MAINTENANCE

05




Scan the QR code to see the cleaning and installation guide



- Always turn off and UNPLUG the humidifier before any cleaning or maintenance.
- Do not clean the main body under running water.
- Do not let water splash into the air outlets.
- Do not use any chemical agents when cleaning the humidifier.
- Store in a cool, dry place and cover it to protect from dust.
- Empty and clean the humidifier before storage. Clean the humidifier before next use.
- Do not overfill the humidifier due to the potential risk of electric shock.

Cleaning

①




Remove the water tank cover.

②



Rinse the water tank cover, and clean the nozzle with the included cleaning brush.

③




Remove the water inlet tank from the humidifier base.

④



Rinse the water inlet tank.

③




Remove the humidifier base and pour out any water.

④




Clean the base chamber with a dry cloth.

⑤



Pour out any water in the main water tank. Clean the inside of the tank with the cleaning brush, then rinse with room-temperature water.

⑥



Pull to remove the cartridge from the silicone tube. Clean the cartridge with the cleaning brush.

⑦




Dry **all parts** with a cloth.

Make sure all parts are completely dry before reassembling or storing.

Descaling


RECOMMENDED ONCE A MONTH

1




Remove the humidifier base from the main water tank.

2




Fill the water tank and base chamber with a solution of bleach and water (one teaspoon of bleach for each gallon of water).

3




Carefully swish the solution around the tank and base chamber.
Do not allow liquid to contact the air outlet.

4




Allow the parts to soak for 15-20 minutes. The solution will loosen scale (mineral deposits) in the tank and base chamber.

5




Pour out the solution.

6




Use a soft cloth and cleaning brush to remove scale from all parts.

7



Pull to remove the cartridge from the silicone tube. Place the cartridge in a container and fill with enough solution to cover the cartridge. Soak for 1 hour.

8




Rinse **all parts** until any bleach smell is completely gone.


Is Your New Humidifier Leaking?



Make sure the water is not added into the mist tube.




Make sure the water does not pass the MAX line.




Make sure the humidifier is placed on a flat surface.

Contact Customer Service If...



The water valve is not flat or the water inlet tank leaks water when refilling.



Your water inlet tank has leakage due to prolonged use of essential oils.

If your humidifier keeps leaking water, please contact customer support (see page 18).

My humidifier does not work.

1. Make sure that the cord is connected to a powered outlet and the mains voltage corresponds with the voltage indicated on the humidifier.
2. The humidifier will shut down automatically in the event of low water.
3. Check if the water tank is installed properly.
4. In Auto Mode, the humidifier will stop adding moisture when it reaches the room humidity target.
5. Make sure that no water enters the inside unit during cleaning or use. If water does get inside, do not power on the humidifier immediately. Place it in a dry, well-ventilated area and let it dry for at least 24 hours before use.

My humidifier is not misting.

1. Please check whether the air inlet is blocked.
2. The water in water reservoir is nearly used up.
3. Your room might have too much ventilation. Please close doors and windows.
4. Check if the humidifier is in Auto Mode and the set humidity is lower than the ambient humidity.
5. Check if there is scale attached to the surface of the atomizer. If necessary, clean it according to the instructions.
6. When the water inlet tank is out of water, you need to wait about 15 seconds for the humidifier to pump water after plugging it in before it starts working.

The mist produces an unpleasant smell.

1. Use purified or distilled water only. It is not recommended to use tap water.
2. Change water regularly to avoid dirty water accumulation.
3. Clean the humidifier and keep it dry for 12 hours with the cover detached.
4. Clean the aroma pad tray, change the aroma pad.

Water leaks from my humidifier.

1. Make sure the silicone sealing ring around the water outlet valve is secure.
2. Avoid running the humidifier in a room with over 60% relative humidity.
3. Wipe any excess water.
4. Do not shake the humidifier.
5. Make sure to place the humidifier on a flat, level surface.
6. Check the water tank for leaks. If there are leaks, contact Customer Support (see page 18).

There is white dust in the water tank.

You should descale the humidifier regularly. Using purified or distilled water can help prevent the formation of scale.

The water pump is making noise.

This humidifier uses a water-pumping mechanism, so a brief, slight noise when starting to pump water is normal.

If your problem is not listed or still persists, contact our Customer Support ([see page 18](#)).

DREO CUSTOMER CARE

07

12-MONTH LIMITED WARRANTY

What is Covered

DREO warrants to you that your product will be free from original defects in materials and workmanship for a period of twelve (12) months from the date of your purchase, when you use your product for intended purposes in accordance with this User Manual.

Please retain your proof of purchase. If you do not retain your proof of purchase, your warranty will start two (2) months from the date of manufacture printed on your product label.

What is Not Covered

This limited warranty only applies to the original purchaser of your product and is non-transferable. This warranty is only valid if your product is used in the country in which you originally purchased it. In addition, this warranty will not apply, and DREO will not be liable for any costs, damages, or repairs, in connection with any of the following:

- Accidents or use of your product with inappropriate force;
- Damage or destruction caused by wrong voltage or unstable electric current;
- Normal wear and tear;
- Careless operation or handling, misuse, abuse, neglect, and/or failure to maintain or use your product in accordance with this User Manual;
- Any partially or completely altered, modified and/or dismantled products;
- Reduction in battery discharge time due to battery age or use (as applicable);
- Products with altered or removed serial numbers;
- Clearing any blockages from the product;
- Purchases from retailers and distributors not authorized by DREO to sell this product;
- Defects caused by or resulting from damages from shipping or handling by any third party not authorized by DREO to ship or handle your product; or
- Defects caused by or resulting from repairs, service, improper maintenance, or alteration to your product or any of its components by anyone other than a repair person authorized by DREO.

Any service and customer support that DREO provides to you under this limited warranty will not extend the duration of this limited warranty.

Warranty Limitations and Exclusions

ANY IMPLIED WARRANTIES RELATING TO YOUR PRODUCT, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THE LIMITED WARRANTY SET FORTH ABOVE AND ARE OTHERWISE DISCLAIMED.

THIS LIMITED WARRANTY SHALL BE THE SOLE REMEDY OF THE PURCHASER OR USER OF THE PRODUCT, AND DREO SHALL NOT BE LIABLE FOR AN ALLEGEDLY DEFECTIVE OR DAMAGED PRODUCT EXCEPT TO REPAIR OR REPLACE IT IN ACCORDANCE WITH THIS LIMITED WARRANTY. DREO WILL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, INDIRECT, CONTINGENT, OR CONSEQUENTIAL DAMAGES OR LOSSES OF ANY NATURE THAT YOU MAY INCUR IN CONNECTION WITH YOUR PURCHASE OR USE OF YOUR PRODUCT.

Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you also may have other rights which vary from jurisdiction to jurisdiction.

Limited Remedies

If your product fails because of an original defect in material and/or workmanship during the warranty period, DREO will repair or replace (in DREO's sole discretion) your product.

To obtain warranty service on your product, contact us at support@dreo.com or at (888) 290-1688 (available from Monday-Friday, 9:00 AM-5:00 PM PST/PDT) for further instructions.

IN THE EVENT OF AN ORIGINAL DEFECT IN MATERIAL AND/OR WORKMANSHIP, TO THE EXTENT PERMITTED BY LAW, THE REMEDIES SET FORTH IMMEDIATELY ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES.

FCC REQUIREMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Model No.: DR-HHM015S
Rev_1.0_EN

We're Here to Help!

-  (888) 290-1688 Mon - Fri, 9:00 am-5:00 pm PST/PDT
-  www.dreo.com
-  support@dreo.com



www.dreo.com

Looking for help?

Contact us to get expert support.



support@dreo.com



[\(888\) 290-1688](tel:(888)290-1688)



www.dreo.com

Mon-Fri, 9:00 am-5:00 pm PST/PDT