

成品尺寸：84*135
材质：105G铜版纸

Powered by

Alibaba Cloud

Wireless
Hotspot Camera
Quick Operation Guide

Before using the product,
please read this quick operation guide carefully.

Download APP

Use your mobile phone to scan the QR code below to download the latest AVIEW APP directly.

You can also search for the keyword "AVIEW" in App Store, Android Market, Google Play, and Apple Store to download the latest APP.

AVIEW

Create Account

1

Sign up

Select Registration Method

Mobile Number

Send

2

Sign up

Register ID and agree to the Terms of Service/Privacy Policy

Send

3

Manage Account Information

Profile

Add Device

1. Click Add, scan the QR code of the device

1

Device

+

2

Scan

QR Code

If the QR code on the device cannot be scanned, please click "If the QR code is not found, add the device directly", and then select "Scan the device to add".

3

Scan

QR Code

4

Device scan code added

4G card activation

Wireless hotspot connection

2. Scan code to add connected devices

1

Device initialization

Scan QR code with camera

2

Network Link

Scan QR code

3.1. Wireless hotspot connection device (Android phone)

1

Search devices

Device initialization

2

Name your Device

Device scan code added

3

Network Link

Connect device hotspot

4

Search devices

Name your Device

3.2. Wireless hotspot connection device (iPhone)

1

Device scan code added

4G card activation

Wireless hotspot connection

2

Search devices

Name your Device

3

Connect device hotspot

Connect device hotspot

4

Search devices

Name your Device

PTZ Control

Room

2020-07-18 11:45:25 Saturday

Message Picture Quality Flip Full screen

Zoom

PTZ Speed Control

Focus

Record Snapshot Call Sound Playback

Powered by

Alibaba Cloud

5

Configure WiFi network

Search devices

6

Reset access configuration

Name your Device

7

Search devices

Name your Device

8

Search devices

Name your Device

4. If adding a device fails, please follow the suggested solution prompts, double check, reset the device and add it again.

1

Search devices

Search devices

2

Reset device

Reset device

Hotspot Viewing Device

1

WLAN

Room

2

Room

Room

Equipment Function

1

Devices

Room

2

Room

Room

3

Room

Room

4

Room

Room

Preset Location Collection

1

Room

Room

2

Room

Room

Device sharing method

1

Room

Room

2

Room

Room

Warranty Card

1

Product Name

Model

2

Purchase Date

Distributor

3

Cause of issue

4

Fault Handling

5

Customer Name

Mailbox

6

Contact Number

Postcode

7

Contact Address

8

QC PASS

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure statement:

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.