

G810无线游戏耳机使用说明书 (在使用的请仔细阅读本说明书,并妥善保管!)	按键及接口定义
---	--

 ①**音量+/下一曲按键**:短按一次音量加一级,长按切下一曲;音量达到最大时会有“Max volume”提示音。 ②**音量-/上一曲按键**:短按一次音量减一级,长按上一曲;音量达到最小时会有“Min volume”提示音。 ③**多功能按键MFB**: (1)开机:长按2秒耳机语音提示“Power on”。 (2)关机:开机状态下,长按3秒进入关机,语音提示“Power off”。 (3)配对:关机状态下,长按5秒进入配对状态,语音提示“Pairing”。 (4)暂停/暂停:在音乐播放时,短按一次为播放或暂停音乐。 (5)接听/挂断来电:有来电时,短按一次为接听来电,长按1秒为拒接来电;通话时,短按一次为挂断当前通话。 ④**灯光关闭按键**:关闭开启LOGO灯光。 ⑤**MIC按键/音效模式切换**: (1)按一次为麦克风关闭,语音提示“MIC OFF”;再按一次为麦克风打开,语音提示“MIC ON”。 (2)游戏模式与音乐模式切换:长按2秒进行模式切换,有语音提示Gaming mode或Music mode。 ⑥**蓝牙指示灯窗口**: (1)开机蓝牙灯闪 (2)配对状态蓝牙灯交替闪烁 (3)来电时蓝牙灯闪烁接听电话后蓝灯长亮 (4)充电时蓝灯以2次闪烁 ⑦**Line In 3.5mm音频输入接口**:当插入3.5mm的插头线,耳机即自动关机,耳机播放外接设备的信号。(耳机的麦克风不支持有线路输入) ⑧**Type C充电接口**:连接的充电器规格为DC5V/1000mA,插入充电时耳机会自动开机。 ⑨**充电状态指示灯窗口**:充电时长亮红灯,充电电量红灯熄灭,绿灯长亮。 ⑩**左右耳亮灯开关**:开机后耳壳亮灯亮起,可通过操作键进行关闭或开启。 | 基本操作说明 **1.开机与关机及Dongle配对:** ●在开机状态下长按音量加键2秒后,蓝牙耳机进入开机状态(语音提示“Power on”),耳机开机后,有配对连接过的会优先进入配对,无配对连接过的会进入配对状态(语音提示Pairing)。在配对状态下,手机等带蓝牙功能的设备可以搜索并连接耳机,连接成功后会退出配对状态。 ●手动进入配对:在关机状态下,长按音量加键,耳机开机后音量键进入配对状态。 ●耳机进入配对状态后,工作指示灯窗口显示亮蓝色指示灯交替闪烁。打开手机蓝牙功能,设置为可发现状态,并开启搜索新设备,在搜索的设备清单中找到“SOMIC G810”,点击配对即可,连接后手机与耳机连接成功,语音提示“Connected”,即完成配对连接过程。连接成功后耳机的音量指示灯熄灭。 ●蓝牙耳机配对:耳机在开机配对状态下,蓝牙耳机插入到电脑/手机的Type-C接口或充电接口,使用随机的Dongle无线连接至USB-A公头转Type-C插座(配合使用)当设备识别成功后,语音提示“Connected”,此时耳机蓝色指示灯熄灭,蓝牙耳机发射器的蓝色指示灯会长亮。 ●出厂时蓝牙耳机与蓝牙耳机已经配对好,把蓝牙耳机插到随机的USB口上,蓝牙耳机即会自动连接。(如有不能连接的情况,请按照上述步骤进行手机与蓝牙耳机发射器重新配对连接) **2.关机:** ●蓝牙耳机在开机状态,长按音量加键3秒,同时有“Power off”提示音,蓝牙耳机进入关机。 **3.音量+/下一曲** ●在连接设备播放音乐状态下,短按音量加键1次,声音增加1级,音量达到最大时会有提示音“Max volume”,长按音量加键,为音乐切换下一曲。 **4.音量-/上一曲** ●在连接设备播放音乐状态下,短按音量减键1次,声音减少1级,音量达到最小时会有提示音“Min volume”,长按音量减键,为音乐切换上一曲。 || 扫码关注硕美科官方微信 获取更多产品信息 广东硕美科高新技术有限公司 硕美科官方网站:www.somic.cn 400-698-9993 | **5.麦克风静音** ●静音状态时,按一次音量减为麦克风关闭,语音提示“MIC OFF”;再按一次音量加为麦克风打开,语音提示“MIC ON”。 ●静音模式与音乐模式切换:长按音量加2秒进行模式切换,有语音提示Bee Play mode或Music mode。 **6.灯光调整**:短按一次音量减,关闭或开启LOGO灯光。 **7.接听电话** ●当连接的手机有来电时,语音提示In coming call,耳机的蓝灯闪烁,短按音量加一次可接听来电电话,接听电话时,耳机的音量灯长亮,再短按一次音量加键挂断电话,长按1秒为拒接来电功能。 **8.充电提醒** ●耳机在连接手机状态下,双击音量减一次,手机会自动提醒蓝牙耳机最后一个拔出去的充电手机。 **9.低电量提示** ●此耳机具有低电量语音提示功能,当电池进入低电量状态,每隔4分钟就会有语音提示“low Power”,同时耳机的红色指示灯每3秒连续闪烁。 **10.充电使用** ●耳机内置锂电池,建议在首次使用耳机前对电池进行充电。 ●耳机使用中当电池电量过低时,耳机会听到“low Power”提示音,请及时充电。 ●将充电插头插入充电口,耳机进入,自动关机,此时音量减指示灯亮,充满电量,红色指示灯熄灭,并亮起绿色指示灯。 **11.蓝牙耳机配对的使用** ●出厂时蓝牙耳机与蓝牙耳机已经配对好,把蓝牙耳机插到随机的USB口也可以通 【售后服务】 | 故障现象 | 可能原因 | 解决方法 | |-------|--|--------------------------| | 无法开机 | 电池电量不足 | 及时给电池充电 | | 无法配对 | 手机未启动蓝牙功能或尚未打开“可发现”状态 | 启动手机蓝牙功能并设置为“可发现”状态 | | 噪音大 | 配对时,耳机离发射器距离太远 | 距离请不要超过1米 | | | 电池电量不足 | 及时给电池充电 | | | 电池电量不足 | 及时给电池充电 | | 断音 | 1,耳机离发射器距离太远
2,耳机离发射器距离之间
有障碍物阻挡 | 重新调整合适位置收听 | | 接收距离短 | 1,发射器设备兼容性问题的。
2,耳机关离发射器距离之间有障碍物阻挡。 | 1,更换发射设备
2,重新调整合适位置收听 | 产品特点: 1. 耳机具备四种连接模式,包括普通蓝牙模式、蓝牙低功耗模式(分两种连接模式)和3.5mm有线模式,可多种场景、多种设备使用。 2. 耳机具备“模拟线”和音乐模式两种音效,听歌、游戏两不误。 3. 耳机搭载强劲低音吸引耳,延迟低至3ms,可尽情享受音画同步的游戏体验 4. 耳机采用航天级工学经优化设计,长时间佩戴也不累。 5. 耳机内置100毫安大容量锂电池,超长续航,充一次电可满足您一周的使用需求。 6. 耳机配备柔软透气大尺寸网布耳罩,佩戴舒适。 7. 耳机配备炫光灯,释放炫酷激情。 | 硕美科无线降噪耳机保修说明 保修条例 硕美科无线降噪耳机售后服务承诺:严格依据《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务,服务内容如下: 在三包有效期内,您可依照国家规定享受修理、换货、退货的权利,修理、换货、退货的权利应当凭发票或有效销售凭证办理。 1. 自您签收收货日起7日内,产品出现品质问题,可享受退货、换货或者免费维修服务。 2. 自您签收收货8日-15日内,产品出现品质问题,可享受换货或者免费维修服务。 3. 自您签收收货12个月内,产品出现品质问题,可享受免费维修服务。 非保修条例 1、已超过三包有效期; 2、无法提供发票或有效销售凭证; 3、发票或有效销售凭证上的产品型号与实物不相符; 4、未经授权的维修、拆装或改动用户为原因或不可抗力所造成的损坏。 注意事项 1. 本产品兼容兼容Windows7/8/10、安卓Android、苹果MAC与iOS操作系统,适配XBOX与PS4主机。如果在未列明的操作系统和设备上使用,导致无法正常工作的,可联系售后服务寻求解决; 2. 产品使用过程中,如果出现部件损坏,如线缆被破皮等,请停止使用并寻找有维修资质的人员或售后服务解决,以免造成不必要的损失; 3. 本产品可能部分与品牌的延长寿命卡不适配,如果使用延长卡而引起冲突,可联系售后服务寻求解决; 4. 使用本产品时,如果遇到驱动兼容性等问题,可联系售后服务寻求解决。 | 产品保修卡 尊敬的顾客: 您好!申请售后时,请根据您的实际情况填写产品保修卡,并把产品与产品保修卡一同寄回您所购买产品的商家处,谢谢! 1.请勾选进行售后的原因: ☐功能不好 ☐不影响 ☐佩戴不舒服 其他: _____ 2.请勾选您所售的售后选项: ☐换新 ☐维修 ☐退货 3.请您给我们提供宝贵的意见: 注:具体售后地址请咨询商家。 请填写以下资料(以下均为必填) 产品信息 产品型号: _____ 产品序列号: _____ 购机信息 订单编号: _____ 购买姓名: _____ 用户姓名: _____ 联系电话: _____ 回购地址: _____ |


Product Specification

- Bluetooth version:V5.2
- Transmit power : CLASS2
- Wireless connection range : about 10m
- Operating frequency range : 2402-2480MHz
- Build-in rechargeable lithium battery capacity: 1000mAh
- Connection charge specification : DC 5.0V 1000mA
- Normal charging time : about 3 hours
- Headset continuous working time : about 50 hours (Turn off LOGO light, 60% volume play music)

Product function

- support stereo music playback, play / pause, volume size / music selection up and down, microphone off / on and many other functions
- support telephone: answer, end, reject, redial the last number and other common functions
- support operation voice prompt
- support earphone low battery prompt
- support hfp1.7, hsp1.2, a2dp1.3, avrtp1.6
- support AAC and SBC audio decoding
- support low delay game function (dongle connection)

Key and socket definition



①Volume + / next key: short press once to increase the volume by one level, long press to switch to the next song. When the volume reaches the maximum, there will be a "Max volume" prompt tone.

②Volume - / previous key: short press once to reduce the volume by one level, long press the previous key. When the volume is reduced to the minimum, there will be a "Min volume" prompt tone.

③Multifunction key MFB :

- (1) Power on: press and hold for about 2 seconds, and the voice prompts "power on".
- (2) Power off: In the power on state, press and hold for about 3 seconds to power off, and the voice prompts "power off".
- (3) Pairing: in the off state, press and hold for about 6 seconds to enter the pairing state, and the voice prompts "pairing".
- (4) Play / pause: when playing music, press once to play or pause music.
- (5) Answer / end an incoming call: when there is an incoming call, short press once to answer the call, and long press for 1 second to reject the call; During a call, short press once to end the current call.
- ④Light switch button: turn off / on the logo light effect.
- ⑤Mic key / sound effect mode switch key :
 - (1) Press once to turn off the microphone, and the voice prompts "mic off". Press again to turn on the microphone, and the voice prompts "mic on".
 - (2) Switching between game mode and music mode: long press for 2 seconds to switch modes, and there is a voice prompt of "game mode" or "music mode".
- ⑥Bluetooth indicator window :
 - (1) Startup blue light flashes slowly
 - (2) Pairing status red and blue lights flash alternately
 - (3) The blue light flashes quickly when an incoming call is made, and the blue light stays on after answering the call
- ⑦Type C charging interface: the connected charger is dc5v/1000ma, and the headset will automatically shut down when plugged in for charging.

(4) Red light double flashing /3 s at low battery

⑧Line in 3.5mm audio input interface: when a 3.5mm plug cable is inserted, the headset will automatically shut down and play the signal of the external device, (the microphone of the headset does not support wired input) (Charging status indication window: the red light will be on for a long time during charging, and the red light will go out and the green light will be on for a long time after being fully charged.)

⑨Left and right ear shell lights: the ear shell lights up after startup, and can be turned off or on by operating ⑤.

Bluetooth transmitter pairing : Bluetooth transmitter is inserted into the computer USB port, when the equipment identification is completed, the blue lights flash slowly, with a thimble by pairing inside the shell of the round hole pressing button for 2 seconds, pairing blue tooth transmitter into the state, the blue indicator light flash, when the blue tooth transmitters and blue tooth headset paired and Connected successfully finished, voice prompt "Connected", The blue light on the Bluetooth transmitter will light up.

•Remark : The Bluetooth headset and the Bluetooth transmitter have been paired at the factory settings. Plug the Bluetooth adapter into the USB port of the computer, and the headset will automatically connect after it is turned on.If it can't match pls follow previous step to re-match again for headphone and USB dongle.

2.Power off

• When the Bluetooth headset is on, long press the "③" button for about 3 seconds, and at the same time, there will be a prompt tone of "Power off", and the Bluetooth headset will turn off

3. Volume + / Next track

• When the device is connected to play music, press the volume "②" button once to increase the sound level by one level. When the volume reaches the maximum, there will be a prompt sound "Max volume". Long press the "②" key to switch to the next track for the music.

4. Volume - / Last song

• When the device is connected to play music, press the volume "②" button once to reduce the sound level by 1. When the volume reaches the minimum, there will be a prompt sound "Min Volume". Hold down the volume "②" button long to switch to the previous track.

5. Mute MIC

• During a call, press the "⑤" button once to turn OFF the microphone, and the voice prompt "MIC OFF" will be displayed. Press the "⑤" button again to open the microphone, and the voice prompt "MIC ON" will be displayed.

• Switch between bee play mode and music mode: long press the ③ key for 2 seconds to switch modes, and there is a voice prompt of bee play mode or music mode

6. Light button: briefly press the button ④ by once to turn off or turn on the light.

7.Calls

•When the connected mobile phone has an incoming call, the voice prompts "in coming call", and the blue light of headset flashes.Press ④ once to answer the call,the blue light of headset ④ will be on when answering the call,press ② again to hang up the call and hold for 1 second to reject the call

8.Last number redial

•When the headset connected the mobile phone, short press ③ twice in succession, the device will automatically redial the last phone number dialed by the mobile phone

9.Low power warning

•This headset has a low-power voice prompt function. When the battery enters a low-power state,there will be a voice prompt "low power" every 4 minutes,and the red indicator light of the headset flashes twice every 3 seconds.

10. Charging instructions

•The headset has a lithium battery, and it is recommended for you to charge the battery before first using the headset.
•When the battery power of the headset is too low during use, there will be a "Low Power" prompt sound, please charge it in time.
•Insert the charging plug into the ⑦ Type C plug and the headset will automatically shut down. At this time, the charging red indicator light will be on. When it is fully charged, the red indicator light will turn off and the green indicator light will stay on.

11. Bluetooth transmitter instructions

•The Bluetooth headset and the Bluetooth transmitter have been paired at the factory settings. Plug the Bluetooth adapter into the USB port of the computer or use the dongle extension cable on the USB interface/mobile phone, and the headset will automatically connect after it is turned on.

12.Headset restores the factory setting

Under the shutdown state, long press ③ and ④ button for 10 seconds to sound the prompt "beep" when the factory setting is completed. The blue light and red light of the headset double flash 3 times at the same time.(Note: Headphone recovery from factory settings removes all previous pairing information)

13.wired mode:

Connect the 3.5mm audio cable to the headset; In this mode, only the microphone on the audio cable can be used, and the microphone on the headset cannot be used.

Reminder

1. Please read the operating instructions carefully and keep them properly before using this product.
2. Please charge the product for the first time.
3. In order to maintain the normal service life of the battery, please ensure that the product is used at least once in two weeks, and please supplement the power in time after use.
4. Chargers produced by regular manufacturers and certified by CCC must be selected.
5. If the mobile phone cannot receive the Bluetooth headset, please confirm whether the Bluetooth headset is in the "pairing mode". If the headset has not been paired or connected for a long time, please restart the headset or restore the factory settings before using.

Headset and Accessories

1.Headset	1PC
2.Type c charging	1PC
3.User Manual	1PC
4.Dongle	1PC
5.3.5mm Audio cable	1PC
6.Dongle Extension cable	1PC

Using Statement

- 1.Do not use headphones during charging.
- 2.When wearing headset outdoors, choose safe sports venues and roads, adjust the appropriate volume, and pay attention to traffic safety.
- 3.Do not use headset while driving a motor vehicle.

After-sales service

In order not to waste your valuable time, please check the following items before repair.

Fault phenomenon	Possible reasons	Exclusion method
Unable to boot	The battery power is insufficient.	Charge the battery in time.

Unable to Pairing

The phone has not yet enabled the Bluetooth function or has not yet opened the discoverable status.

Start Bluetooth and set to discoverable.

The battery power is insufficient.

Charge the battery in time.

The noise is large

The battery power is insufficient.

Charge the battery in time.

Staccato

1. The headset is too far from the transmitter, beyond the receiving range.

2. There is an obstacle between the headphones from the transmitter.

Resweak properly to listen.

The receiving distance is short

1. Transmitter equipment compatibility issues.

2. There is an obstacle between the headphones from the transmitter.

1. Replace the transmitting equipment

2. Reset the appropriate location to listen

Product Features :

1.The headset has four connection modes, including normal Bluetooth mode, Bluetooth low-latency mode (USB-A And Type C connection modes) and 3.5mm wired mode, which can be used in various scenarios and devices.

2.Headset with game mode and music mode two kinds of sound, listening to songs, games can be.

3.The headset comes with a powerful low latency engine, which can be as low as 35ms to enjoy the game experience of audio and picture synchronization.

4.The headset is ergonomic and lightweight, which makes it easy to wear for a long time.

5.The headset has a built-in 1000mah battery, which can last you a week on a single charge.

6.The headset are equipped with soft and breathable large size mesh earmuffs for comfort.

7.Headset with cool lighting, release the passion of e-sports.

G810 Wireless Gaming Headset Instruction Manual

Please read this manual carefully when using it and save it

FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.	
--	--