

**JVC**  
WIRELESS HEADPHONES  
HA-B5T

Instruction Manual



website : [us.jvc.com](http://us.jvc.com)

**PRODUCT DESCRIPTION**



1. Charging Case  
2. Power Button Status LED  
3. Multi Function Button (MFB)  
4. Status LED

**SPECIFICATIONS**

- Wireless version: V5.0
- Wireless range: 10M
- Playtime: 4 Hours
- Charging Time: 1 hr earbuds  
1.5 hr charging case
- Battery Capacity: Earbuds 30mAh  
Case 200mAh
- Operation Frequency: 2402-2480MHz
- Operational Temperature: -10 – 40°C
- Charging Port: Type-C

**PACKAGE CONTENTS**

Earbuds x 2	Earbuds caps:
Charging case x 1	Size S x 2
Charging cable x 1	Size M x 2 (installed)
User manual x 1	Size L x 2

**CHARGING THE EARBUDS**

Put the earbuds into the charging case, the earbuds will be charged automatically. The red status LED light will be on during charging and will turn off when fully charged.

**CHARGE THE CHARGING BOX**

Use a Type-C cable connected to a USB charger (DC 5V-1A)

**THE STEPS FOR DUAL EARBUDS PAIRING (FIRST USE ONLY)**

Take out both earbuds from the charging case the same time. LED light on both earbuds will be flashing blue & red at first. One of the earbud's LED light will turn Off after 2 seconds. It means that both earbuds are ready to pair. Turn on the bluetooth on your device and search for a new device then select "JVC HA-B5T" to connect.

**HOW TO RE-CONNECT**

The earbuds will automatically try to re-connect with the last paired device after re-start. If not, please put earbuds back to charging case and try again or connect manually.

**Caveats**

1. Never disassemble or modify your earbuds for any reasons to avoid any damages and danger.  
2. Do not store the earbuds and charging case in extreme temperatures (under 5°C or over 35°C).  
3. Avoid using the indicator close to the eyes of children or animals.  
4. Do not use this earbuds during a thunderstorm to avoid irregular function and increased risk of electricshock.  
5. Do not use harsh chemicals or strong detergents to clean the earbuds.  
6. Keep the headset dry.

**COMMON PROBLEMS AND SOLUTIONS:**

1. The mobile phone cannot find the wireless earbuds
  - Check whether the earbuds power is switched On or not.
  - Does the status LED light flicker red & blue alternatively? If the wireless earbuds still haven't been found after switching power On, please restart both the earbuds and the bluetooth search on your phone.
2. There is something wrong with the wireless earbuds while using it.
  - Please try to re-connect with the mobile phone after turning it Off and restarting the earbuds.
  - Check the charging status of the earbuds by putting them into the charging box until the red LED indicator is On. Then take them out and let them trying to re-connect with the mobile device.
3. The wireless earbuds always disconnect or make noise when connected to the mobile device.
  - The wireless earbuds power status is low, please re-charge it.
  - There is an obstruction between the mobile device and the wireless earbuds, or the wireless distance is beyond signal range. Please do not cover the wireless earbuds with your hands in order to maintain the continuous stability of the signal; please try to keep the wireless earbuds and the mobile device in the same direction

**FCC Statement:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**FCC CAUTION:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines as this equipment has very low levels of RF energy.

**Tips:**

1. Before using the earbuds, please read the manual carefully and keep it for future references.
2. The earbuds need to be fully charged prior to first-time use.
3. If the earbuds is left unused for over two weeks, please recharge it periodically.
4. Please use the chargers made by qualified manufacturer.
5. If the earbuds cannot be found by your phone, please check whether it is in pairing mode; if left unconnected for a long while, the earbuds will exit pairing mode, please re-enter the mode; if a procedure error of your phone occurs, reboot it; if a procedure error of the earbuds occurs, reboot or reset it.

Function	Operation
Power on	Take out the earbuds from the charging case. Or long press MFB
Power off	Put the earbuds into the charging case.
Pairing Mode	LED light flashing red & blue at first. One of the earbuds will be off automatically after 2 seconds.
Connected	LED light is off on both earbuds
Charging case charging	Red LED light flash
Charging case fully charged	Red LED light is on
Earbuds charging	Red LED lights on earbuds are on.
Earbuds fully charged	Red LED lights on earbuds turn off automatically.
Play/Pause	Single touch MFB
Picking up incoming call	Single touch the MFB
End phone call	Single touch the MFB
Reject incoming call	Long touch the MFB
Next song	Triply press the MFB of the right earbud
Previous song	Triply press the MFB of the left earbud

For Customer Use:  
Enter the Model No. and Serial No. (on the charging case ) below.  
Retain this information for future reference.

Model No. \_\_\_\_\_  
Serial No. \_\_\_\_\_

Supplier's Declaration of Conformity  
Model Number : HA-B5T  
Trade Name : JVC  
Responsible party : JVC/KENWOOD USA Corporation  
Address : 1440 Corporate Drive, Irving, TX 75038  
Telephone Number: (678)449-8879  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2A3ZQ-HABST

**ATTENTION:**  
The product you have purchased is powered by a rechargeable battery that is recyclable. Please call 1-800-8-BATTERY for information on how to recycle this battery.

**MADE IN CHINA**

**Support**

**JVC** IS HERE TO HELP!

TOLL FREE: 1(800)252-5722

<http://www.us.jvc.com>