

KF-01/KF-01C
摇头夹子风扇

— 说明书 —

【产品结构】

【产品参数】

产品名称：摇头夹子风扇
产品型号：KF-01 (标准版) / KF-01C (遥控版)
材料：ABS+PP+PC
风扇功率：5.5W
充电输入：DC 5V=2.0A (MAX)
充电时间：3-5 小时
使用时间：2.5-13 小时 (根据不同档位 / 模式而定)
电池容量：4000mAh (14.8Wh/3.7V)
产品重量：535g
产品尺寸：162 (L) x 125 (W) x 230 (H) mm
执行标准：GB4706.1-2005; GB4706.27-2008

【使用方法】

A.开关、风速、摇头、显示：

- 1.长按开关 1.5s 可使风扇开关或关机；
- 2.在风扇开启的状态下，旋转开关：
- 每顺时针转动一下，风速增加5%，最高为100%；
- 每逆时针转动一下，风速减少5%，最低为10%；
- 3.在风扇开启的状态下，短按开关，可打开或关闭摇头；
- 4.当转动开关调整风速时，显示屏显示为风速百分比，随后1.5s自动跳转为电量百分比。

B.手动调节：

C.如何清洁：

清洁保养
1.断开电源后,请确保电源已被切断。
2.风扇叶片可用干净的抹布擦洗,面罩、扇叶及后罩清洗完毕后请静置至完全干燥方可安装使用。
3.禁止用水或其他液体清洁电源及电器部件。
4.禁止用湿润的手或者抹布触碰电源及电器部件。

D.充电说明：

- 1.产品内置4000mAh锂离子电池,超强续航能力,且支持边充边用。
- 2.为延长电池使用寿命,当产品电量低于10%时,请及时充电。
- 3.产品充电时DC5V=2A,如果充电适配器不是2A会影响充电时间。
- 4.产品进行充电时,屏幕上会显示内部电池和当前电量。
- 5.当显示屏显示100%时表示电池已经充满。
- 6.产品使用充电器充电时,使用充电器应获得ccc认证。

E.遥控器说明：

【包装配件】

摇头夹子风扇*1
Type-C充电线*1
说明书*1
遥控器 (KF-01C配遥控器)*1

【产品中有害物质的名称及含量】

部件 名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr VI)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
塑料件	○	○	○	○	○	○
金属件	○	○	○	○	○	○
硅胶件	○	○	○	○	○	○
PCB	×	○	○	○	○	○

本表根据欧盟RoHS 2014/35/EU 规定编制。

○表示该有害物质在该部件所用材料中的含量在GB/T 25722规定的限量要求以下。

×表示该有害物质在该部件所用材料中的含量超过了GB/T 25722规定的限量要求。

□表示该有害物质在该部件所用材料中的含量超过了GB/T 25722规定的限量要求。

本公司产品正常使用年限为10年。

本公司产品实行保修年限之内的有限保修。

属于下列情况的设备故障或者损坏,不在有限保修之列,本公司不承担免费保修义务;

1.设备或部件以及超过了有效的保修期;

2.客户未按照说明书的要求,错误的安装、保管以及使用而造成的设备故障或损坏;

3.非由本公司授权机构或人员拆卸而造成的设备故障或损坏;

4.因意外因素或者人为因素(包括但不限于操作失误、刮伤、搬运、磕碰、输入不合适的电压电流等)导致的设备故障或损坏;

5.因自然灾害等不可抗力(如地震、火灾等)原因造成的设备故障或者损坏。

产品保修卡

(本卡仅适用于中国大陆)

产品名称 联系电话
产品型号 购买地址
用户名 销售商名称
购买时间

【以下情况恕不提供免费维修】

本公司产品实行保修年限之内的有限保修。

属于下列情况的设备故障或者损坏,不在有限保修之列,本公司不承担免费保修义务;

1.设备或部件以及超过了有效的保修期;

2.客户未按照说明书的要求,错误的安装、保管以及使用而造成的设备故障或损坏;

3.非由本公司授权机构或人员拆卸而造成的设备故障或损坏;

4.因意外因素或者人为因素(包括但不限于操作失误、刮伤、搬运、磕碰、输入不合适的电压电流等)导致的设备故障或损坏;

5.因自然灾害等不可抗力(如地震、火灾等)原因造成的设备故障或者损坏。

【注意事项】

- 1.长时间近距离直吹强风可能会导致不适,尤其是婴儿和老人。
- 2.本机使用的是锂离子电池,无记忆效应,可随用随充不必等到电池耗尽才充电,随时保持电池有电,有利于延长电池寿命。
- 3.风扇工作时风叶会高速旋转,严禁将异物伸进风扇内,否则可能会造成机器损坏。
- 4.10岁以下儿童使用产品,必须在成人监督下使用,避免造成危险。
- 5.风扇摇头过程中,请勿人为干扰产品运行。(使用外力打乱正常摇头方向及速度)。
- 6.请勿用力拉扯或者弯折扇叶,装回时用力将扇叶盖好,避免扇叶安装不当而导致产品开裂,请勿用力拉扯或者弯折扇叶,装回时用力将扇叶盖好,避免扇叶安装不当而导致产品开裂。
- 7.清洗风扇时勿弯折扇叶,装回时用力将扇叶盖好,避免扇叶安装不当而导致产品开裂。
- 8.当产品开裂时,应取出电池单独回收。

【三包凭证】

- 1.请妥善保管维修卡,以做维修时的凭证。
- 2.保修期内产品购买之日起一年内。
- 3.保修期间,本产品在正常使用的条件下发生故障,经本公司查验属实,将免费提供维修和换新服务。

【产品保修卡】

(本卡仅适用于中国大陆)

产品名称 联系电话
产品型号 购买地址
用户名 销售商名称
购买时间

D. Charging Descriptions:

1. Product built in 4000mAh rechargeable battery, working while charging is available.
2. For a better battery life, please charging when the battery power reach to 10%.
3. Product input with DC5V=2A, it will effect the charging time if the adapter input less than 2A.
4. It will display the flash icon & power percentage while charging.
5. Full charged when the display shown 100%.
6. Please use standard charging adapter.

E. Remote Control Description:

1. KF-01C is Remote control version。
2. 4 buttons on the remote control: ON/OFF, Rotating, Increase wind speed, Reduce wind speed.
3. Before use the remote control,please take off the plastic sheet.
4. Remote control point to the LED display, press ON/OFF to turn on the fan.
5. Oscillating function only working when the fan is on.
6. Press "Wind speed+" & "Wind speed-",once, increase or reduce wind speed 10%.
7. Remote control build in a CR2025 3V button cell.

F. Three-guarantee Certificate

1. Please keep the warranty card properly as a certificate for maintenance.

2. The warranty period is within one year from the date of purchase.

3. During the warranty period, if this product breaks down under normal use and is verified by our company, we will provide maintenance and replacement service free of charge.

【Free maintenance is not available under the following circumstances】

Our products are subject to limited warranty within the warranty period. Equipment failure or damage under the following circumstances is not covered by the limited warranty and the Company will not undertake the warranty obligation free of charge.

1. Equipment or parts have exceeded the valid warranty period.

2. Equipment failure or damage caused by the customer's incorrect installation, storage and use according to the instructions.

3. Equipment failure or damage caused by disassembly by non-authorized agencies or personnel of the Company.

4. Equipment failure or damage caused by unexpected factors or human factors (including but not limited to operating errors, scratches, handling, bumping, input of inappropriate voltage and current, etc.).

5. Equipment failure or damage caused by force majeure such as natural disasters (e.g. earthquake, fire, etc.).

【Precautions】

1. Directing the fan at people with a high level of airflow for a long time will cause discomfort especially for infants and the elderly.
2. The battery provided for the fan is a lithium-ion battery without the memory effect, which can be recharge at any time rather than after the battery is exhausted. Keep it charged is conducive to extending its service life.
3. When the fan is working, the fan blades will rotate at high speed. Therefore, it is strictly prohibited to extend foreign objects into the fan, otherwise the fan may be damaged.
4. Children under the age of 10 should use the fan under the supervision of an adult to avoid dangers.
5. During the running of the under the oscillation mode, please never disturb it. (For example, force to disturb its normal oscillating direction and speed.)
6. Do not pull or bend the fan steering lever to avoid damage.

本说明书的内容及产品的相关信息将根据实际情况进行更新,恕不另行通知
The contents of this manual and the specification of the product are subject to change without prior notice

KF-01/KF-01C
Oscillating Clip Fan

— User manual —

【Product Structure】

【Product Parameters】

Product name: oscillating clip fan
Product model: KF-01/KF-01C
Material: ABS+PP+PC
Fan power: 5.5W
Input: DC 5V=2.0A (MAX)
Charging time: 3-5hrs
Working Time: 2.5-13hrs (Different wind speed/mode)
Battery capacity: 4000mAh (14.8Wh/3.7V)
Product weight: 535g
Product size: 162 (L) x 125 (W) x 230 (H) mm

【How to Use It】

A.On/Off, Wind Speed, Oscillating Function, LED Display:

- 1.Long press 1.5s to turn ON or turn OFF;
- 2.Spin the button when it turn ON:
Clockwise rotation once, wind speed increase 5%, until to 100%;
Counterclockwise rotation once, wind speed reduce 5%, until to 10%;
- 3.Short press the button to turn the Oscillating ON or OFF;
- 4.While adjusting the wind speed,wind speed percentage displaying, after 1.5s it will switch to battery percentage .

B. Manual adjustment:

C. How to clean it:

- 7.While cleaning blades,do not bend and folding the fan blade, when put the blade back,make sure to put in correct position,otherwise it will causes the fan not working.
- When the product is discarded, the battery inside should be taken out and recycled separately.

【Three-guarantee Certificate】

1. Please keep the warranty card properly as a certificate for maintenance.

2. The warranty period is within one year from the date of purchase.

3. During the warranty period, if this product breaks down under normal use and is verified by our company, we will provide maintenance and replacement service free of charge.

【Free maintenance is not available under the following circumstances】

Our products are subject to limited warranty within the warranty period. Equipment failure or damage under the following circumstances is not covered by the limited warranty and the Company will not undertake the warranty obligation free of charge.

1. Equipment or parts have exceeded the valid warranty period.

2. Equipment failure or damage caused by the customer's incorrect installation, storage and use according to the instructions.

3. Equipment failure or damage caused by disassembly by non-authorized agencies or personnel of the Company.

4. Equipment failure or damage caused by unexpected factors or human factors (including but not limited to operating errors, scratches, handling, bumping, input of inappropriate voltage and current, etc.).

5. Equipment failure or damage caused by force majeure such as natural disasters (e.g. earthquake, fire, etc.).

【Precautions】

1. Directing the fan at people with a high level of airflow for a long time will cause discomfort especially for infants and the elderly.
2. The battery provided for the fan is a lithium-ion battery without the memory effect, which can be recharge at any time rather than after the battery is exhausted. Keep it charged is conducive to extending its service life.
3. When the fan is working, the fan blades will rotate at high speed. Therefore, it is strictly prohibited to extend foreign objects into the fan, otherwise the fan may be damaged.
4. Children under the age of 10 should use the fan under the supervision of an adult to avoid dangers.
5. During the running of the under the oscillation mode, please never disturb it. (For example, force to disturb its normal oscillating direction and speed.)
6. Do not pull or bend the fan steering lever to avoid damage.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

All other devices shall bear the following statement in a conspicuous location on the device:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Oscillating clip fan
Model Number:KF-01C

(Shenzhen Cassvie Technology Co., Ltd.)
(2A42R-KF01C)