




English


Smart Vibrator - Vivid Tadpole, human design and exciting play, let you enjoy the wonderful feeling. This product has a variety of ways to play, you can use it in different occasions. If you have any suggestions or comments about our products during the use, please feel free to contact us. It is your feedback that allows us to develop the exciting and innovative sex toys.



Turn off the device before charging. The cable can be plugged into any USB adapter for charging. It will take approximately 1.5 hours to fully charge. The indicator light will breathe when charging. Once it is fully charged the indicator light will stay on. You can also check the device's battery level in the App.

App Mode

Scan the QR code to download the App, or search "Dolp" for download on the App Store or Google Play. Press and hold the button for 3-5 seconds to start the device. Open the App, click the icon in the upper right corner of the interface to enter the device search. After find the device, click it and connect to the device. The device's work light will stay on when connection is successful and the icon changes to .



Manual Mode

Press and hold on/off button for 3-5 seconds to turn on or turn off the device, and then press the on/off button to switch modes after the device turn on.

1. Touch Mode: App controls the device to vibrate at different frequencies

2. Sound Mode: App controls the vibration of the device according to the sound decibel size of the environment. The sound decibel is high and the vibration is strong, and the sound decibel is small and the vibration is weak.

3. Music Mode: App controls the vibration of the device according to the frequency and tone of the playing music, and can select single, loop or random to play music.

4. Video Mode: App controls the vibration of the device according to the volume of the sound played by the video.

5. Election Mode: Select different frequency mode to control the vibration of the device, and each person can choose different frequency mode according to their preferences.

In App mode, multiple control modes are available:

7. Vibrations: Store saved vibration curve files and can play back to control device or share them.

8. Cloud Mode: Vibration curve files shared by others. You can download them to your phone. And play them to control the device to vibrate and experience the vibration curve of others. The curves you share will also be displayed here.

9. Setting


Click the avatar: Select your own avatar.

Vibration Point Selection: Select the location point where the device needs to be vibrated (G point or C point or both). If there is no multi-point selection, please use the default setting to G point. Vibration of G/C: Let the vibration intensity of point G be the percentage of G point. Use the default settings when there are no more choices.

Turn off device: In the connecting state, the device can be turned off directly.

Toy power: Displays the current power of the device.

Change password: Change the login password of the current account.



Use and Care

1. To avoid issues, only use water-based lube. Apply a proper amount of lube to the device and body before use.

2. Clean the device before and after each use. Clean with warm water or a sex toy cleaner.

3. Dry thoroughly before storing, keep away from extremely cold or heat places.

4. When the power of the device is seriously insufficient, please charge it in time.

Specifications

Name	Vivid Tadpole
Material	Body Safe silicone
Size	180mmx3.8mmx3.52mm
Weight	6 grams
Battery	Li-ion Rechargeable
Working Voltage	3.7v
Use Time	120 Minutes
Charging Time	90 Minutes



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.