


User Manuals



Contents

User Manuals.....	1
Notices.....	3
I. Product composition.....	3
II. Function of the Button and Touch Control.....	3
III. Charge Description and Music Storage (U Disk).....	4
IV. Installation of APP.....	5
V. Connection of APP.....	5
VI. Instructions of APP.....	7
VII. Use Instructions of Watch.....	9
VIII. Troubleshooting.....	16
IX. Brief Function Introduction of TWS Earphone.....	18

In order to ensure the safety and proper use of the product, please read this manual before use it.


Notices

- The service environment of the product (excessively high or low temperature, humid, rainy, diving or dusty environment), operation specifications, low battery, etc. may affect the normal use of the product, or even cause the damage to it. Please use the product properly;
- Please charge the product before first use, charging will take about 2 hours;
- In order to avoid the accidents, please use qualified accessories from formal manufacturers when charging;
- Do not charge the product when it is wet or in wet conditions;
- When measuring, the sensor should be close to the skin and avoid moving;
- The measurement results of the product are for reference only and cannot be used for medical purposes and basis;
- Some data such as time, weather, number of steps, sleep, etc., are synchronized with the mobile phone or network data after connecting the mobile phone through the APP and cannot be set manually.

I. Product Composition


Composition of product:
Watch; Earphones for the watch; Charging cable; User Manual; Packaging;

II. Function of the Button and Touch Control



1 English

III. Charge Description and Music Storage (U Disk)



1. After the magnetic cable is successfully connected, the watch will display a charging icon; the other end is connected to a standard USB interface, and the charging can be conducted.
- Notes:
 1. Do not charge in a humid, watery environment;
 2. Please ensure there is no dirt or corrosion on the watch body and the metal contacts on the magnetic charging cable;
 3. Please regularly clean the watch back and the metal contacts on the magnetic charging cable with a piece of clean flannel;
 4. This product is not equipped with a power adapter. In order to ensure the safety of family and property, you can use a computer USB interface or choose a power adapter with an output not exceeding 5V/1A for charging. In order to avoid the bursting or fire, don't buy or use low-quality and shoddy power adapters, please buy qualified power adapters through formal channels.
2. One end of the magnetic cable is connected to the watch, and the other end is connected to the computer USB interface. After the computer reads the U disk of the watch, the song is stored in MP3 format only.

IV. Installation of APP

1. Install and open the APP for the first time: Allow the APP to obtain the corresponding permissions by following the prompts. For iPhone, a Bluetooth pairing request will be prompted for the first time to connect the APP. Tap "Pairing" to connect, and the watch can accept notifications and alerts such as incoming calls and text messages pushed by the iOS system.
2. Open the APP, tap "Add Device", and search "T92" for connection. If there is more than one device nearby, when binding the device, select the MAC address of your watch (composed of 12 letters and numbers) to bind. (Check the watch MAC address through the method of watch's Settings>About-MAC address). If there is Bluetooth icon on the top of the watch or shows successful Bluetooth connection, it indicates that the watch and the mobile phone are successfully connected.
3. This product provides three Bluetooth signals, respectively are: "T92"/watch Bluetooth signal; "T92_Audio"/watch amplifier loudspeaker (watch speaker) signal; "T92-R"/watch Bluetooth earphone.

V. Connection of APP

1. Install and open the APP for the first time: Allow the APP to obtain the corresponding permissions by following the prompts. For iPhone, a Bluetooth pairing request will be prompted for the first time to connect the APP. Tap "Pairing" to connect, and the watch can accept notifications and alerts such as incoming calls and text messages pushed by the iOS system.
2. Open the APP, tap "Add Device", and search "T92" for connection. If there is more than one device nearby, when binding the device, select the MAC address of your watch (composed of 12 letters and numbers) to bind. (Check the watch MAC address through the method of watch's Settings>About-MAC address). If there is Bluetooth icon on the top of the watch or shows successful Bluetooth connection, it indicates that the watch and the mobile phone are successfully connected.
3. This product provides three Bluetooth signals, respectively are: "T92"/watch Bluetooth signal; "T92_Audio"/watch amplifier loudspeaker (watch speaker) signal; "T92-R"/watch Bluetooth earphone.

2 English

VI. Use Instructions of APP

- User registration: New users can register through the mobile phone number and email address. Registered users can record, save, and share the information content of the sports and health, while unregistered casual users cannot record and save relevant information.
1. Sports
 - As for the step numbers and sleep, it is used to view the data recorded by the watch and the data synchronized to the mobile phone, and the data can be viewed according to the date.
 - As for heart rate, blood pressure, blood oxygen, blood pressure, body temperature, tap "startCheck" and the watch will start to measure. Please wear the watch as per the user manuals when measuring. Select the icon in the upper right corner to view the recorded data.
 - As for GPs Running, select the icon in the upper right corner to view the recorded data. Select "Target Setting", tap "start Training", the watch will start to work. The "Map Track" can be viewed in the upper right corner. If you want to stop, long press "Pause" and select "End" or "Continue".
 2. Device
 - Display the status of connected devices. "Unbind" can release the connection between the APP and the watch.
 - selection of dial plate - customize dial plate, you can choose "digital dial plate" and "analog dial plate". Whether to display the month, day, and week on the "Display Date" dial plate. The settings here only apply to customize dial plate. You can choose a customize background by taking a photo or a picture stored in a mobile phone album.

VII. Use Instructions of Watch

1. Long press the UI interface of the main screen to enter the theme selection (you can also enter through the settings-theme selection). In this mode, the user can choose the system-provided dial plate or a custom dial plate.
2. swipe down on the main screen UI interface to enter the shortcut menu:
 - About: View device information: model, version number, date of manufacture, MAC address, etc.
 - Theme selection: the user can choose the system-provided dial plate or a custom dial plate.
 - Language: language set "Auto", the watch is synchronized with the language of the mobile phone.
 - style switching: Two options for style switching. Slide the UI interface of the main screen to the left to enter the menu mode to display different styles.
3. Go to settings

VIII. Troubleshooting

- 1. APP cannot be connected or some functions are unstable
 - The battery level of the watch may be too low and needs to be charged.
 - Check whether certain functions are in the corresponding watch mode. Please refer to Section 5-APP Connection - Article 3 of this Manual for details.
- 2. The battery level of the watch may be too low and needs to be charged.
- 3. Check whether the Bluetooth of the mobile phone is turned on and whether the mobile phone and the watch are properly connected.
- 4. Weather data is regularly updated by the APP in the background of the phone via the server, and then synchronized to the watch. Please confirm that the network connection is normal. The weather data provided by the server may be different from that of other platforms.
- 5. The update and upgrade of the data server may cause problems in data synchronization. Please wait patiently for the completion of the upgrade according to the announcement on the APP.

3 English

IX. Brief Function Introduction of TWS Earphone

1. Earphone pairing:
 - Take the earphones out of the watch host and there will be a power-on prompt. Open the Bluetooth in the phone settings and find corresponding Bluetooth name T92-R/T92-L for Bluetooth connection. The TWS earphones have been paired before leaving the factory. Only the Bluetooth name T92-R/T92-L is displayed. If you see "Connected" in the phone, it means that the product has been successfully connected.
 - Take out the earphones from the watch host, it will automatically power on and automatically be paired and connected.
 - If the earphone is disconnected from the phone while in service or the earphone is disconnected, the phone needs to be reconnected to Bluetooth. In the Bluetooth under the phone settings, there are previously connected Bluetooth models, please clear them first, and then search for Bluetooth T92-R/T92-L to connect.
 - Earphone pair connection: If there is only one side earphone with sound, then you need to connect the earphones in pair. Operation method of pairing between earphones:
 - 1) First, long press both earphones for 6 seconds to turn them off.
- 2) Long press both earphones at the same time to turn on. When turning on, press the two earphones 6 times at the same time when the lights of the two earphones are flashing alternately. After pressing 6 times, the two earphones will automatically turn off at the same time.
- 3) Turn on the two earphones at the same time, and only one of them will light up after turning on, which means the earphone pairing is successful.
- B: The middle surface of the headset is a touch surface, which is used to touch control of answer/hang up calls, control the previous and next music, volume up and down, and AI voice assistant.
- C: Answer/hang up the call
 - When the earphone is in the base of the watch and there is an incoming call, it will be automatically connected when it is taken out of the watch. When the earphone is in the watch for a long time, the incoming call needs to be answered manually. Tap the button to answer the call, then tap the button again to hang up. Put the earphones back into your watch during a call, and the earphones will return to the watch. If the caller does not hang up the call, it will automatically switch to the mobile phone to answer the call.
 - D: Play music
 - Single click is pause/play, double click is previous/next song, triple click is volume +/-.
 - E: AI voice assistant and making phone calls
 - When the earphone is connected to the Bluetooth, long press the touch key for 3 seconds to wake up the iPhone Siri function and Android voice assistant, which can be used to make phone calls, check the weather, navigate the map and other functions. The phone must be in the lock screen interface or the home screen of time to wake up the voice assistant effectively.

X. Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

4 English

XI. Use Instructions of Watch

1. Long press the UI interface of the main screen to enter the theme selection (you can also enter through the settings-theme selection). In this mode, the user can choose the system-provided dial plate or a custom dial plate.
2. swipe down on the main screen UI interface to enter the shortcut menu:
 - About: View device information: model, version number, date of manufacture, MAC address, etc.
 - Theme selection: the user can choose the system-provided dial plate or a custom dial plate.
 - Language: language set "Auto", the watch is synchronized with the language of the mobile phone.
 - style switching: Two options for style switching. Slide the UI interface of the main screen to the left to enter the menu mode to display different styles.
3. Go to settings

XII. Troubleshooting

- 1. APP cannot be connected or some functions are unstable
 - The battery level of the watch may be too low and needs to be charged.
 - Check whether certain functions are in the corresponding watch mode. Please refer to Section 5-APP Connection - Article 3 of this Manual for details.
- 2. The battery level of the watch may be too low and needs to be charged.
- 3. Check whether the Bluetooth of the mobile phone is turned on and whether the mobile phone and the watch are properly connected.
- 4. Weather data is regularly updated by the APP in the background of the phone via the server, and then synchronized to the watch. Please confirm that the network connection is normal. The weather data provided by the server may be different from that of other platforms.
- 5. The update and upgrade of the data server may cause problems in data synchronization. Please wait patiently for the completion of the upgrade according to the announcement on the APP.

XIII. Brief Function Introduction of TWS Earphone

1. Earphone pairing:
 - Take the earphones out of the watch host and there will be a power-on prompt. Open the Bluetooth in the phone settings and find corresponding Bluetooth name T92-R/T92-L for Bluetooth connection. The TWS earphones have been paired before leaving the factory. Only the Bluetooth name T92-R/T92-L is displayed. If you see "Connected" in the phone, it means that the product has been successfully connected.
 - Take out the earphones from the watch host, it will automatically power on and automatically be paired and connected.
 - If the earphone is disconnected from the phone while in service or the earphone is disconnected, the phone needs to be reconnected to Bluetooth. In the Bluetooth under the phone settings, there are previously connected Bluetooth models, please clear them first, and then search for Bluetooth T92-R/T92-L to connect.
 - Earphone pair connection: If there is only one side earphone with sound, then you need to connect the earphones in pair. Operation method of pairing between earphones:
 - 1) First, long press both earphones for 6 seconds to turn them off.
- 2) Long press both earphones at the same time to turn on. When turning on, press the two earphones 6 times at the same time when the lights of the two earphones are flashing alternately. After pressing 6 times, the two earphones will automatically turn off at the same time.
- 3) Turn on the two earphones at the same time, and only one of them will light up after turning on, which means the earphone pairing is successful.
- B: The middle surface of the headset is a touch surface, which is used to touch control of answer/hang up calls, control the previous and next music, volume up and down, and AI voice assistant.
- C: Answer/hang up the call
 - When the earphone is in the base of the watch and there is an incoming call, it will be automatically connected when it is taken out of the watch. When the earphone is in the watch for a long time, the incoming call needs to be answered manually. Tap the button to answer the call, then tap the button again to hang up. Put the earphones back into your watch during a call, and the earphones will return to the watch. If the caller does not hang up the call, it will automatically switch to the mobile phone to answer the call.
 - D: Play music
 - Single click is pause/play, double click is previous/next song, triple click is volume +/-.
 - E: AI voice assistant and making phone calls
 - When the earphone is connected to the Bluetooth, long press the touch key for 3 seconds to wake up the iPhone Siri function and Android voice assistant, which can be used to make phone calls, check the weather, navigate the map and other functions. The phone must be in the lock screen interface or the home screen of time to wake up the voice assistant effectively.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

5 English

XIV. Use Instructions of Watch

1. Long press the UI interface of the main screen to enter the theme selection (you can also enter through the settings-theme selection). In this mode, the user can choose the system-provided dial plate or a custom dial plate.
2. swipe down on the main screen UI interface to enter the shortcut menu:
 - About: View device information: model, version number, date of manufacture, MAC address, etc.
 - Theme selection: the user can choose the system-provided dial plate or a custom dial plate.
 - Language: language set "Auto", the watch is synchronized with the language of the mobile phone.
 - style switching: Two options for style switching. Slide the UI interface of the main screen to the left to enter the menu mode to display different styles.
3. Go to settings

XV. Troubleshooting

- 1. APP cannot be connected or some functions are unstable
 - The battery level of the watch may be too low and needs to be charged.
 - Check whether certain functions are in the corresponding watch mode. Please refer to Section 5-APP Connection - Article 3 of this Manual for details.
- 2. The battery level of the watch may be too low and needs to be charged.
- 3. Check whether the Bluetooth of the mobile phone is turned on and whether the mobile phone and the watch are properly connected.
- 4. Weather data is regularly updated by the APP in the background of the phone via the server, and then synchronized to the watch. Please confirm that the network connection is normal. The weather data provided by the server may be different from that of other platforms.
- 5. The update and upgrade of the data server may cause problems in data synchronization. Please wait patiently for the completion of the upgrade according to the announcement on the APP.

XVI. Brief Function Introduction of TWS Earphone

1. Earphone pairing:
 - Take the earphones out of the watch host and there will be a power-on prompt. Open the Bluetooth in the phone settings and find corresponding Bluetooth name T92-R/T92-L for Bluetooth connection. The TWS earphones have been paired before leaving the factory. Only the Bluetooth name T92-R/T92-L is displayed. If you see "Connected" in the phone, it means that the product has been successfully connected.
 - Take out the earphones from the watch host, it will automatically power on and automatically be paired and connected.
 - If the earphone is disconnected from the phone while in service or the earphone is disconnected, the phone needs to be reconnected to Bluetooth. In the Bluetooth under the phone settings, there are previously connected Bluetooth models, please clear them first, and then search for Bluetooth T92-R/T92-L to connect.
 - Earphone pair connection: If there is only one side earphone with sound, then you need to connect the earphones in pair. Operation method of pairing between earphones:
 - 1) First, long press both earphones for 6 seconds to turn them off.
- 2) Long press both earphones at the same time to turn on. When turning on, press the two earphones 6 times at the same time when the lights of the two earphones are flashing alternately. After pressing 6 times, the two earphones will automatically turn off at the same time.
- 3) Turn on the two earphones at the same time, and only one of them will light up after turning on, which means the earphone pairing is successful.
- B: The middle surface of the headset is a touch surface, which is used to touch control of answer/hang up calls, control the previous and next music, volume up and down, and AI voice assistant.
- C: Answer/hang up the call
 - When the earphone is in the base of the watch and there is an incoming call, it will be automatically connected when it is taken out of the watch. When the earphone is in the watch for a long time, the incoming call needs to be answered manually. Tap the button to answer the call, then tap the button again to hang up. Put the earphones back into your watch during a call, and the earphones will return to the watch. If the caller does not hang up the call, it will automatically switch to the mobile phone to answer the call.
 - D: Play music
 - Single click is pause/play, double click is previous/next song, triple click is volume +/-.
 - E: AI voice assistant and making phone calls
 - When the earphone is connected to the Bluetooth, long press the touch key for 3 seconds to wake up the iPhone Siri function and Android voice assistant, which can be used to make phone calls, check the weather, navigate the map and other functions. The phone must be in the lock screen interface or the home screen of time to wake up the voice assistant effectively.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

6 English

XVII. Use Instructions of Watch

1. Long press the UI interface of the main screen to enter the theme selection (you can also enter through the settings-theme selection). In this mode, the user can choose the system-provided dial plate or a custom dial plate.
2. swipe down on the main screen UI interface to enter the shortcut menu:
 - About: View device information: model, version number, date of manufacture, MAC address, etc.
 - Theme selection: the user can choose the system-provided dial plate or a custom dial plate.
 - Language: language set "Auto", the watch is synchronized with the language of the mobile phone.
 - style switching: Two options for style switching. Slide the UI interface of the main screen to the left to enter the menu mode to display different styles.
3. Go to settings

XVIII. Troubleshooting

- 1. APP cannot be connected or some functions are unstable
 - The battery level of the watch may be too low and needs to be charged.
 - Check whether certain functions are in the corresponding watch mode. Please refer to Section 5-APP Connection - Article 3 of this Manual for details.
- 2. The battery level of the watch may be too low and needs to be charged.
- 3. Check whether the Bluetooth of the mobile phone is turned on and whether the mobile phone and the watch are properly connected.
- 4. Weather data is regularly updated by the APP in the background of the phone via the server, and then synchronized to the watch. Please confirm that the network connection is normal. The weather data provided by the server may be different from that of other platforms.
- 5. The update and upgrade of the data server may cause problems in data synchronization. Please wait patiently for the completion of the upgrade according to the announcement on the APP.

XIX. Brief Function Introduction of TWS Earphone

1. Earphone pairing:
 - Take the earphones out of the watch host and there will be a power-on prompt. Open the Bluetooth in the phone settings and find corresponding Bluetooth name T92-R/T92-L for Bluetooth connection. The TWS earphones have been paired before leaving the factory. Only the Bluetooth name T92-R/T92-L is displayed. If you see "Connected" in the phone, it means that the product has been successfully connected.
 - Take out the earphones from the watch host, it will automatically power on and automatically be paired and connected.
 - If the earphone is disconnected from the phone while in service or the earphone is disconnected, the phone needs to be reconnected to Bluetooth. In the Bluetooth under the phone settings, there are previously connected Bluetooth models, please clear them first, and then search for Bluetooth T92-R/T92-L to connect.
 - Earphone pair connection: If there is only one side earphone with sound, then you need to connect the earphones in pair. Operation method of pairing between earphones:
 - 1) First, long press both earphones for 6 seconds to turn them off.
- 2) Long press both earphones at the same time to turn on. When turning on, press the two earphones 6 times at the same time when the lights of the two earphones are flashing alternately. After pressing 6 times, the two earphones will automatically turn off at the same time.
- 3) Turn on the two earphones at the same time, and only one of them will light up after turning on, which means the earphone pairing is successful.
- B: The middle surface of the headset is a touch surface, which is used to touch control of answer/hang up calls, control the previous and next music, volume up and down, and AI voice assistant.
- C: Answer/hang up the call
 - When the earphone is in the base of the watch and there is an incoming call, it will be automatically connected when it is taken out of the watch. When the earphone is in the watch for a long time, the incoming call needs to be answered manually. Tap the button to answer the call, then tap the button again to hang up. Put the earphones back into your watch during a call, and the earphones will return to the watch. If the caller does not hang up the call, it will automatically switch to the mobile phone to answer the call.
 - D: Play music
 - Single click is pause/play, double click is previous/next song, triple click is volume +/-.
 - E: AI voice assistant and making phone calls
 - When the earphone is connected to the Bluetooth, long press the touch key for 3 seconds to wake up the iPhone Siri function and Android voice assistant, which can be used to make phone calls, check the weather, navigate the map and other functions. The phone must be in the lock screen interface or the home screen of time to wake up the voice assistant effectively.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

Warnings

1. The measurement results of this product are for reference only, not for any medical purposes and basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is life waterproof, and it cannot be used for deep diving and long time immersion in water. In addition, this product does not protect against hot water, because the water vapor will affect the watch.
3. The company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version, which is normal.
4. Please use Restore Factory Defaults carefully. Restore Factory Defaults will result in the loss of APP content settings and watch history data.

7 English

XVIII. Use Instructions of Watch

1. Long press the UI interface of the main screen to enter the theme selection (you can also enter through the settings-theme selection). In this mode, the user can choose the system-provided dial plate or a custom dial plate.
2. swipe down on the main screen UI interface to enter the shortcut menu:
 - About: View device information: model, version number, date of manufacture, MAC address, etc.
 - Theme selection: the user can choose the system-provided dial plate or a custom dial plate.
 - Language: language set "Auto", the watch is synchronized with the language of the mobile phone.
 - style switching: Two options for style switching. Slide the UI interface of the main screen to the left to enter the menu mode to display different styles.
3. Go to settings

XIX. Troubleshooting

- 1. APP cannot be connected or some functions are unstable
 - The battery level of the watch may be too low and needs to be charged.
 - Check whether certain functions are in the corresponding watch mode. Please refer to Section 5-APP Connection - Article 3 of this Manual for details.
- 2. The battery level of the watch may be too low and needs to be charged.
- 3. Check whether the Bluetooth of the mobile phone is turned on and whether the mobile phone and the watch are properly connected.
- 4. Weather data is regularly updated by the APP in the background of the phone via the server, and then synchronized to the watch. Please confirm that the network connection is normal. The weather data provided by the server may be different from that of other platforms.
- 5. The update and upgrade of the data server may cause problems in data synchronization. Please wait patiently for the completion of the upgrade according to the announcement on the APP.

XX. Brief Function Introduction of TWS Earphone

1. Earphone pairing:
 - Take the earphones out of the watch host and there will be a power-on prompt. Open the Bluetooth in the phone settings and find corresponding Bluetooth name T92-R/T92-L for Bluetooth connection. The TWS earphones have been paired before leaving the factory. Only the Bluetooth name T92-R/T92-L is displayed. If you see "Connected" in the phone, it means that the product has been successfully connected.
 - Take out the earphones from the watch host, it will automatically power on and automatically be paired and connected.
 - If the earphone is disconnected from the phone while in service or the earphone is disconnected, the phone needs to be reconnected to Bluetooth. In the Bluetooth under the phone settings, there are previously connected Bluetooth models, please clear them first, and then search for Bluetooth T92-R/T92-L to connect.
 - Earphone pair connection: If there is only one side earphone with sound, then you need to connect the earphones in pair. Operation method of pairing between earphones:
 - 1) First, long press both earphones for 6 seconds to turn them off.
- 2) Long press both earphones at the same time to turn on. When turning on, press the two earphones 6 times at the same time when the lights of the two earphones are flashing alternately. After pressing 6 times, the two earphones will automatically turn off at the same time.
- 3) Turn on the two earphones at the same time, and only one of them will light up after turning on, which means the earphone pairing is successful.
- B: The middle surface of the headset is a touch surface, which is used to touch control of answer/hang up calls, control the previous and next music, volume up and down, and AI voice assistant.
- C: Answer/hang up the call
 - When the earphone is in the base of the watch and there is an incoming call, it will be automatically connected when it is taken out of the watch. When the earphone is in the watch for a long time, the incoming call needs to be answered manually. Tap the button to answer the call, then tap the button again to hang up. Put the earphones back into your watch during a call, and the earphones will return to the watch. If the caller does not hang up the call, it will automatically switch to the mobile phone to answer the call.
 - D: Play music
 - Single click is pause/play, double click is previous/next song, triple click is volume +/-.
 - E:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction