




LEQISMART




ELECTRIC SCOOTER A6 Pro
USER MANUAL
English

Package Contents



User Manual




Power Adapter




T-shape Allen Key



Screw



Function



Function mode
Speedometer
Gear mode
Battery level

Function mode: Cruise mode, Pedestrian mode, Fault prompt, Light, Bluetooth, Lock.
Speedometer: Displays the current speed; displays the remaining mileage within 6 seconds after power-on.
Gear mode: The maximum speed limit is 6 km/h for L gears, 15 km/h for M gears and 25 km/h for H gears.
Battery level: Displays the remaining battery power; it displays in red and flashing when the power is about 10%.
Switch button: Press it to turn on, press and hold for 3 seconds to shut down; in power-on state, press once to turn on/off the light, and press twice consecutively to switch gears; in power-off state.