

FIDGET SPINNER

WITH LED LIGHTING AND WIRELESS SPEAKER


Introductions

This manual will help you operate the wireless speaker function of your spinner. You should first familiarize yourself with the wireless functionality of your cell phone or other devices before using the spinner.

Safety rules

1. Please follow the rules depicted in this manual closely to ensure your safety. Before using your spinner, we would strongly encourage you to read through this user manual.
2. Be aware of any edges, uneven surfaces, metal parts, accessories and its packing so as to prevent any possible injury or damage.
3. Do not modify, repair or dismantle your spinner. Doing so may result in fires, electric shocks, complete break down of this spinner etc.
4. Do not use the spinner in a hazardous location.

Diagram



FRONT SIDE

Pairing to cell phone or other device

To use the wireless function of your spinner, you must first pair your spinner with a cell phone, tablet or computer. Once your spinner is paired to a specific device, it remains paired and automatically recognizes each other whenever they are within range.

Pairing to a phone and entertainment

- Turn on your phone and ensure its wireless function is activated.
- Turn on your spinner and go to the pairing mode.
- Search your wireless devices on your device by following the device's user manual for more information.
- After a few seconds the device will list the "G460" as a discoverable device.
- Select it and follow your device's instruction to select this pairing.
- Your device will confirm the pairing, and then press Yes/OK.
- Finally, select to connect with the spinner from your device.

Charge your Spinner

Connect the spinner to USB Charger with the included cable. The red color LED indicator is on when charging. The LED indicator turns off when fully charged. Make sure that your spinner is charged for at least 1 hour before initial use.

Warning

You must select a qualified charger from a regular manufacturer. You must charge the spinner if it has been not used for more than 1 month.

Product specification

Input	5V / 0.1A
Output	1W
Wireless Version	V5.0
Wireless Range	30 Feet
Connection Frequency	2.40GHz-2.48GHz
Battery Capacity	50mAh

Made in China

BACK SIDE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure conditions without restriction