

TRIOS 6

Label placement

Labels are placed in the inner part of the shell at the battery inlet side

