




802.11g CHANNEL 10, Carrier level




802.11g CHANNEL 10, Reference level




802.11g CHANNEL 11, Carrier level




802.11g CHANNEL 11, Reference level




802.11n-20 MHz CHANNE 1, Carrier level




802.11n-20 MHz CHANNEL 1, Reference level




802.11n-20 MHz CHANNEL 2, Carrier level




802.11n-20 MHz CHANNEL 2, Reference level




802.11n-20 MHz CHANNEL 10, Carrier level




802.11n-20 MHz CHANNEL 10, Reference level




802.11n-20 MHz CHANNEL 11, Carrier level




802.11n-20 MHz CHANNEL 11, Reference level




802.11n-40 MHz CHANNEL 3, Carrier level




802.11n-40 MHz CHANNEL 3, Reference level




802.11n-40 MHz CHANNEL 4, Carrier level




802.11n-40 MHz CHANNEL 4, Reference level




802.11n-40 MHz CHANNEL 5, Carrier level




802.11n-40 MHz CHANNEL 5, Reference level




802.11n-40 MHz CHANNEL 7, Carrier level




802.11n-40 MHz CHANNEL 7, Reference level




802.11n-40 MHz CHANNEL 8, Carrier level




802.11n-40 MHz CHANNEL 8, Reference level



802.11n-40 MHz CHANNEL 9, Carrier level




802.11n-40 MHz CHANNEL 9, Reference level




MIMO-Main Antenna


802.11b CHANNEL 1, Carrier level




802.11b CHANNEL 1, Reference level




802.11b CHANNEL 11, Carrier level




802.11b CHANNEL 11, Reference level




802.11g CHANNEL 1, Carrier level




802.11g CHANNEL 1, Reference level




802.11g CHANNEL 2, Carrier level




802.11g CHANNEL 2, Reference level




802.11g CHANNEL 10, Carrier level




802.11g CHANNEL 10, Reference level




802.11g CHANNEL 11, Carrier level




802.11g CHANNEL 11, Reference level




802.11n-20 MHz CHANNE 1, Carrier level




802.11n-20 MHz CHANNEL 1, Reference level




802.11n-20 MHz CHANNE 2, Carrier level




802.11n-20 MHz CHANNEL 2, Reference level




802.11n-20 MHz CHANNE 10, Carrier level




802.11n-20 MHz CHANNEL 10, Reference level




802.11n-20 MHz CHANNEL 11, Carrier level




802.11n-20 MHz CHANNEL 11, Reference level




802.11n-40 MHz CHANNEL 3, Carrier level



802.11n-40 MHz CHANNEL 3, Reference level



802.11n-40 MHz CHANNEL 4, Carrier level



802.11n-40 MHz CHANNEL 4, Reference level

