

Remote control manual

Basic Operations

1. Power Control

- Press the power button to turn the TV on/off.

2. Input source selection

- Press INPUT to switch between HDMI/AV/PC modes.

3. Channel Adjustment

- CH+/CH-: Navigate channels sequentially.
- Number keys: directly enter the channel number.
- PAGE UP/PAGE DOWN: Skips channels by groups (for example, by 10).

4. Volume Management

- VOL+/VOL-: Adjust the volume.
- Mute: Mutes the sound immediately (press again to restore).

Advanced features

5. Device pairing (universal remote)

- Press and hold Back + Home until the indicator light flashes twice → Press a device button (e.g. TV) → Press and hold OK until the indicator light turns off

6. Menu Navigation

- Menu: Access Settings → Use arrow keys (▲▼◀▶) + OK to select/confirm.
- Back/Exit: Return to the previous screen or to live TV .

7. Special Features

- NETFLIX : Open the NETFLIX shortcut
- YouTube : Open YouTube shortcut
- Prime video : Open YouTube shortcut
- Music: Open YouTube Music shortcut
- Live TV: Open Live TV shortcut

Language settings

Switch language mode :

Press the Settings button → Select System/Settings → Select Language → Change to Simplified Chinese or Chinese

Maintenance Tips

- when the response decreases (usually 5-6 months).
- Avoid contact with liquids and extreme temperatures.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.