

Warranty print data
Size:W297mm H420mm
Color:1C print K
80g/ m² White paper Duplex print

Front side



Safety Precautions/Warranty

Thank you very much for purchasing FlipVR. Please be sure to read this "Safety Precautions/Warranty", before using your new FlipVR. Also, please carefully read the online manual and use the product safely and correctly.
Please keep this document for future reference.


Please read the online manual before use.



Online manual
<https://manual.shiftall.net/en/flipvr/>




Items included.



FlipVR controller unit: 2 pcs



Safety Precautions/Warranty: 1 pc



Hook-and-loop fastener: 2 pairs

Back side



安全上のご注意 / 保証書

このたびは、FlipVR をお買い上げいただき、まことにありがとうございます。
ご使用前に本書「安全上のご注意 / 保証書」を必ずお読みください。
また、オンラインマニュアルをよくお読みのうえ、正しく安全にお使いください。本書は大切に保管してください。


ご使用前にオンラインマニュアルを必ずお読みください。



オンラインマニュアルはこちら
<https://manual.shiftall.net/flipvr/>




内容物の確認



FlipVR 本体 (左右各 1 個)



安全上のご注意 / 保証書 (本書)



面ファスナー (2 セット)

Safety Precautions To reduce the risk of death, injury and accidents, please read carefully and follow all instructions included those in these instruction and online at <https://manual.shiftall.net/en/flipvr/>.

Danger The following have a high risk of death or serious injury.

- Use FlipVR for only its intended purpose. Doing otherwise may result in damage to the equipment, accidents, death or serious injury.
- Be sure to provide sufficient play space when using the product. Using the product with objects around it may cause damage to the equipment, accidents, or injury.
- Exposing the product to water may result in electrical shock. Do not use in the kitchen, laundry room, bathroom or any place where there is the presence of water. Electrical shock can result in serious injury or death.
- Charge the product as specified in the online manual to avoid battery leakage, overheating, or rupture. Not doing so may result in fire or explosions and death or serious injury.

Warning The following have a risk of death or serious injury.

- Do not disassemble or modify the product. Modifications, including placing metal objects inside the product, may result in malfunction, burns, fire, death or serious injury.
- Radio waves emitted by the product may affect the operation of cardiac pacemakers. Please keep the product at least 6 inches away from any pacemaker.
- Do not use the product near automatic control devices such as automatic doors or fire alarms. Radio waves emitted by the product may affect automatic control devices causing accidents due to malfunctions.
- Do not use in hospitals or places where electrical medical equipment are in use. Radio waves emitted by the product may affect electrical equipment causing accidents due to malfunctions.
- Do not allow foreign objects, including water and other liquids, to enter the unit. A short circuit or overheating may cause a fire, electrical shock, or malfunction. Be especially careful with children.
- In the event of the following abnormalities or malfunctions immediately unplug the USB cable and discontinue use. If you continue to use the product it may cause a fire or electric shock. If there are any problems with the product contact the Shiftall support desk.
Beware of:
 - ・ Smoke, unusual smell or sounds.
 - ・ Water or foreign matter inside the product.
 - ・ Damage to the main unit.
- If you experience any unusual physical symptoms such as breathlessness, dizziness, headache, or nausea during use, discontinue use immediately and seek medical attention.

Caution The following may result in minor injuries or property damage.

- Do not use or store the product in any place with high humidity, steam, oil smoke, dust or vibrations. Doing so may cause fires or electrical shock.
- Do not place heavy objects on top of the product. The objects may fall and cause injuries. It may also deform the outer case or the plug of the cord and damage the internal parts, resulting in fires or malfunctions.
- Do not leave the product in places of high temperatures. Do not leave inside car's, especially in hot weather. Doing so may result in fires. Undue heat may also cause deterioration of the outer case and internal parts.
- Do not use the product while sleeping. Doing so may cause damage to the product, accidents, or injuries.
- Do not continue to charge the battery if it will not be used for a long time. Failure to do so may result in fire.
- Do not place the product near infants or children. It may cause accidental ingestion of parts, other unexpected accidents, or injuries.
- Do not use the product with the USB cable wrapped around your body.
- If you feel any abnormality on your skin through direct contact with the product, stop using immediately. Continued usage of the product may cause irritation or rashes.
- Use the fitting method described in the online manual for installation.
- Be sure to use the product in the correct fitting condition for comfort and safety, and check the fit periodically during use.
- Do not over-tighten the straps.
- When using the product, be sure to attach and fix the hand and wrist straps. Failure to do so may cause unexpected accidents, injury or damage to the equipment.
- Do not allow fingers or clothing to touch hinges when you move the moving parts of the product. Failure to do so may result in malfunction, damage to clothing or injury.
- Do not make aggressive movements when not holding the control part of the product. Doing so may cause an unexpected accident or injury.
- Do not pull hard on the cord part of the product or swing it around by holding it. Doing so may cause unexpected accidents, injury or damage to the equipment.
- Do not strongly twist or pull the shaft part of the control part of the product. Doing so may cause damage to the equipment.

Disclaimer and Regulatory Information
Use and storage location
Do not leave the product in direct sunlight or places exposed to high-temperatures.
Do not drop, hit, or otherwise subject the product to strong shocks. Doing so may cause a malfunction.
If the product will not be used for a long period of time, recharge the battery approximately every 3 months.

Care and Maintenance
Wipe the unit with a soft, dry cloth. If the unit is very dirty, first wipe off the dirt with a slightly damp cloth, then wipe with a dry cloth.
Do not allow contact with solvents such as paint thinner, alcohol, benzene, kitchen, or cloth detergent. Exposure to chemicals may change the quality of the unit or cause the paint to peel off.

Disclaimers
For use in Japan, and the United States only.

Disposal
Dispose of the product according to local environmental regulations. Do not dispose of it along with normal household waste.

Shiftall Product Warranty Policy
The product warranty for FlipVR (hereafter referred to as "the product") is valid only under the conditions described in this document. Shiftall Corporation (hereinafter referred to as "Shiftall") guarantees the product to be free from defects in design and workmanship under the conditions of use as specified in the online manual for one year (hereinafter referred to as the "Warranty Period") from the date of purchase by the original purchaser from the dealer.
Not covered by warranty
This warranty is not valid under any of the following circumstances:
(1) If you do not present this warranty card upon purchase of the product.
(2) If your name and address are not written on this warranty card.
(3) If there is no date of purchase or the store name is not written on this warranty card.
(Not applicable if you provide a receipt or other proof of the date and the store of purchase.)
(4) Any part of this warranty card has been altered.
(5) If the product has been disassembled or altered.
This warranty does not apply to damage, failure, or malfunction caused by:
(I) Transportation, handling, or dropping after purchase.
(II) Accident, misuse, contact with liquid, chemicals, fire, earthquake, or other external causes.
(III) Connection with other equipment or compatibility problems.
(IV) Wear on or damage to consumable parts.
(V) Use or storage of the product that is not specified, permitted, or intended.
(VI) Servicing (including, but not limited to, repair or modification) other than by Shiftall-authorized technicians.
(VII) Update of SteamVR™, Windows, or supported software makes the product unusable.
Our response
This warranty does not guarantee that the use of the product will be uninterrupted or error-free.

If a defect arises and a valid claim is made against Shiftall during the warranty period, Shiftall will in its sole discretion and to the fullest extent permitted by law.
(a) Repair the product free of charge using new parts or parts that are equivalent to new in performance and reliability.
(b) Replace the product with a new or refurbished product that is equivalent to a new one in performance and reliability.
(c) Refund the cost of the product.
The remaining term of this warranty shall not be extended if the product or part is replaced or repaired under this warranty. If a product or part is replaced, the new product or part shall become your property, and the product or part that was replaced or repaired shall become the property of Shiftall. In the event of a refund the product to be refunded shall be returned to Shiftall.

TO THE MAXIMUM EXTENT PERMITTED BY (APPLICABLE) LAW, THIS WARRANTY IS THE SOLE EXPRESS WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, REMEDIES, AND CONDITIONS, WHETHER ORAL OR WRITTEN, STATUTORY OR IMPLIED, IF PERMITTED BY THE LAWS OF THE COUNTRY OR STATE OF SALE. SHIFTALL MAKES NO STATUTORY OR IMPLIED WARRANTIES OF ANY KIND, IF PERMITTED BY THE LAWS OF THE COUNTRY OR STATE OF SALE. SHIFTALL DISCLAIMS ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT FOR HIDDEN OR LATENT DEFECTS.

Scope of responsibility
The remedies available to the consumer are limited to those remedies expressly provided in this warranty. Except as permitted by this warranty, to the maximum extent permitted by (applicable) law, we shall not be liable for any direct, special, indirect, or consequential damages under any legal theory arising out of a breach of warranty or condition.
How to file a warranty claim
To obtain service under this warranty, please contact us using the URL below. Please note that we do not offer support via phone or fax.
Contact from here: <https://en.shiftall.net/support/>

Model	SVP-VC1B
Your Name	
Your Address	
Purchase date	
Store name	

FCC CAUTION
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

安全上のご注意 必ずお守りください

危険 死亡や重傷を負うおそれ大きい内容です

- 水のかかるおそれのある場所で、本製品を使ったり、充電したりしないでください。台所、洗濯場などで利用すると感電の原因になります。

- 本来の目的以外の用途には使用しないでください。破損、事故、けがの原因になります。
- 本製品をご使用になる際は、必ず十分なプレイスペースを確保してください。周囲に物があつてご使用すると、破損、事故、けがの原因になります。
- 本製品は充電式電池を内蔵しています。必ずオンラインマニュアルで指定された方法で充電してください。指定方法以外での充電や火中投下、加熱、高温での充電、電子レンジやオーブなどで加熱しないでください。発熱、発火、破壊の原因となります。

警告 死亡や重傷を負うおそれがある内容です

- 分解、改造しないでください。火災や感電、やけど、故障の原因となります。
- 心臓ペースメーカーを装着している方は装着部から15cm 程度以上離してください。本製品からの電波がペースメーカーの作動に影響を与える場合があります。
- 自動ドア、火災警報器などの自動制御機器の近くで使用しないでください。本製品からの電波が自動制御機器に影響を及ぼすことがあり、誤作動による事故の原因となります。
- 病院内や医療用電気機器のある場所では使用しないでください。本製品からの電波が医療用電気機器に影響を及ぼすことがあり、誤動作による事故の原因になります。
- 内部に異物をいたり、水などの液体をかたまり溜めたりしないでください。ショートや発熱により、火災・感電・故障の原因になります。また、機器の近くに水などの液体の入った容器や金属物を置かないでください。特にお子様にはご注意ください。

- 次のような異常、故障時は直ちに使用を中止してください。そのまま使うと火災・感電の原因となります。本製品に異常があるときは、Shiftall サポート窓口までご連絡ください。
 - ・ 煙が出たり、異常な臭いや音する。
 - ・ 内部に水や異物が入った。
 - ・ 充電が途中で止まったり、充電しきれない。
- 次のような症状を感じたときはすぐに使用を中止してください。使用を中止しても治らないときは医師の診察を受けてください。
 - ・ 視、目、耳、鼻、口、舌、喉、皮膚などに異常を感じたり、めまい、吐き気など乗り物酔い似た症状を感じる。
- 寝ているときや睡眠不足のとき、または、不安定な場所で VR ヘッドセットをお使いになると症状がひどくなります。また、外装ケースや内部部品が劣化する原因にもなりますので、ご注意ください。

注意 軽傷を負うことや、財産の損害が発生するおそれがある内容です

- 湿気、湯気、油煙、ほこりの多い場所や振動するところでは使用したり、保管しないでください。火災や感電の原因となります。
- 本製品のの上に重い物を載せたり、垂ったりしないでください。落下すると、けがの原因になることがあります。また、重量や外装ケースやヒンジ部分が変形し、内部部品が破損すると、火災・故障の原因になることがあります。
- 暑さに温度が高くなるところに置かないでください。特に真夏の車内、車のトランクの中は、特に注意が必要です。高温に長時間さらされると、発熱の原因になります。また、外装ケースや内部部品が劣化する原因にもなりますので、ご注意ください。

- 本製品を睡眠時に使用しないでください。破損、事故、けがの原因になります。
- 長時間使用しないときは充電を止めてください。火災の原因になることがあります。
- 本製品を乳幼児や子供の手が届く場所に置かないでください。思わぬ事故、けがの原因になります。
- USB ケーブルが体に巻き付いた状態で使用しないでください。
- 顔など本製品が直接触れる部分に異常を感じたら使用を中止してください。そのまま使用すると、炎症やかぶれなどの原因になることがあります。
- オンラインマニュアル記載の装着方法を参照し、正しく装着してください。
- 快適で安全にご使用いただくために正しい装着状態で使用し、使用中も定期的に装着感を確かめてください。
- ストラップを締め付けすぎないようにしてください。
- 本製品を使用するときは必ずハンドストラップおよびリストストラップを装着し、手を振っても本製品が振り落ちないことを確認して使用してください。思わぬ事故、けが、機器の破損の原因になります。
- 本製品の可動部分を動かす際は、ヒンジ部分に指で触れたり衣服が触れないようにしてください。故障の原因になります。
- 本製品の操作部分を握っていない時に激しい動きをしないでください。思わぬ事故、けがの原因になります。
- 本製品のコード部分を強く引っ張ったり、持って振り回したりしないでください。思わぬ事故、けが、機器の破損の原因になります。
- 本製品の操作部の軸部分を強くねじったり、引っ張ったりしないでください。破損の原因になります。

使用上のお願
使用、保管場所について
直射日光が当たる場所や暖房器具の近くなど温度が非常に高い場所に置かないでください。落し、こぼし、ぶついたりなど強いショックを受けると、故障の原因になります。また、本製品を長期間使用しない場合は、3 ヶ月を目安に充電してください。

お手入れについて
本製品は乾いた柔らかい布でふいてください。
本製品の汚れがひどいときは水に浸した布をよく絞ってから汚れをふき取り、そのあと乾いた布でふいてください。
※ 本製品は、アルコール、台所洗剤などの薬剤または科学雑巾は、本製品が変質したり、塗装がはげるおそれがありますので使用しないでください。

使用制限
日本国内およびアメリカ合衆国でのみ使用できます。

廃棄について
廃棄に関しては、一般ゴミ（不燃ゴミ）と一緒に廃棄せず、お住まいの市区町村の条例に従ってください。

FlipVR (以下、本製品) についての製品保証 (以下、本保証) は、本書に記載する条件においてのみ有効といたします。株式会社 Shiftall (以下、弊社) は、以下に定める通り本製品についてオンラインマニュアルに示す使用方法に基づき使用する状況において、設計および製造上の瑕疵がないことを、最初の購入者が販売店または Shiftall にて購入した日から 1 年間 (以下、保証期間) 保証します。

保証対象外
本保証は、以下のいかなる場合においても有効ではありません：
(1) 本保証書をご提示いただけない場合
(2) 本保証書にお名前・ご住所のご記入がない場合
(3) ご購入日・ご購入店印がない場合 (但し、ご購入日・ご購入店を証明できる領収書等を提示いただける場合は除きます)
(4) 本保証書の字句・印影の一部が改ざんされている場合
(5) 本製品を分解された場合
本保証は以下のいかなる原因による損害・故障・動作不具合においても有効ではありません：
(I) ご購入後の輸送、移動、落下による場合
(II) 事故、誤使用、液体又は異物との接触、火事、地震または他の外的原因による場合
(III) 他の機器との接続、または相性問題による場合
(IV) 弊社が消耗品と定めた部品による場合
(V) 弊社が定め、許可し、意図した使用・保管方法ではない場合
(VI) 弊社以外の者によるサービス (修理・改造等を含むがこれに限らない) による場合
(VII) SteamVR™やWindows、対応ソフトの更新によって本製品が使用できなくなった場合
弊社は、本製品の使用が中断されず、またはエラーなく動作することを保証いたしません。

弊社の対応
万一、本製品に瑕疵があり、かつ有効な請求が保証期間内に弊社にされた場合、弊社は法律が認める限り弊社の自由裁量において以下のいずれかの対応をいたします。
(a) 新品の部品、または性能・信頼性において新品同等の部品を使用し無償修理いたします
(b) 新品または性能および信頼性において新品と同等の再生製品と交換いたします
(c) 本製品の代金を返金いたします
本保証の残存期間は、本保証を用いて製品または部品の交換・修理等が実施された場合であっても延長されないものといたします。製品または部品が交換された場合、新しい製品または部品をお客様の所有物とし、交換・修理の対象となった製品または部品は弊社の所有物といたします。製品代金が返金される場合、返金対象となる本製品は、弊社に返却されるものといたします。
法によって最大限認められる範囲内において、本保証は唯一の明示的な保証であり、口頭・書面のいずれにおいても、法定であるか黙示であるかを問わず、その他の保証・救済・条件について代わるものです。販売国の法律によって認められる場合、弊社は、一切の制定法上の、または黙示の保証をしないものとし、またこれは商品使用や、特定の目的への適合性、隠れたあるいは潜在的な瑕疵に対する黙示の保証をしないことを含むものですが、これに限るものではありません。

責任の範囲
本保証で認められることを除き、法によって最大限認められる範囲内において、弊社は保証もしくは条件違反から生じるいかなる法的理論に基づく直接・特別・間接・結果的損害に責任を負わないものといたします。

保証請求の方法
本保証を用いてサービスを受けるには、下記 URL よりお問い合わせください。お電話・FAX 等でのご連絡方法はございません。

お問い合わせはこちらから：<https://ja.shiftall.net/support/>

製品型番	SVP-VC1B
お名前	
ご住所	
ご購入日	
ご購入店印	