



Sing-along PRO

SA2

Microphone

1. Turn on the power. The light on the display will turn on. You can turn the device on or off by touching the power button.
2. How to use the microphone:
 - When the battery voltage is low, the product will automatically shut down.
 - When the LED display shows the correct standard Micro USB port to your microphone and the light on the microphone LED indicator light will turn on to show that the device is charging.
 - Typical charge time is approximately two hours, when charge is completed the red light will turn off.
 - Standard continuous use time from a full charge is 4-6 hours.
3. How to use the microphone:
 - Press the microphone icon to start music.
 - Press the phone icon or microphone volume icon to turn back your volume settings.

WE-SAZ-ROSE Gold

WE-SAZ-ROSE

Guidelines for use

[illegible][illegible][illegible][illegible][illegible][illegible][illegible][illegible][illegible]

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.