

# YUEYINPU

## Wireless Pedal USER MANUAL

### 1. Product description

Thank you for purchasing our wireless pedal. This product can be used on Android, Windows, iOS system by fixed button to achieve wireless&silently switching page by stepping on the pedal. By this way, you can play music without using your hands to switch pages of sheet music. Hope this product can bring you convenience and happiness.

### 2. Five control models and one circular button

Mode	Pedal Left	Pedal Right
1. Up Dn	Page Up	Page Down
2. ←→	Left Arrow	Right Arrow
3. ↑↓	Up Arrow	Down Arrow
4. ⌂	Left Mouse Click	Right Mouse Click
5. ←→	Space	Enter

Note: due to the fact that different apps response to different control models, so you need to find out what control model your app can response when first used.

### 3. POWER and REPEAT switches


- Switch "POWER" to "ON" to turn on the pedal is ready to connect with your device.

- Switch "POWER" to "OFF" to turn off.
- When the "REPEAT" is on, long press the pedal and the pages will keep switching.
- When the "REPEAT" is off, step on the pedal once to switch one page, no matter long press or short press.

### 4. Power indicator light

When the power of the pedal lower than 20%, the middle power light will flash red after the pedal connected successfully with the device.

### 5. How to connect



### 6. Indicator light introduction

Status	Indicator
Connecting	R_G_B twinkle alternately
Connected	Mode light will be on
Disconnected	Mode light will be off

### 7. Dormant time and way to wake up

- (1). The state of without successful connecting (means after you turn on the power

button, but can not connected successfully), without working for 3 minutes, then it turns into the state of dormant.

- (2). Only need to step on anyone of the pedals to wake up the pedal again.

### 8. iOS connection tip

When to connect with iOS system, the virtual keyboard of the original iOS system will be locked. At that time, only need to press on the left and right pedals at the same time, then it can be unlocked, and release the iOS virtual keyboard.

### 9. Charging

- (1). When charging, the middle indicator light will be on (red) all the time, and turn yellow-green after full-charged.

- (2). You can choose your own USB plug with the cable we provide to charge the pedal. It usually takes about 3 hours to full charge.

### 10. Specification

Item model	K24-01
Power	5V / 2402-2480 MHz
Distance	10m / 33ft
Warranty time	6 months

Made in China

#### FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.