



品名: SoundAce S6
材質: 銅版紙128g
尺寸: 316*156mm

SKYWING  User Manual IPX7 Portable Waterproof Speaker Soundace S6 Thank you for choosing SKYWING product. Please read this manual to enhance your user experience. We hope you will enjoy it very much!	Product Features: 1.The SKYWING Soundace S6 portable waterproof speaker is a sturdy and compact speaker that can be used indoors or outdoors, which will easily fit your bag or backpack. Depending on your phone's Bluetooth version, your phone can display the speaker's battery life. 2.Certified IPX7 - 100% Waterproof: The SKYWING Soundace S6 portable waterproof speaker is great around water as it's not just water resistant, it can be fully immersed in water up to 3 feet. You can enjoy your shower, have fun with your friends by the pool or on a boat. 3.The SKYWING Soundace S6 Portable Waterproof Bluetooth Speaker brings a fast and stable connection. When fully charged it will provide you up to 10hrs of play time. The pairing process is easy and the speaker is compatible with all Bluetooth devices. 4.Automatic shutdown function: The speaker will shut down when Bluetooth is disconnected for 10 minutes, which is helpful to save power when the unit is accidentally left on.And the LED light show design colors your music time. Technical Data: The Pairing Name:SKYWING Soundace S6 Battery Capacity: 2000mAh Charging Input: 5V / 1A Charging Time: 2-3 hours Operating Range: 10m/33ft Charge: Micro USB Output Power: 4025W Frequency Response: 100Hz-190kHz Signal Noise Ratio: ≥85dB Distortion Degree: <1% Unit Weight: 201g Unit Size: 110*110*48mm What's included: · SKYWING Soundace S6 · USB Charging cable · User Manual · Carabiner Clip · Lanyard · Feedback Card · Warranty Card	FAQ: 1.How do you charge the speaker? Please use your phone charger or USB port on your computer/laptop. 2.What if the unit doesn't charge and the LED is off? Please check your USB and cable connections to make sure they are working properly. 3.Why won't the unit connect/pair? Delete the pairing record(s) on your device ,restart the device and reset the speaker. 4.Why is there a delay or corrupted audio? In some rare cases, your phone's Bluetooth version may be out of date or some phone apps have poor compatibility with Bluetooth, resulting in playback issues. We may be able to provide an update file to resolve this. 5.How to pair 2 speakers together? First use of TWS function, please follow the steps below: 1) Turn on both of the speakers,please do not turn on your Bluetooth-enabled device's Bluetooth function at this time) double press the "  " button of one speaker; you will hear a chime, and one of the speaker's flashing light LED indicator is stable while another's is flashing, which means the 2 speakers pairing completes 2)Then connect to your phone.Two speakers will connect automatically as TWS. - If you want to use TWS function again, please turn on the both speakers directly ,no need to repeat above steps. - In TWS mode: No matter which one of the speakers can control to play or pause the music, double press the "  " will cut off the connection between them.	Warranty: You can feel confident using our SKYWING brand speaker. We offer a 3-Year warranty for quality-related issues, and Lifetime technical support. Notice: As Amazon separates customer orders and product reviews, we can not find your order ID and email address depend on product reviews. If you have any questions, please contact us directly via the email below, we hope that our after-sales service can make you satisfied.  support@skywingtek.com us: skywing.us@skywingtek.com eu: skywing.eu@skywingtek.com jp: skywing.jp@skywingtek.com  www.skywingtek.com  *please note that unauthorized reselling of SKYWING products is prohibited.
Product Model : 	Compatible Devices: Phone, Android Phone, Tablets, Computers, Laptops, Mac Book, Echo Dot, Kindle, MP3 Players, PSP, TV, and more. *  "Button: 1.How to Turn on/off the speaker: Long Press and hold for 3 seconds to turn the speaker on or off. 2.Flash Light Mode: When there is music, it automatically switches to solid color light mode. Shore Press "  " button to switch light mode:solid white color light mode- flash color light mode - turn off the light- turn on the light-solid color light mode. *  "Button: 1.During play music ,short press once : play music /pause music 2.When there is a phone call coming in,short press once: answer the call ,when the call is finished,short press once to hang up; short press twice: reject a call. 3.Double press quickly:redial the last call in Bluetooth mode 4.Hold this button/Voice Assistant is awakened, you can let voice assistant,like "Siri" to control the the speaker's volume up or down,next song or previous song-call somebody. LED Charging Indicator/Light Mode: 1)The LED light is solid red when charging,it will be off when the battery is full. 2)LED Flashes when the speaker is waiting for connection, and turns solid color after the Bluetooth connected successfully 3)There are general two led light effects,solid color light and flash color light, short press the led button to change the led light effect, if no need any led light, just short press the led button to turn off the led light.	How to Pair with Your Device: Turn on the speaker and it will automatically enter Bluetooth mode. On your device, under Bluetooth, look for "SKYWING Soundace S6." (For devices with Bluetooth versions under 2.1, press "Yes" to confirm pairing.) Enter a password or PIN code "0000" (four zeros), then press "Yes" or "OK" to finish pairing. Phone/Tablet: Turn on the speaker—Open the Phone/Tablet Settings—Bluetooth—On—Searching/Scanning—SKYWING Soundace S6—Paired/Connected—Play music. Computer/Laptop: Turn on the speaker—Open the Laptop Settings—Devices—Bluetooth and other devices—Turn on the Bluetooth—Add Bluetooth or other devices—Bluetooth—Searching device—SKYWING Soundace S6—Paired/Connected—Play music. Notice: If the computer does not have Bluetooth, please insert the Bluetooth adapter and download the Bluetooth driver to use it normally. Mac Book: Turn on the speaker—Open the Mac Book System Preferences—Bluetooth—turn Bluetooth on—searching device—SKYWING Soundace S6—Paired/Connected—Play music. Echo Dot: Turn on the speaker—Open Alexa APP—settings—set up a new device—Bluetooth—Pair a new device—Searching Device—SKYWING Soundace S6—Paired/Connected—Play music. Kindle: Turn on the speaker—Open Kindle Settings—Wireless—Bluetooth—Enable Bluetooth(ON)—Search for Device—SKYWING Soundace S6—Paired/Connected—Play music.	Microphone / Call: 1.When your phone is connected via Bluetooth, press the "  " button to answer a phone call. 2.To Hang up the call:After the call is over, press the "  " button to hang up. 3.To redial the last call: Double press the "  " button quickly. 4.Refuse to answer a call: When the call comes in, long press "  " button to reject a call. Notice: For higher call quality, please speak near the microphone. Tips: 1.Hometek Technology has worked across R&D and sales in the audio industry for many years. Based on consumer feedback, we designed this wireless speaker with waterproof technology. The locations are located seamlessly at the top of the unit for convenient use. 2.With the speaker located under the sun, sound is balanced via high fidelity speakers including a compact subwoofer. Sound is engineered so that it can be clear and voluminous when reflected off the surface underneath. 3.For most TWS functions, usually it has only a little bass, it focuses on treble and clarity. For Dual stereo speaker, it has big bass, it combines bass and stereo sound. 4.Our consumers let us know they love our speaker because the sound is clearer and louder compared to other brands on the market. Consumers also report better overall sound quality, the longest battery life, and they love our user technology! 5.As a reliable manufacturer, we listen to and directly incorporate this consumer feedback into our product development to constantly improve and meet the needs of our consumers.
5	6	7	8

DE Aus- und anschließen: Halten Sie den "  " Knopf für 3 Sekunden gedrückt. Den Lautsprecher mit Ihrem Gerät verbinden Smartphone/Tablet: Schalten Sie den Lautsprecher ein – Öffnen Sie Einstellungen des Smartphones/Tablets – Bluetooth – Ein – Suchen – SKYWING Soundace S6 – Verbinden – Musik abspielen Computer/Laptop: Schalten Sie den Lautsprecher ein – Öffnen Sie Einstellungen des Laptops – Geräte – Bluetooth und andere Geräte – Bluetooth einschalten – Hinzufügen von Bluetooth oder anderen Geräten – Gerät Suchen – SKWING Soundace S6 – Verbinden – Musik abspielen Echo Dot: Encienda el altavoz: Abra la aplicación Alexa- configuración- configure un nuevo dispositivo- Bluetooth- Empezar un nuevo dispositivo- Dispositivo de búsqueda –SKWING SoundAce S6- Emparejarlo / conectado- Reproduce música. Lautsprecher miteinander verbinden: 1. Schalten Sie die beiden Lautsprecher an und deaktivieren Sie Bluetooth am Handy. 2. Drücken Sie den "  " Knopf der beiden Lautsprecher gleichzeitig- das Paaren beginnt- das Licht wird aufhören, zu blinken- die beiden Lautsprecher sind miteinander verbunden- schalten Sie Bluetooth am Handy ein FAQ: 1.Wie wird der Lautsprecher aufgeladen? Bitte verwenden Sie das Ladegerät Ihres Handys oder den USB Anschluss an Ihrem Laptop/Computer.	2.Was mache ich, wenn der Lautsprecher nicht lädt und das LED Licht aus ist? Bitte überprüfen Sie die Verbindung Ihres USB Anschluss und des Kabels. 3.Warum stellt der Lautsprecher keine Verbindung her? a. Bitte überprüfen Sie, ob Bluetooth an Ihrem Gerät aktiviert ist. b. Versichern Sie sich, dass Ihr Gerät sich innerhalb von 3 Fuß/einem Meter von dem Lautsprecher befindet. c. Warum ist die Wiedergabe verzögert oder unterbrochen? In seltenen Fällen kommt es vor, dass die Bluetooth Version Ihres Smartphones veraltet ist oder andere Apps eine schlechte Kompatibilität mit Bluetooth haben, was zu Problemen in der Wiedergabe führt. Um dies zu lösen, können wir Ihnen eine Update Datei anbieten. FR Cómo encender / apagar: Mantenga presionado el botón "  " durante 3 segundos. Comment faire l'appareillage avec votre périphérique Téléphone et Tablette: Allumer le haut parleur et ouvrez les réglages-Bluetooth- Recherchez et tapez sur SKWING SoundAce S6—Appareillage-/Connecte Et Lancez la musique Ordinateur et Portable: Allumez le haut parleur, ouvrez les réglages, Bluetooth, Recherchez et tapez sur SKWING SoundAce S6-ppareillage-/Connecte Et Lancez la musique	Echo Dot: Allumez le haut parleur –ouvrez Alexa –settings–configurez un nouveau périphérique –Bluetooth–Appareillez un nouveau périphérique –Recherchez périphérique –SKWING SoundAce S6- Paired/Connected—Lancez la musique Comment connecter deux enceintes ensemble : 1. Allumer ces 2 enceintes, garder le Bluetooth du téléphone éteint. 2. Appuyer sur la touche "  " des 2 enceintes ensemble- L'association commence- La lumière de l'indicateur en clignote- Les 2 enceintes sont associées l'une avec l'autre- Allumer le Bluetooth du téléphone. FAQ: 1. Comment charger le haut parleur Merci d'utiliser votre chargeur de téléphone ou un port USB sur votre portable 2. Que faire si le haut parleur ne se charge pas et si la led reste sur Off ? Merci de vérifier les connexions et le cable USB. 3. Pourquoi le haut parleur ne s'appelle pas ? a. Merci de vérifier que le Bluetooth est activé. b. Vérifier que le haut parleur est à moins de 3 mètres du périphérique c. Supprimer les périphériques enregistrés sur votre telephone et ré-essayez 4. Pourquoi il y a du délai ou de l'audio corrompu? Dans de rares cas, la version Bluetooth de votre telephone est obsolète, ce qui peut provoquer des problèmes de lecture. Nous pourrions peut être apporter des mises à jour pour corriger ce problème.	IT Come attivare/disattivare : Premere il pulsante "  " per 3 secondi. Come associare il dispositivo Telefono/Tablet: Accendere l'altoparlante –aprire impostazioni del telefono/tablet–attivare bluetooth ricerca o scansiono –SKWING Soundace S6- associare il dispositivo- riprodur musica. Computer/Laptop: Accendere l' altoparlante –aprire le impostazioni del computer–dispositivi–Bluetooth e altri dispositivi–attivare il dispositivo–aggiungi bluetooth o altri dispositivi–cerca il dispositivo–SKWING SoundAce S6-associato/connesso–riproduci musica. Echo Dot: Accendere l'altoparlante –Aprire Alexa APP –impostazioni–imposta nuovo dispositivo –Bluetooth—Associa un nuovo dispositivo—Cerca dispositivo—SKWING SoundAce S6 –Associato/Connesso—Riproduci musica Come collegare 2 altoparlanti insieme: 1. Accendere gli altoparlanti, spegnere il Bluetooth del telefono. 2. Premere il tasto "  " dei 2 altoparlanti insieme- inizia l'associazione- Se la spia dell'indicatore smetterà di lampeggiare significa che i 2 altoparlanti si sono associati- Accendere il Bluetooth del telefono Domande più comuni: 1. Come si carica l'altoparlante? Si prega di utilizzare il caricabatteria del telefono o la porta USB del computer/laptop.
2.Cosa succede se l' altoparlante non si carica ed il Led è spento? Si prega di controllare il cavo USB per assicurarsi che funzionino correttamente. 3. Perché l' altoparlante non viene associato/accoppiato? a. Verifica che il Bluetooth del tuo dispositivo sia attivato. b. Assicurarsi che il dispositivo si trovi a una distanza inferiore ad 1 metro dall' altoparlante. c. Elimina i preesistenti dispositivi associati e ripristina l'altoparlante. 4. Perché c'è un ritardo o l'audio risulta danneggiato ? In alcuni casi molto raramente la versione Bluetooth del tuo telefono non è aggiornata oppure alcune app del telefono non sono compatibili causando dei problemi di riproduzione. Potremmo essere in grado di risolvere i problemi ma ti fornire un file di aggiornamento.	Portátil / sobremesa: Encienda el altavoz: Abra la configuración del portátil- Dispositivos- Bluetooth y otros dispositivos- encienda el Bluetooth- Agregue Bluetooth u otros dispositivos- Bluetooth- Dispositivo de búsqueda- SKWING SoundAce S6- Emparejarlo / conectado- Reproduce música. Echo Dot: Encienda el altavoz: Abra la aplicación Alexa- configuración- configure un nuevo dispositivo- Bluetooth- Empezar un nuevo dispositivo- Dispositivo de búsqueda –SKWING SoundAce S6- Emparejarlo / conectado- Reproduce música. Cómo conectar 2 altavoces juntos: 1. Encienda estos 2 altavoces, manténgalos apagados del telefono. 2. Presione la tecla "  " de los 2 altavoces a la vez- Comience a emparejar- La luz indicadora dejará de parpadear cuando los 2 altavoces estén emparejados entre sí- Encienda el Bluetooth del teléfono Preguntas frecuentes: 1. ¿Cómo se carga el altavoz? Utilice el cargador de su teléfono o el puerto USB en su ordenador / portátil. 2. ¿Qué sucede si la unidad no se carga y el LED está apagado? Compruebe sus conexiones de cable y USB para asegurarse de que funcionan correctamente. 3. ¿Por qué la unidad no se conecta / empareja? a. Verifique para asegurarse de que el Bluetooth de su dispositivo esté habilitado. b. Asegúrese de que su dispositivo esté a menos de un metro del altavoz. c. Elimine los registros de emparejamiento en su dispositivo y reinicie el altavoz.	4. ¿Por qué hay un retraso o audio dañado? In algunos casos raros, la versión de Bluetooth de su teléfono puede estar desactualizada o algunas aplicaciones del teléfono no son compatibles con Bluetooth, lo que resulta en problemas de reproducción. Es posible que podamos proporcionar un archivo de actualización para resolver esto. ON/OFFを切り替える方法: 「  」ボタンを3秒間押し続けます。 Bluetoothペアリング方法: スマートフォン/タブレット端末: 本スピーカーの電源をONにした状態で、スマートフォン/タブレット端末から、設定画面 → Bluetooth → 端末の検索を開始。SKWING SoundAce S6を接続/ペアリング完了状態にした後、音楽を再生してください。 デスクトップPC / ノートブックPC: 本スピーカーの電源をONにした状態で、PC上から、設定画面 → デバイス → Bluetoothとその他のデバイスを開き、Bluetoothを起動してください。Bluetoothとその他のデバイスの追加メニューからBluetoothを選択し、端末の検索を開始。SKWING SoundAce S6を接続/ペアリング完了状態にした後、音楽を再生してください。	Echo Dot: 本スピーカーの電源をONにした状態で、Alexa Appを開きます。Alexa App上、Echo Dotデバイスを選択し、Bluetoothのペアリングを選択します。ペアリングを完了。 *SKWING SoundAce S6を接続/ペアリング完了状態にした後、音楽を再生してください。 2つのスピーカーを接続(ペアリング)する方法: 1. スマートフォンのBluetoothをオフにした状態で、2つのスピーカーをONにします。 2. 2つのスピーカーの「  」ボタンを同時押し、その後「ペアリング」が開始されます。インターカラータの音が再生するまで。 3. 2つのスピーカーは接続(ペアリング)が完了した状態になりました。一部はスマートフォンアプリ Bluetoothの権限の問題で、再生に問題が発生する場合があります。 この問題を解決するためのアップデートファイルを提供する可能性があります。 FAQ: 1. どうやってスピーカーに充電するのですか? お使いのスマートフォン充電器やパソコンのUSBポートに接続してください。 2. スピーカーに充電できない場合、LEDランプが点滅し、音は再生されませんか? お使いの充電ケーブル、USBケーブルの接続を確認してください。正しく接続されていることを確認してください。 3. なぜ2スピーカーが接続/ペアリングできないのですか? お使いのデバイスのBluetooth機能を閉鎖してください。 1. 2つのスピーカーの電源をONにした状態で、本スピーカーをONにしてください。 2. 2つのスピーカーの電源をONにした状態で、Bluetoothとその他のデバイスの権限の問題で、再生に問題が発生する場合があります。

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.