



Instruction Sheet

Play / Pause Song

Previous Song

Next Song

Voice Effects MODE

Hold to Enter VOICE EFFECTS Mode

Click to Cycle Voice Effects

Hold to Exit

Adjust MIC Volume

Adjust MUSIC Volume

Adjust ECHO Volume

 Hold to Power On/Off
- The blue light will turn on/off
Click to cycle through MODES

Bluetooth MODE:

1. Turn on Bluetooth on your mobile phone
2. Click the device name "Kid Star" to pair
3. The product will play the CONNECTED sound
4. Use any suitable App to play music and sing!

 **USB Charging Port**
- Automatically shuts down when the battery is low
- Red light will show when charging
- Normal charge takes 2 hrs, red light will turn off (operation: 8-10 hrs)

Battery: Li-ion 18650 1200mAh, 3.7V

Kid Star Karaoke MODE - Song List:

- | | | |
|------------------------------|---------------------------------|---------------------------|
| 1. Wheels on the Bus | 6. Twinkle Little Star | 11. B.I.N.G.O. |
| 2. Row Your Boat | 7. Take Me Out to the Ball Game | 12. Itsy Bitsy Spider |
| 3. Old MacDonald | 8. Wish You a Merry Christmas | 13. Happy And You Know It |
| 4. ABCs | 9. Jingle Bells | 14. You Are My Sunshine |
| 5. Comin' Round the Mountain | 10. Happy Birthday Song | 15. Animal Sounds Song |

FCC Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.