


R87Pro 说明书折页：128g双铜四色印刷

正面

反面

773 MECHANICAL KEYBOARD



FCC WARNING: This device complies with the FCC part 15 rules. If you are experiencing interference, you may need to adjust the antenna or the position of the device.

WHEN USING A KEYBOARD: Please use the keyboard in a safe and proper manner. Do not use the keyboard in a way that may cause damage to the device or the computer.

12 MONTH WARRANTY

PRODUCT BASIC

- Model: RK773-001 (Black)
- Switch: Mechanical (Red)
- USB Type: USB-A
- Layout: 104 Keys
- 2.4G Dongle: 2.4G Wireless

INDICATOR LIGHTS/KNOB FUNCTION

KNOB FUNCTION

- Plugable knob (can be used instead of Fn key)
- On/Off: Volume
- On/Off: Mute
- On/Off: Play/Pause

Wired Mode

Place the switch to "WIRED MODE" side.

BT CONNECTIVITY

Place the switch to "B" side.

2.4G CONNECTIVITY

Place the switch to "G" side.

DFU MODE

There are two methods to enter dfu mode (development Firmware upgrade) on the keyboard:

BATTERY REMINDER

In BT 2.4G mode, Press and hold **Fn+Enter** to view the battery level indicator.

BACKLIGHT CONTROL

In USB mode, the backlight brightness is brightest by default.

Backlight Brightness +

Backlight Brightness -

Backlight Speed +

Backlight Speed -

Pause

Backlight Monochrome Switching

Supports Multiple Backlight Effect Switching

Windows Lock

Side Light Color Switching

Turn Off Backlight And Side Lights


Switch To Windows System

Switch To Mac System

Switch Between Six-key Rollover And Full-key Rollover

Press And Hold For Three Seconds To Restore Factory Settings

773 MECHANICAL KEYBOARD



ISED STATEMENT: This device complies with the ISED part 247 rules. If you are experiencing interference, you may need to adjust the antenna or the position of the device.

BATTERIES: The keyboard is powered by 2 AA batteries. Please insert the batteries correctly.

12 MONTH WARRANTY

CUSTOM BACKLIGHT SET

Step 1: Press **Fn+F1** to customize backlight.

Step 2: Press **Fn+F2** to enter backlit recording mode.

Step 3: Press the keys which you want to record the backlight, and repeat the steps.

Step 4: When it is done, pressing **Fn+F3** again will save and exit the backlit recording mode.

MULTIMEDIA KEYS FOR WINDOWS

Windows system (Fn + A: switch to Windows system)

Fn + F1	Fn + F2	Fn + F3	Fn + F4	Fn + F5	Fn + F6
Computer	Browser	Mailbox	Calculator	Notes	Map
Fn + F7	Fn + F8	Fn + F9	Fn + F10	Fn + F11	Fn + F12
Last Song	Play / Pause	Next Song	Mute	Volume-	Volume+

MULTIMEDIA KEYS FOR MAC

MAC system (Fn + S: switch to Mac system)

Fn + F1	Fn + F2	Fn + F3	Fn + F4	Fn + F5	Fn + F6
Screen Brightness-	Screen Brightness+	Keyboard Backlight Brightness-	Keyboard Backlight Brightness+	Last Song	Play / Pause
Fn + F7	Fn + F8	Fn + F9	Fn + F10	Fn + F11	Fn + F12
Next Song	Mute	Volume-	Volume+		

Have an issue with one of our RK products?

Feel free to contact us with any product issues or questions. We will reply as quickly as possible to ensure all your needs are handled. For better technical support, please contact rkgameing@rkgameing.com

RK ROYAL KLUDGE

Executive standard GB/T 14281-2010
Made in China www.rkgameing.com
Download Driver Address: www.rkgameing.com/Download/