


Power Bank Manual



Product Description

Thank you for choosing our wireless charger, before you use this product, please read this manual carefully and keep it properly.

Product Parameters

Name: Power Bank
Model: ZHX-PB37
Battery Type: Lithium Polymer Battery
Battery Energy: 5000mAh/19.25Wh
Type-C Input: 5V-3A, 9V-1.6A
Type-C Output: 5V-2A, 9V-2A
Wireless charging (support automatic wake-up): 5W, 7.5W, 10W, 15W
Material: PC+ABS/Aluminum alloy

Packing List

Power Bank x1
Charging cable x1
User manual x1

Instructions And Precautions For Use

1. For first time use, please fully charge the product.
2. Description of the display: Click on the button to change the mode of the display to the state of the charge (power % → tension V → current W).
3. When the adapter is plugged in to charge the product, the corresponding display will be IN, while supporting fast charging to display the green lightning mark.
4. If the product is charging, it will be displayed as OUT, and support fast charging to show the green lightning mark.
5. Button Description: Click on the button to check the power and turn on the output, or switch the display mode, double-click to turn off the output.
6. If there is a conversion efficiency of mobile power, so the mobile power battery capacity is not equal to the rechargeable capacity.
7. When charging this product or using the product to charge other devices, please choose the appropriate charger and data cable.
8. If there is no battery indicator, after pressing the button, the product may be in a protective state, you can connect to an external charger to try to recover.
9. When you do not use the product for a long time, please keep the battery level in the range of about 35-50%, and store it in a cool and dry environment. Avoid storing the product for a long period of time in a fully charged or non-charged state to prolong the battery life.
10. If the consumer violates the warnings in the instruction manual and uses the product improperly, he/she will be responsible for all the consequences of personal and property damages, and our company will not be held legally liable for any damages.

Safety Instructions

1. This product is not a toy, please place it out of reach of children, and prohibit children from using or playing with it to avoid accidents.
2. Please make sure to use the charger that meets the local safety standards (such as China's 3C certification standards) to charge this product.
3. Do not press, knock the product and avoid making the product serious or strong vibration, such as these cases, or if liquid seepage / splash into the interior of the product, it may cause circuit damage or short circuit, please stop using and dispose of it appropriately.

Safety Guidance

1. This product is not a toy, please place it out of reach of children, and it is forbidden for children to use or play with it to avoid accidents.
2. Please be sure to choose a charger that meets local safety standards (such as China's 3C certification standards) to charge this product.
3. Do not press, knock the product and avoid making the product serious or strong vibration, such as these cases, or if liquid seepage / splash into the interior of the product, it may cause circuit damage or short circuit, please stop using and dispose of it appropriately.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Do not charge or discharge this product in a place that may affect its heat dissipation, such as in a pocket of clothes and pants, in an airtight bag, bed, sofa, or other places that may affect its heat dissipation to charge or discharge. And make sure that the product is not covered by clothes, pillows, bedding or other debris, etc. When charging other devices such as mobile phones for a long time, please do not stack the product and other devices such as mobile phones together to ensure good heat dissipation of mobile phones and other devices.

2. It is strictly forbidden to disassemble, squeeze, puncture, short-circuit this product or put it into water, fire (including near stoves, heating and other heat sources) or expose it to temperatures higher than 60°C (140°F).
3. When the weather is hot, do not leave this product outside in an unoccupied car or other places exposed to the sun.

4. If this product is swollen, deformed, leaking, or has a significant decrease in capacity, please stop using it immediately and dispose of it properly.

5. Do not charge or discharge this product in a place that may affect its heat dissipation, such as in a pocket of clothes and pants, in an airtight bag, bed, sofa, or other places that may affect its heat dissipation to charge or discharge. And make sure that the product is not covered by clothes, pillows, bedding or other debris, etc. When charging other devices such as mobile phones for a long time, please do not stack the product and other devices such as mobile phones together to ensure good heat dissipation of mobile phones and other devices.

6. Do not charge or discharge this product in a place that may affect its heat dissipation, such as in a pocket of clothes and pants, in an airtight bag, bed, sofa, or other places that may affect its heat dissipation to charge or discharge. And make sure that the product is not covered by clothes, pillows, bedding or other debris, etc. When charging other devices such as mobile phones for a long time, please do not stack the product and other devices such as mobile phones together to ensure good heat dissipation of mobile phones and other devices.

7. When the weather is hot, do not leave this product outside in an unoccupied car or other places exposed to the sun.

8. If this product contains ionic polymer batteries, and it is strictly forbidden to disassemble the product shell without permission. Avoid causing battery damage or other hazards.

使用说明及注意事项

1.首次使用,请将本产品充完电。
2.显示说明:在单击按钮可切换显示模式(电量%→电压→电流→功率W→电量%)。

3.当插入适配器给产品充完电时对应显示为IN,同时支持快充显示绿色闪电图标。
4.按键说明:按住按键给电源充电并打开输出,也可以以显示模式,双击关闭输出。当产品负载30±3秒后进入待机状态。

5.本产品含有离子聚合物电池,严禁拆开产品外壳,避免造成电池破损或其他危险。

Anweisungen Und Vorsichtshinweise

1. Bei der ersten Verwendung laden Sie das Produkt vollständig auf.

2. die Beschreibung der Anzeige/Leistung Sie auf die nächsten Minuten ein. Wenn Sie die Anzeige/Leistung nicht mehr benötigen, drücken Sie auf den Schaltknopf wieder nicht mehr.

3. Do not press, knock the product and avoid making the product serious or strong vibration, such as these cases, or if liquid seepage / splash into the interior of the product, it may cause circuit damage or short circuit, please stop using and dispose of it appropriately.

4. If this product is swollen, deformed, leaking, or has a significant decrease in capacity, please stop using it immediately and dispose of it properly.

5. Do not charge or discharge this product in a place that may affect its heat dissipation, such as in a pocket of clothes and pants, in an airtight bag, bed, sofa, or other places that may affect its heat dissipation to charge or discharge. And make sure that the product is not covered by clothes, pillows, bedding or other debris, etc. When charging other devices such as mobile phones for a long time, please do not stack the product and other devices such as mobile phones together to ensure good heat dissipation of mobile phones and other devices.

6. Do not charge or discharge this product in a place that may affect its heat dissipation, such as in a pocket of clothes and pants, in an airtight bag, bed, sofa, or other places that may affect its heat dissipation to charge or discharge. And make sure that the product is not covered by clothes, pillows, bedding or other debris, etc. When charging other devices such as mobile phones for a long time, please do not stack the product and other devices such as mobile phones together to ensure good heat dissipation of mobile phones and other devices.

7. When the weather is hot, do not leave this product outside in an unoccupied car or other places exposed to the sun.

8. If this product contains ionic polymer batteries, and it is strictly forbidden to disassemble the product shell without permission. Avoid causing battery damage or other hazards.

Sicherheitshinweise

1. Diese Produkte ist kein Spielzeug, bitte es auf Kinder fern halten.

2. die Anzeige/Leistung Sie auf die nächsten Minuten ein. Wenn Sie die Anzeige/Leistung nicht mehr benötigen, drücken Sie auf den Schaltknopf wieder nicht mehr.

3. Do not press, knock the product and avoid making the product serious or strong vibration, such as these cases, or if liquid seepage / splash into the interior of the product, it may cause circuit damage or short circuit, please stop using and dispose of it appropriately.

4. If this product is swollen, deformed, leaking, or has a significant decrease in capacity, please stop using it immediately and dispose of it properly.

5. Do not charge or discharge this product in a place that may affect its heat dissipation, such as in a pocket of clothes and pants, in an airtight bag, bed, sofa, or other places that may affect its heat dissipation to charge or discharge. And make sure that the product is not covered by clothes, pillows, bedding or other debris, etc. When charging other devices such as mobile phones for a long time, please do not stack the product and other devices such as mobile phones together to ensure good heat dissipation of mobile phones and other devices.

6. Do not charge or discharge this product in a place that may affect its heat dissipation, such as in a pocket of clothes and pants, in an airtight bag, bed, sofa, or other places that may affect its heat dissipation to charge or discharge. And make sure that the product is not covered by clothes, pillows, bedding or other debris, etc. When charging other devices such as mobile phones for a long time, please do not stack the product and other devices such as mobile phones together to ensure good heat dissipation of mobile phones and other devices.

7. When the weather is hot, do not leave this product outside in an unoccupied car or other places exposed to the sun.

8. If this product contains ionic polymer batteries, and it is strictly forbidden to disassemble the product shell without permission. Avoid causing battery damage or other hazards.

产品介绍

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品描述

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。

产品参数

名称: 移动电源
型号: ZHX-PB37
电池类型: 聚合物锂电池
电池能量: 5000mAh/19.25Wh
Type-C 输入: 5V-3A, 9V-1.6A
Type-C 输出: 5V-2A, 9V-2A
无线充(支持自动唤醒): 5W, 7.5W, 10W, 15W
材质: PC+ABS/铝合金

产品说明

感谢您选择我们的无线充电器,在您使用本产品之前,请仔细阅读本说明书并妥善保管。