

Floor Standing Digital Signage

Product User Manual **2.0**



Catalogue

I	Attention	1
II	Accessories	2
III	Installation Guide	3
IV	Installation Guidance	4
V	Operation Guidance	5
VI	After-sales Support	8



Scan the QR code to open the link in browser.
To get the video guidance of the installation
and the usage on YouTube

1. Attention

Please have a check on the user guide about the operation guidance before using.

- 2) Do not splash liquid on the digital signage.
- 3) Do not put the digital signage under sunlight directly.
- 4) Normal use is protected by our warranty terms.
Damage caused by abnormal use is not protected by warranty terms.
- 5) If you required with any support from us, please contact our after-sales support team.

After-sales Support

If you have any technical inquiries or need any product services, please feel free to contact us . We always provide the best solution and service for you!

✉ Email:

support@marveltechgroup.com

☎ Phone:

0016284885213 (WhatsApp Online)

008618123978547 (WhatsApp Online)

2.Component Introduction

The attachments received are subject to



Body



Base



Cross screw driver



Allen wrench



M8 screw



M6 screw



Remote-control



Power Cord



Wheels



Battery




Key

3.Installation Guide

Step 1: Wheels installation on the base (If you don't want install wheels, jump to next step). Using the cross screw driver to screw in the 4 M6 screws on each wheel.



Step 2: Put the digital signage body on a bench, and install the base. Use the Allen wrench to screw in the 6 M8 screws to fasten the base.



Step 3 :Put the signage on the floor, get the power connected. And turn the power switch on.



4.Operation Guidance

1.Remote Controller



5.Application

1.Aptoide


This is the application store. Other application can be installed with this application store.



Aptoide

2.Auto Start Settings

Application which installed on the system can be selected with automatically start when system boot up. Especially when there's a player box with HDMI connected into the system, that HDMI Input application suggested to be selected with automatically start when system boot up.



3.Autoplay

The Autoplay was the system player with USB disk plug and play or copy mode play. Quickly started your advertising with a USB disk easily plug in.



Autoplay

4.Chrome, Google

The web browser on this Android system.



Chrome



Google

5. File Manager

The internal storage or the USB disk when it was plugged in can be accessed on the Android system with the File Manager.



6. HDMI Input

Display the HDMI input signal when this HDMI Input was turn on.



HDMI input

7. HiFile Manager, Play Store

The File Manager and Application Store for the TV version, not suggested to be used on this vertical screen Android system.



HiFileManager




Play Store

8. Settings

The system settings, the WiFi connection, the brightness adjusting and some other basic system settings can be done on this Settings application.




Setting



9. Time Switch

The Automatically power ON/OFF settings for the Android system.




Timer Switch

6. Autoplay

The quick start advertising application "Autoplay "


The Autoplay application will wake up automatically once the media contents was detected from your USB disk root directory. The default play mode setting of the Autoplay application is the Plug and Play Mode function.

Put your media contents into the USB flash disk root directory. And plug into the digital signage USB port. It will display the media contents automatically from your USB disk.




Also you can make settings on the Autoplay application, set with Copy Mode.

Set up a file folder named with "AutoPlayFile" on your USB flash disk. Put your media contents into that "AutoPlayFile". Then plug your USB flash disk into the digital signage USB ports at the back, it will copy the media contents from your USB flash disk "AutoPlayFile" file folder into the digital signage's internal storage. So that you can plug out your USB flash disk after your media contents was copied successfully to the system internal storage.




7.HDMI Input Supported

You can install your player box inside of the digital signal. There's AC power plug and HDMI input port inside the door, and there's a holder available for your player box installation. If you are going to put your own player box inside, suggested to set on the "Auto Start Settings", select the HDMI input, so that it will display your player box HDMI signal automatically after the digital signage powered on. And if your digital signage is touch screen, be sure switch the 2 USB cables connection to your player box to make the touch working on your player box system.





8.Timer Switch


You can make auto ON/OFF schedule on the Timer switch application.



Select to turn this power switch on. Or click EDIT to make the time settings.



And the timer switch settings from Sunday to Saturday can be canceled or selected.



FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.