

70mm

70mm

70mm

70mm

70mm

70mm

70mm

70mm

70mm

560mm

Premium Product

TRUE WIRELESS EARBUDS

User manual

1 Package Contents

Earbuds

Earbuds

2 Product Overview

Middle/Power button

Charging Case Indicator

Type-C Charging Port

3 Operation instruction

① Power on

② Pair

③ Bluetooth earbuds connection successfully

④ Earbuds pairing mode

⑤ Turn on your mobile phone's Bluetooth function

⑥ Click the product search key to connect the earbuds

⑦ Bluetooth earbuds connection successfully

⑧ Power off

⑨ Phone LED

⑩ Main, Play and pause

⑪ LED Status Indicators

⑪ LED Status Indicators

When the charging case is charged, the four lights of the charging case gradually turn on, that is, when the power supply is less than 25%, only one light turns on. When the power supply reaches 25-50%, there are two lights on, when the power supply reaches 50-75%, three lights turn on, and when the power supply is 75-100%, four lights turn on, indicating that the charging case is fully charged.

⑪ LED Status Indicators

When the charging case is charged, the four lights of the charging case gradually turn on, that is, when the power supply is less than 25%, only one light turns on. When the power supply reaches 25-50%, there are two lights on, when the power supply reaches 50-75%, three lights turn on, and when the power supply is 75-100%, four lights turn on, indicating that the charging case is fully charged.

FCC ID: 3AHL4B29

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, it can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

