



# FireBoltt Call Smart Watch User Manual

# Downloading and connecting of smart watch with Da Fit APP


1. Download and install Da Fit APP
2. Scan QR code with mobile phone to download APP.
3. For IOS system, select APP Store, search for Da Fit App.



Android system, select Google Play to download and install Da Fit App. Or scan QR code to download

Note: your mobile phone must support Android 5.1 or IOS 8.0 or above, and Bluetooth 4.0 or above.

## Connect smart watch with Da Fit APP



Click on "Add Device" to connect the smart watch

12:31



## ADD A DEVICE



FireBoltt Call

E3:EF:F1:57:52:84

Click on your device in the device list scanned. Connect it directly to Android system.

12:32



## FireBoltt Call

Connected

E3:EF:F1:57:52:84

50%

Remove Device



WATCH FACES



NOT

**Bluetooth Pairing Request**

"FireBoltt Call" would like to pair with your iPhone.

ALAI

[Cancel](#)

[Pair](#)



SHUTTER



FUNCTIONS



OTHERS



The IOS system will show a Bluetooth pairing request and you can click on Bluetooth "Pairing" to confirm.

12:32



## FireBoltt Call

Connected

E3:EF:F1:57:52:84

50%

[Remove Device](#)



Successfully connected

### WATCH FACES



### NOTIFICATIONS



### ALARMS



### SHUTTER



### FUNCTIONS



### OTHERS



12:32



# FireBoltt Call

Connected

E3:EF:F1:57:52:84

50%

[Remove Device](#)



WATCH FACES



NOT

**Allow FireBoltt Call to display  
your iPhone notifications?**

When this accessory is connected, all  
the notifications you receive will  
appear on its display.

[Allow](#)

[Don't Allow](#)

ALAR



SHUTTER



FAVORITE CONTACTS



FUNCTIONS



Click on Allow to let the  
watch display all the  
notification of the phone

# FireBoltt Call

Connected

E3:EF:F1:57:52:84

50% [Remove Device](#)

WATCH FACES



NOTIFICATIONS



For both android & iOS click on Notifications Tab in the Dafit app



## NOTIFICATIONS

Turn on the switch to synchronize related information to smart bracelet.

	Phone	<input checked="" type="checkbox"/>
	Messages	<input checked="" type="checkbox"/>
	Facebook	<input checked="" type="checkbox"/>
	Twitter	<input checked="" type="checkbox"/>
	WhatsApp	<input checked="" type="checkbox"/>
	WeChat	<input checked="" type="checkbox"/>
	Instagram	<input checked="" type="checkbox"/>
	Skype	<input checked="" type="checkbox"/>
	KakaoTalk	<input checked="" type="checkbox"/>
	Line	<input checked="" type="checkbox"/>

Enable all the notifications for the ease of use

# **BLUETOOTH CALLING FUNCTION**

This watch comes with a special feature of Bluetooth calling. The user can make calls without having to open the phone. You can also view the call history of the watch. You need to keep the connection between the watch and the phone stable when using the Phone Call function.


The watch also has a microphone and a speaker built in for the ease of talking through the watch and to hear music, phone calls, and other notifications

Follow the steps to activate the calling function and much more.

## **Part A - How to connect**

- **Step 1:** After connecting the watch to the Da Fit App, you need to go the bluetooth settings of the phone and pair the watch there as shown below.

## For iOS



Switch on the bluetooth in the phone bluetooth settings and you shall see the available device as **"Audio\_FireBoltt Call"**

12:33



Settings

## Bluetooth

Bluetooth



Now discoverable as "Aayushi's iphone".

MY DEVICES

Accessory Not Connected

It shall show Connected


Audio\_FireBoltt Call Connected

BSW004 Not Connected


BSW004\_313E Not Connected

FireBoltt Call Connected

## For Android



Switch on the bluetooth in the phone bluetooth settings you shall see the available device as "**Audio\_FireBoltt Call**"



Accept the Bluetooth Pairing Request

12:43

71%

Bluetooth

Scan Advanced

On



Make sure the device you want to connect to is in pairing mode. Your phone (Raunak's Galaxy M31s) is currently visible to nearby devices.

Paired devices

**Audio\_FireBoltt Call**  
Connected for calls and audio




Available devices

**Echo Plus-7JU**

**Home Theatre BT**

Once accepted you can see the following screens saying - **"Connected for calls & audio"**


- **Step 2:** Go to the watch and swipe right to the phone function




- After successfully connecting the bluetooth you will get this screen.



- Upon clicking on the recent call you can see the recent calls of your device



- When you click on the dial pad you shall get this screen on your watch.



- Once you dial the number the call button on the right corner shall appear.




- You click the dial button, you can see that the number is dialling



- Through the microphone available in the watch **you can talk through the watch and adjust the speaker volume by the + & - sign on the watch and disconnect the call.**


## Part B - How to disconnect

**To disconnect the bluetooth calling the user simply has to go to the phone's bluetooth setting and "unpair" the Audio\_FireBoltt Call device**



**The Calls button on the extreme left top helps you to connect/disconnect the bluetooth calling with one touch**

## Part C - Add contacts



- You can add upto 8 contacts – Add the contacts from the Dafit App. Go to "Favourite Contacts" and add contacts. The selected contacts will get synced to your watch.

18:29 75%

### FireBoltt Call

Connected

E3:EF:F1:57:52:84

31%

REMOVE



Watch Faces

Notifications

Alarms

Shutter

Favorite Contacts

Functions

Others

Click on Favorite Contact to add the contacts

Cancel

Select Contact

Done(2)

A

A Afzal

A Arunay Kumar Jha

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z

Select the contacts you  
want to add

A Ajit Raikar

A Arvind Mahajan

A Ashok Jhunjhunwala

<

Edit All

## Favorite Contacts

You can select 8 contacts in the address book and display their  
shortcuts on the watch

A Akshay Sharma

A Ajit Raikar



+

The contacts will get added.

It takes a while to upload contact  
data


## **Part D - Switch between Phone / Watch**

**Switch Between Watch / Phone During an Active Call :** If your watch is connected to the Phone via Bluetooth, all calls will come on the watch by default. If you want to change the call to the phone, during an active call, simply click on **Audio\_FireBoltt Call** Bluetooth icon to unselect it. The call will then come on your phone.



## **Part E - Listen to Music**

**Listen to Music** - You can Listen to Music on your Watch, when it is connected to your Phone Via Bluetooth Mode. Now Play, Pause and Listen to your Favourite Songs all on the Watch!




## **Part F - Battery Advisory**

### **Battery**


- The battery lasts for 24 hours with bluetooth calling mode enabled.
- If the bluetooth calling mode is disabled then the battery can last for 5 days.
- On standby the battery can stay for as long as 30 days.
- Advisory- To conserve battery, It is advised to turn off the bluetooth when not in use.

## **Part G - Call Reset in Case Bluetooth Connection is Lost**


In case the Bluetooth connection for voice calls gets disconnected and is not visible in the list of Bluetooth devices on the phone i.e. you don't see **Audio\_FireBoltt Call**, Please reset the call connection by clicking on the call reset button in the main menu.



Click on the Settings Icon




Click on the Call Reset Icon



Confirm the Reset Process

# Functions Navigation

The screen can be navigated by sliding left/right or sliding up/down




Control Center


Swipe  
Down      Up



Menu



Swipe  
Right



Feature pages

Swipe  
Down      Up



Messages

# Watch Face Functions Navigation and Button Instructions


The watch features a full touch control screen with a reflective display and a button

## Functions Navigation

The screen can be navigated by sliding left/right or sliding up/down


By default, the watch face page displays, and on the watch face page, you can:

- Slide down to view watch settings.




- The Phone Icon needs to be clicked upon to be able to connect to bluetooth calling
- Brightness
- Weather
- Menu
- Info
- Settings



- Slide up to view messages and other notifications.



- Slide left to view quick menu, which allows you to go to any function with a single click.




- a) Slide right to view phone, music, steps, sleep, heart rate, SPO2, weather




- b) On each function when you slide down you can view details.

- SPO2





- Heart Rate



- b) On each function when you slide down you can view details.

- Steps



# Touch Button Operations

## Short press from the side button


To unlock the screen in the lock screen status

To return to the watch face page from the first-level menu entry in the unlocked status



## Long press from the side button

To turn on the watch in the power off status





# Watch Wearing and Charging

It is recommended to wear the watch with a moderate tightness at a distance two fingers far from your wrist to ensure that the optical heart rate monitor works properly

## Charging

- Plug the charger's USB port into a mobile phone charger or a computer USB port to charge the watch.
- Attach the charging pin to charge the smart watch.
- The charging icon will appear on the screen, indicating that the watch is being charged.
- It is recommended to use computer USB ports or brand mobile phone chargers to charge the watch.



# Use of Functions

The watch has a lot of functions, these can be accessed by swiping left to the menu. A short brief of the functions are as below:



**Stopwatch**



**Breathe**



**Bluetooth Calling**



**Weather**



**Music**



**Heart Rate**



**SPO2**



**Flashlight**



**Sleep**



**Message**



**Training**



**Timer**



**Settings**



**Steps**




**Alarm**




**Shutter**

- Steps - The watch automatically tracks the step taken on the screen. Note: Your movement stats reset to 0 at midnight.




- Sleep - You need to wear the watch while sleeping, it will provide the hours slept and quality of sleep stats.
- Note: Sleep stats reset to 0 at 8 pm




- Exercise - This feature comprises of 8 exercise modes. Track your fitness goals in a tap. You can view the following activities: Running, Walking, Cycling, Skipping, Football, Basketball, Badminton, Swimming.




- Heart Rate – The watch will record your heart rate all day. You can also tap on the page to start measuring




- Music – You can remote control the music player of your phone once the watch is connected to the device



- Oxygen Tracking (SPO2) – Tap the SPO2 page to start measuring. On the SPO2 page you can see the previous data




- Weather – You can know the current weather and the forecast for tomorrow, this information is synced from your app. Scroll Up to see the forecast weather. It will not be updated if the phone is disconnected for a long time.



- Camera – You can remote control the camera of your phone once the watch is connected with your device.



- Setting - Check out other features through this tab.



# Other Settings

## Watch Face

Replace the Watch Face on the Watch:

Long Press the screen, you shall get the options to change the watch face, scroll left and click on the watch face you want to select. The watch face will set.

Slide down and go to Settings. Under Settings select Dial Switch and swipe left and click to select the watch face



Replace the Watch Face on the App:

Tap the Watch face settings entry in the "Profile" -> "FireBoltt Call" page, and then download and sync watch faces on the Watch Face Store. After that, the replacement is done

# Notifications

## Enable Notifications

During use, you need to enable the corresponding "App alerts" on the Da Fit App, and keep the watch and the mobile phone connected.

If you are using an iOS device, you need to pair the watch with the Bluetooth of the mobile phone before use.

If you are using an Android device, you need to include the App into the whitelist or self-starting list of the mobile phone in background settings and keep the App running in the background to protect it from being detected and killed by the mobile phone's background processes. Such background processes could disconnect the watch and the App, and as a result no reminder will be received. See "Profile" -> "FireBoltt Call" -> "Run in background" settings for different mobile phone systems

## View Notifications

When the watch receives a notification alert, it will vibrate to remind you and automatically display the notification content. If you do not view the notification immediately, you may slide up in the watch face page to go to messages and check the notification

## **Workout**

Sliding left in the watch face page can make the Activity app items visible. For more information, see the "Introduction to the Workout Function" section below

## **Weather**

In the weather page, you can view the weather for the day and the weather information for the next day.

The weather displayed by the watch comes from the server. Therefore, you need to keep the Bluetooth of your mobile phone on and connect it with the watch to keep abreast of the latest weather information changes.

In addition, when a weather alert is received, the watch will receive the alert as well. You may toggle on the weather alert switch in the "Profile" -> "FireBoltt Call" -> " Weather settings " page on the Da Fit App


## **Settings**

In the settings page, the settings items of Stopwatch, Alarm, Countdown, Brightness, Vibration, Theatre, Reset, About, Power off and App QR Code are provided.


**Stopwatch:** You can begin and close any time line and stop the watch.

**Vibration:** This feature allows the user to turn on and off the vibration of the watch



**Timer:** A countdown timer lets you count the time forward and allows the user to set goals and finish a particular event on time.




**Alarm:** When the alarm on the mobile phone rings, the watch will vibrate to remind you that the alarm is ringing




**Phone:** This is a feature allows the user to make calls from the watch itself




**Brightness:** The brightness is a bar that you may click to adjust



**Theater:** This is a mode where the brightness will dim and vibration will shut




**Factory reset:** This is a feature to reset all data, and you can press and hold the touch button to reset, you shall get a confirmation dialogue box after that. After a reset, you need to re-connect the watch before use.



**About:** You can view the firmware version and Bluetooth address of the watch in the about page.




**Power off:** This is a feature to turn off the watch.




**App QR Code:** This is a feature helps to download the app as it gives a QR Code on the watch screen that is scannable.



**DND:** The watch can be put into the DND mode meaning Do Not Disturb Mode



**Style:** This is a feature is to change the way the quick menu is seen



**Dial Watch:** This is a feature helps you to change the watch face with a click




# Watch Status Reminder

## Incoming Call

When the watch receives incoming calls, it will vibrate to remind you, also you can answer or reject the call.

## Idle alerts

When you are sitting for a long time, the watch will vibrate to remind you to get up for a while. Before using this function, you need to enable Idle alerts by tapping "Profile" -> "My devices" and turning on Idle alerts on the Da Fit App



MOVE



WATER

## Goal Notifications


When the number of steps reaches the set goal, the watch will vibrate to remind you. Before using this function, you need to enable Goal notifications by tapping "Profile" -> "My devices" and turning on Goal notifications on the Da Fit App



GOAL

## Watch Alarm Alert

When the alarm on the mobile phone rings, the watch will vibrate to remind you that the alarm is ringing. Before using this function, you need to enable Watch alarm alert by tapping "Profile" -> "My devices" and turning on Watch alarm on the Da Fit App



## **Introduction to the Workout Function**


### Start Workouts

There are two approaches to starting a workout:

- Select a workout type in the Activity entry and enable it;
- Press and hold the touch button to quickly start the preset workout

The watch currently supports the following workout modes: Walking, Running, Cycling, Skipping, Football, Basketball, Badminton.

Before starting a workout, it is recommended to check whether the watch storage space is enough.



## **Daily Maintenance of the Watch**

1. The watch is not resistant to erosive liquids such as seawater, acidic and alkaline solutions and chemical reagents. Damages or defects caused by misuse or improper use are not covered under warranty
2. Don't use detergents such as soap, hand sanitizer, or bath foam for cleaning to avoid chemical residues from irritating the skin or corroding the device.
3. Don't swim with your smartwatch, we also don't recommend showering with your smartwatch.

## **Precautions**

- The watch has an IP67 water resistant and dustproof rating, but it is not suitable for swimming or bathing.
- Do not operate the watch underwater. After touching water, do not operate the touch screen or charge the watch until the watch is wiped by using a soft cloth.
- The watch is not resistant to erosive liquids such as seawater, acidic and alkaline solutions and chemical reagents. Damages or defects caused by misuse or improper use are not covered under warranty.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction