


# Wii Remote + Wii Nunchuk Game Controller User Guide

## User Guide

### Controller diagram



## ***Connect to the Wii***

Push the small red button on the controller (where the batteries go) then push the red button on the Wii console (under the little door), then you're able to synchronize with Nintendo Wii.

### ***Please note***

- ① Recommended distance for using the cursor: 50cm--6m (visual sensitivity change).
- ② Recommended distance for using the sound: >6m (without obstacles)

## ***Connect to the Wii U***

Turn on Wii U to be booted into the main interface. Press the white SYNC button on the front of the Wii U console, and later install the batteries into Wii remote, connect the Nunchuk, and press Sync button(red button, where the batteries go), then you're able to synchronize with Nintendo Wii U.

If you need extra help, please contact

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits –

for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.