


# K3

## 无线蓝牙耳机 双麦通话降噪 使用说明




Version: 1.0

### 操作功能

- ①:菜单键  
开机:长按三秒  
关机:长按四秒
- 通话状态:  
接听/挂断:单击  
拒接:长按两秒  
末位重播:双击
- 播放状态:  
单击:播放/暂停  
音量:单击  
下一曲:双击
- ②:音量-键  
音量:单击  
下一曲:双击
- ③:音量+键  
音量:单击  
上一曲:双击
- ④:环境麦克风  
⑤:拾音麦克风  
⑥:磁吸充电口  
⑦:充电顶针  
⑧:备用耳塞L/S  
⑨:电量显示屏  
⑩:磁吸充电器


### 佩戴

选择合适尺寸的耳塞(默认为中号耳塞;如果佩戴眼镜请先取下眼镜)  
将硅胶耳挂朝着脸颊,沿耳廓想好轻轻挂住,调整以贴合耳廓后边  
旋转麦克风风,使拾音麦克风朝向嘴唇方向以保证收音清晰  
调整耳挂,以及麦克风帮的角度,使之佩戴牢固



P1


需要换一边佩戴时,如下图下所示将麦克风棒沿水平方向旋转180°,在参考上逐步重新  
截到另一边耳朵



### 开机/关机

(温馨提示:首次使用破产品,请将耳机及充电盒充满电)

自动开机/关机:将蓝牙耳机从充电盒中取出耳机将自动开机;放回充电盒后自动关机  
手动操作:耳机关机状态下长按菜单键约三秒后开机;长按菜单键约4秒后耳机将关机




### 配对与连接

第一步:从充电盒中取出蓝牙耳机等待约3秒钟,耳机自动开机并处于等待配对状态  
第二步:打开手机蓝牙开关,搜索新设备,单击列表中的“K3”以完成配对

P2


### 给充电盒充电

使用配备的USB A-Type-C充电线连接5V/1A充电器或者电脑USB输出口开始充电  
充电盒充电时,电脑显示屏点亮;充满电时,显示屏熄灭,请及时断开连接




### 给耳机充电

将耳机放进充电盒对齐充电槽位开始充电  
耳机充电时耳机充电盒电量显示屏亮起;充电完成,显示屏熄灭



将磁吸充电器插在USB输出口上,对齐耳机磁吸充电口,即可开始充电



P3

### 技术参数

产品型号:K3  
蓝牙版本:V5.0  
播放时间:10H  
通话时间:10小时  
灵敏度:-90dBm  
信噪比:-42±1db  
信号距离:10米(无任何较大障碍物的理想环境中)  
耳机电池:90mAh  
充电盒电量:500mAh  
充电时间:给充电盒充电约3小时,给耳机充电约1小时

### 安全提示

请尽量避免长时间使用最大音量这可能会损伤您的听力  
请将本产品、配件以及包装盒置于儿童无法接触的地方,避免吞咽、窒息等事故  
用干净的棉布擦拭产品,请勿使用任何化学药剂  
产品应保存于干燥阴凉的环境下,避免尖锐物品划伤  
不要将耳机长时间暴露在潮湿、高温、寒冷、或其他不利环境下  
使用过程中有任何感觉不属实,或者发热发烫的情况下,请立即停止使用  
避免长时间对蓝牙耳机和充电器过度充电  
使用合格的DC 5V/1A充电器为充电器或耳机充电

P4

## 保修条款

1商品售出之日起半个月内,如有发生性能故障,商品本身及外包装保修条款必须保持完整(无  
划伤),可更换同型号的商品,(须经检查)但不包括人为损坏  
2保修服务只限正常使用下有效  
3一切人为损坏、自行拆机、拆封、使用不当、等一切外表的损坏不在保修范围内,此服务不包  
含运输费和上门服务  
注意:当您持保修卡撕毁或丢失时,您已失去了保修机会,我司拥有资料的最终解释权

报修记录:

购买时间:

序号:

维修核实问题:

用户:

维修时间:

发现问题:

经办人:

P5

## 产品合格证


生产批号:

审核人:



# K3

## Wireless Bluetooth headset Double mic call noise reduction Directions for use




Version: 1.0

### Operating functions

- ①: menu  
Turn on: long press for three seconds  
To shut down: hold for four seconds  
Call status:  
Answer/Hang up: Click  
Reject/Hold for two seconds  
Last replay: Double click  
Playing status:  
Click play/Pause
- ②: Volume- key  
Volume- Click  
Next track: Double click  
③: Volume+ button  
Volume+ Click  
Last track: Double click
- ④: Ambient microphone  
⑤: Pick up microphone  
⑥: Magnetic suction  
charging port  
⑦: Charging thimble  
⑧: spare earplug L/S  
⑨: Battery display  
⑩: Magnetic chargers


### Wear

Choose earplugs of appropriate size (the default is medium; Please remove glasses if you wear them.)  
Hang the silicone ear against the cheek and gently hang it along the auricle, adjusting it to fit the back  
of the auricle; Hang the silicone ear against the cheek and gently hang it along the auricle, adjusting it  
to fit the back of the auricle  
Rotate the microphone stick so that the pick-up microphone is facing your lips to ensure clear radio  
Adjust the Angle of the ear hook and microphone stick so that they are securely worn



P1


To wear the microphone on one side, rotate the microphone stick 180° horizontally  
as shown in the following figure, and then wear it on the other side by referring to  
the preceding steps



### Turn on/Off

(Tips: Please fully charge the headset and charging case when using the product for the first time)

Automatic power on/off: Take the Bluetooth headset out of the charging case and the headset will be  
automatically turned on; Put back to the charging case automatically shut down charging  
Manual operation: when the headset is off, long press the menu button for about three seconds and  
then power on; Long press the menu button for about 4 seconds and the headset will be turned off




### Pairing and connecting

Step 1: Take out the Bluetooth headset from the charging case and wait for about 3 seconds. The headset  
automatically starts up and is in the waiting state for pairing  
Step 2: Turn on your phone's Bluetooth switch, search for new devices, and click "K3" in the list to  
complete the pairing

P2


### Charge the charging case

Use the equipped USB A-Type-C charging cable to connect the 5V/1A charger or the USB output port of the  
computer to start charging  
When the charging case is charging, the computer screen lights up; When the battery is fully charged,  
the display screen is off. Disconnect the device in time




### Charge your headphones

Put the headset into the charging case and align it with the charging slot to start charging  
When the headset is charged, the headset charging case power display lights up; After charging  
the display goes out



Plug the magnetic charger into the USB output port and align the magnetic charging port of the headset  
to start charging



P3

### Technical parameters

Product Model:K3  
Bluetooth version:V5.0  
Running time: 10H  
Talk time: 10 hours  
Signal-to-noise ratio: 90 db  
Sensitivity: -42±1db  
Signal distance:10 m (in ideal environment without any large obstacles)  
Charging warehouse power: 500mAhCharge time: charge the case for  
about 3 hours, charge the headset for about 1 hour

### Safety tips

Please try to avoid using the maximum volume for a long time as this may damage your hearing  
Please keep the product, accessories and packing boxes out of reach of children to avoid swallowing  
choking and other accidents  
Wipe the product with a clean cotton cloth. Do not use any chemicals  
The product should be stored in a dry and cool environment to avoid scratches from sharp objects  
Do not expose headphones to humidity, heat, cold, or other adverse conditions for long periods of time  
Please stop using immediately if you feel untrune or get hot during use  
Avoid overcharging your Bluetooth headset and charger for a long time  
Charge the charger or headphones using a qualified DC 5V/1A charger

P4

## Guarantee clause

1. Within half a month from the date of sale of the goods, if there is a performance failure, the goods  
themselves and the outer packaging warranty must be kept complete (no scratches), can be replaced  
with the same type of goods,(must be inspected) but does not include man-made damage  
2. The warranty service is only valid under normal use  
3. All artificial damage, self-disassembly, unpacking, improper use, and all appearance damage are  
not covered by the warranty. This service does not include transportation and on-site service

Note: When you tear or lose the warranty card, you have lost the warranty opportunity, our company  
has the final interpretation of the data

Repair record:

Purchase Time:

Serial number:

Maintenance problem:

User:

Maintenance time:

Identify problems:

Agent:

P5

## Product certificate

No:

Reviewer:



**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.