

## Product Warranty Instructions

In order for you to better enjoy the services of our company, please read the following contents in detail. The warranty service of our products is provided by authorized technical service centers all over the country. This product from the date of sale of the warranty period and the "three guarantees" period of validity, in the "three guarantees" period of validity. In normal condition, if the product fails, it can be repaired, replaced or returned according to the "three guarantees". During the warranty period, the product can enjoy free maintenance service in the authorized technical service center according to the content of this warranty clause (the attached accessories are not within the warranty scope). The warranty period of this product is one year.

In the warranty period (including the "three guarantees" period of validity) the following conditions will be carried out for paid maintenance service, at the same time do not enjoy "three guarantees" service:

- 1) The original valid warranty card and valid invoice cannot be presented.
- 2) The warranty card cannot be completely filled in or altered, such as the date of purchase of the product and the name of the sales unit (the seal is valid).

- 3) Failure or damage caused by irresistible natural disasters.
  - 4) Failure and damage caused in the process of transportation and unloading.
  - 5) Human failure caused by failure to follow the operation method and precautions written in the Product Instruction Manual.
  - 6) Failure caused by disassembly, maintenance and modification of products without authorization of the company.
- Please send the machine together with this warranty card (original) and purchase certificate (copy) to the authorized technical service center, and the transportation cost shall be borne by the user.

## Save and precautions

1. Loudspeakers should be stored in dry and ventilated places indoors, avoid high temperature, humidity and heavy fall, and avoid rain and water when used outdoors.
2. Non-technical skills. Please do not disassemble or repair the machine without authorization: if you have any questions or service needs, please contact the local dealer.
3. Do not insert external audio signals (mobile phones, computers, etc.) from the microphone interface, so as not to cause distortion caused by excessive sound

- amplitude.
4. Turn off the power when not in use.
  5. To ensure the best performance of the amplifier, please:
    - A. Charge the device with A special 10V power charger. (5V charger for wireless transmitter.)
    - B. Use genuine USB flash drive and TF card.
    - C. Do not place too many non-MP3 files in the USB flash drive or TF card. Otherwise, the reading speed of the host may be affected.

## Warning

1. It is strictly forbidden to charge the machine in inflammable and explosive places.
2. It is strictly forbidden to use a charger higher than 10V to charge the machine, in case of serious safety problems caused by lithium batteries.
3. The battery should be replaced by a professional. Do not disassemble or place the battery at will.
4. Do not place batteries near the fire or throw them into the fire.
5. Do not give the battery to children.

## Voice Amplifier with Wireless & Wired Headset Microphone

## E series operation manual

Instructions for frequency loss operation of transmitter terminal of wireless amplifier.

- 一. The red light is on when charging and off when fully charged.
- 二. Head-mounted, Lapel mounted
  1. Open the switch, not successful pairing blue light flashing, open the amplifier pairing success stop flashing, steady on, receive the amplifier, the indicator light also follow steady on.
  2. Plus, minus adjust the volume.
  3. Note, if the pairing is not successful, power off and then on, the transmitter power is insufficient, which will also lead to the pairing is not successful, need to charge in time.

## Operation instructions (Simple functions can be seen on the host panel)


- 一. The keyboard:
  1. Play/Pause: In the play state, press to play/pause, and press to select the loop mode. Press to call up a saved radio station.
  2. Stop: Stop. Under the radio state, press

- the button to search the channel automatically and save the channel automatically.
3. Previous song: Short press the previous song while playing, long press to reduce the volume. Under the radio state, press forward to fine-tune the frequency, and press forward to search the station.
  4. Next: Short press to play the next song long press to increase the volume. Under the radio state, short press backward to fine-tune the frequency, long press backward to search the channel.
  5. Mode conversion: short press to cut off audio source (USB/TF/radio/switch), and long press to select sound effect in playing state.
  6. When the host is charging, the red and green flashing is green when it is fully charged, or the red light when it is fully charged, and the red light when it is fully charged is off.
- 二. Product Specifications function:
    1. Automatic detection USB insertion port automatic play;
    2. Fully compatible with USB 1.1/2.0U disk, play in USB HOST mode; Can be read to 8 gusb;
    3. Support CARD READER, compatible with

- TF/MMC CARD;
4. Support MP3: MPEG 1, 2, 2.5, Layer 3, Bit rate: 1 Kbps-320Kbps;
  5. Loop (one song/all)
- 三. Recording function:
1. Transfer key- MP3 and radio to play the recording file, long press to delete the recording file.
  2. Record button- In the MP3 state, long press to enter the recording mode, record the recording hole (external microphone) and long press again to end the recording content, and then play the recording content in a loop.
  3. In Bluetooth search state, blue blinks and stops blinking after being connected.



Head-mounted



Lapel mounted

## Product warranty card

Please fill in this card carefully and keep it properly when purchasing products.

User profiles:

The user name \_\_\_\_\_

Gender \_\_\_\_\_

Correspondence address \_\_\_\_\_

Zip code \_\_\_\_\_

Contact phone number \_\_\_\_\_

Buy site \_\_\_\_\_

Purchase date \_\_\_\_\_

Product name and specification \_\_\_\_\_

Sales order \_\_\_\_\_

The fuselage serial number \_\_\_\_\_

Dealer's signature \_\_\_\_\_

The user signature \_\_\_\_\_

The dealer is at his disposal

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **RF Exposure Information**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.