


五轮SI说明书

尺寸: 21x28cm


RC THUNDER TUMBLER®/TWIRLING TUMBLER™ SHARPER IMAGE®

6+


OPERATING INSTRUCTIONS



⚠ Carefully remove items from package.




Locate the battery compartment on the back of each item. Swivel latches on bottom of car to release battery pack and insert batteries. Insert 4 AA 1.5V batteries (not included) for car and one 9V battery (not included for remote control).



On/Off Switch




Reverse



Forward



Spinning Action



Action Button



Hold Action Button
While Spinning

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Never operate your car in a confined or crowded area, and do not use your car near people.
- Do not run your car into furniture, objects or hard surface, as this will cause damage to both the object and your car.
- Keep fingers, hair and loose clothing away from the tires, gears and wheels.
- Do not leave car or remote control near source of heat or under direct sunlight for long periods of time.
- Do not use car or remote control outdoors at night. Operation may be harmful to interior components.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this car.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries using the correct polarity.
- Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of properly.
- Do not dispose of batteries in a fire - they may leak or explode.
- Only use manufacturer specified battery(ies), charger(s) and/or accessories.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.
- Keep these instructions for future reference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference from licensed radio stations.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to other electronic equipment.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to other electronic equipment, you may need to take one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

You are encouraged to report any product interference problem directly to the party responsible for compliance with the user's authority to operate the equipment.

The artwork and design of this manual are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without the prior written permission of Sharper Image Corporation. Any use of the trademark or copyright notices on this package is not permitted.

Sharper Image name and logo (including the 77 logo and Tomorrow's Tomorrow) are trademarks or registered trademarks of Sharper Image Corporation. © 2017 MercSource, LLC, Irvine, CA 92618. All rights reserved.

Model Number: 1014812

KEEP THIS INSTRUCTION MANUAL AS IT CONTAINS IMPORTANT INFORMATION FOR FUTURE REFERENCE.

Due to continuous product improvements, the picture on this manual may differ slightly from the actual product.

Printed in China

FOR CUSTOMER SUPPORT, PLEASE CALL

1-800-374-2744