


# User Manual




Celcube Night Light Bluetooth Speaker

## User Manual

Thank you for choosing us. Please read this user manual before using the speaker.

### Operation Image:



Material	ABS+METAL
Lamp Power	1.8w
Lumens	160lm
Color	Warm white
LED Size	2838
Battery Union	3.7V
Speaker output power	3W
Driver	0.5inch 40mm 3W
Frequency Response	50HZ-20KHZ
Transmission Range	10 meter
Product dimension	Ø95mm*122mm
Audio Input	3.5mm audio
Frequency	2.4 GHz/2.4GHz
Input power	Input DC5V/500mA

### Playing time after fully charged:

10 hours music playing for normal 70% volume, 20 hours lighting lamp on highest brightness

#### Power switch:

Long press the button to turn it on or off. The speaker will enter Bluetooth Mode. After the blue light will be on by soft touch. Bluetooth Mode will instantly switch when click the MODE button icon. TF Card Music Playing will automatically switch when inserted TF card. Voice prompts will sound before bluetooth pairing and TF card music playing.

#### Button icon:

1.Mode icon: achieve bluetooth mode and TF Card music playing, lighting mode changing freely

#### 2.Bluetooth music mode:

Short press "  $\text{M1} + \text{M2}$  " to play the next song and long press to volume up.

Short press "  $\text{M1} - \text{M2}$  " to play the previous song and long press to volume down.

#### 3.Handset mode:

Answer and hang up the phone

There will be an alert sound from the speaker when there is a phone call. Click "  $\text{M1} \text{ M2}$  " to answer the call, and click "  $\text{M1} \text{ M2}$  " again to hang up

#### 4.TF card music playing:

Enter TF card music playing mode automatically when TF card inserted

Short press "  $\text{M1} + \text{M2}$  " to play the next song and long press to volume up

Short press "  $\text{M1} - \text{M2}$  " to play the previous song and long press to volume down.

Music playing or pause click

Bluetooth pairing will automatically click the MODE button when on TF card music playing mode

#### 5.AUX IN audio input mode:

Inserting the 3.5 mm aux in cable, the speaker can be a external audio when connected with mobile phone, PC, tablet, etc.

Music in audio input mode: "  $\text{M1} + \text{M2}$  " to volume up;"  $\text{M1} - \text{M2}$  " to volume down;"  $\text{M1} \text{ M2}$  " For the mute button.

In any mode when inserted 3.5 mm audio in cable, the speaker self identified and automatically switch to audio in input mode

#### Indicator light:

1:Bluetooth indicator:

The Bluetooth indicator light will flash rapidly when in pairing state the blue light flash slowly means bluetooth connected, the speaker enter bluetooth music playing.

#### 2.TF card music playing indicator:

The speaker enter TF card music playing when blue indicate light flash in TF card playing mode

#### 3.Charging:

1. Please make sure the speaker is fully charged in first use. Charge the speaker with the provided USB cable and connect with any computer or cell phone's USB output charger. The charge indicator light will be red while charging, then when the battery is fully charged it will turn off.

2.Charge time about 4 hours

#### 4.Bluetooth connection:

This speaker supports the bluetooth device with A2DP function. Slide the power switch first, then enter bluetooth mode,blue light and blue flicker alternately,together with voice prompts, the speaker is in pairing state at this time, and only in this time, the bluetooth can be paired and connected successfully.

#### 2.Mobile phone connection:

Step 1:Open the Bluetooth setting on your phone or tablet and click "search device". Iphones will search for Bluetooth devices automatically.

Step 2:Find the speaker when the screen display the character "BT-SPEAKER", click on it in your device to pair the connection.

Step 3:Enter "0000" and click OK. There is a prompt that requires you to enter a password.

Step 4:Enter the password and click the pairing icon when the pairing is successful. The character on the display of the speaker will stop flickering.

#### 3.Computer connection:

Activate the bluetooth function first if the computer has bluetooth device. It's necessary to install the bluetooth driver, then connect the bluetooth adapter when there is no bluetooth available.

Step 1:Click the Bluetooth icon at the lower right the computer by mouse right button, choose "device adding".

Step 2:Bluetooth adapter will search for the speaker automatically, and the screen displays the character.

Step 3:The computer will install the driver automatically after double click the character "BT-SPEAKER", and display driver is successfully.

Step 4:Double click the Bluetooth icon, the speaker connects the computer successfully and be in use. Please check the computer audio device has switched to bluetooth mode or connected well if the speaker still can not play music successfully.

#### Bluetooth pairing and connection:

1. If the speaker has been connected with Bluetooth devices before, it will connect with the last Bluetooth device

automatically once it turned on.

2. If the speaker has not been connected with Bluetooth devices before, it will enter pairing mode, click connecting is achievable.

3. Other phone or tablet can not be connected with the Bluetooth speaker when the speaker is being connected with a phone or tablet.

4. The phone or tablet can not be connected with the Bluetooth speaker if it is connected with other Bluetooth devices. You should turn off your Bluetooth connection and connect your phone with the Bluetooth speaker again.

#### Lamp function

Long Press the button to turn it on. Turn on the light by tap the mesh on the top, and the lamp will light on in the dimmest grade one. The brightness can be adjusted by tap the top mesh, and there are 3 brightness grades low brightness, medium brightness, and high brightness. Turn off the light by tap the mesh on the top, and the light will be off in any mode. Long Press the mesh on the top, can switch between the warm light and modes of lights, lights mode turns to red, blue, green, purple, breathing, rhythm of the lamp for circulation. Can follow music and play with the rhythm.

#### Frequency Asked Questions

Questions	Solutions
1.Unsuccessful pairing and connection repeatedly.	1. Check the speaker and make sure it is in the searching state or reboot the speaker. 2. Connection is difficult when there are too many Bluetooth devices nearby. Turn off other Bluetooth devices.
2.Connection is difficult when there are too many Bluetooth devices nearby.	1. Turn off other Bluetooth devices. 2. Turn off the speaker first, and reconnect the speaker.
3.Muted or distorted sound	1. Check the volume of your phone or the speaker, and adjust the volume. 2. Turn the speaker to the low. Please change the volume.
4.Cheesy music play	1. Check the speaker and the phone. Adjust the connection distance. 2. Check if there is any obstacle between the speaker and your device.
5.The speaker not showing in Bluetooth mode	1. The battery is low. Please charge it. 2. Please reboot the speaker.
6.Low power continuous beep	1. Please recharge the speakers.

FCC warning:

1. This device should be installed and operated with minimum distance 20cm between the radiator&your body.
2. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
4. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
5. The devices must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the product. ,