


Wireless Security Camera

180-Day Battery Life
Indoor & Outdoor

*Mounting Tips


This is an adjustable indoor/outdoor camera. For outdoor use, please mount the camera vertically upward to avoid rain or snow getting in the device. We recommend to mount the camera less than 16 feet above the ground (*alarm system won't be triggered above this height).



IN THE BOX




VIRTAVO Camera*1




USB Cable*1




USB Adapter*1



Screw Kit*1



Quick Start Guide*1



3M VHB Sticky Adhesive Pad*1



Nut*1




Round Adapter Plate*1




Camera Mount Holder*1

PRODUCT OVERVIEW



- Lens
- Indicator light
- Microphone
- Light sensor
- PIR sensor



- Battery status light
- Sync button
- MicroSD card slot (MicroSD card not included)
- USB slot
- Power button

SETTING UP THE SYSTEM

1.Download the Home V app and create an account.



2.Switch the power button on to wake up the camera.


3.Press the Sync button for about 5 seconds until you hear a 'Du' sound with the red light flashing.

4.Go to the Home V app, then add your device by tapping on the '+' button; follow the app instruction to finish the setup process.

MOUNTING THE CAMERA


Step 1

*Option 1A




We recommend you use a 1/4 inch drill bit to drill holes on the wall, then insert the provided anchors. (Anchors are necessary for walls that are made out of hard materials such as concrete, brick, or stucco.) Mount the round adapter plate on the wall with two screws.

*Option 1B




To install the camera on smooth surfaces, you can peel off one film from the double-sided sticky adhesive pad, then directly stick it on the round adapter plate; peel off another film and stick the round adapter plate on the surface.

Step 2




Place the nut onto the round adapter plate.

Step 3



Firmly press the camera mount holder onto the round adapter plate, then rotate the nut clockwise to the camera mount holder.


Step 4



Vertically place the camera upward on the camera mount holder, then rotate the camera 90 degrees clockwise to tighten it; To adjust the camera viewing angles, you can check the live stream feed in your Home V app and loosen the nut to help adjust.

*PIR sensor is designed to detect people, pets & other warm moving objects. Putting the sensor in a wrong location can lead to blind spots and false alarms, so it's important to place the camera near where the sensor is clear of obstacles.

CHARGING



Battery status light	Charging: Steady Red
	Fully Charged: Steady Green
Charging time	7-8 hours(0-100%)

SAFETY STATEMENT

FCC Statement

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to connect the interference by one or more of the following measures: (1) Reorient or relocate the receiving


antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.


FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

 This product is designed and manufactured with high-quality materials and components, which can be recycled and reused.

 This symbol means the product must not be discarded as household waste and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling help protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1)this device may not cause interference, and
(2)this device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1)l'appareil nedit pas produire de brouillage, et
(2)l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est confome à la norme NMB-003 du Canada.

IC RF Statement

When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements. Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.

LIMITED ONE YEAR WARRANTY

PUWELL CLOUD TECH LIMITED warrants this product to be free of defects in materials or workmanship for one year. This warranty does not include damage resulting from accidents or misuse. Damage from unauthorized service or modification of the product or of any furnished component will void this warranty in its entirety. This warranty is expressly in lieu of all other warranties, expressed or implied, including any warranty, representation, or condition of merchantability or that the products are fit for any particular purpose or use, and specifically in lieu of all special, indirect, incidental or consequential damages. To obtain service/replacement, please contact homevservice@virtavo.com. Please allow up to seven (7) business days for your replacement to be processed.

CUSTOMER SERVICE

Contact us

✉ homevservice@virtavo.com

📞 @ HomeVIRVATO

📺 @ HomeVIRVATO

Please download the Home V app from Google Play or Apple App Store.

