

1.字体颜色: 黑色 Pantone Black 3 C
橙色 Pantone 1505C

2.单页尺寸: 140x144mm, (七折页) 展开尺寸: 980x144mm
3.材质: 128G双铜, 双面彩色印刷

折页首页

Smart Pet Water Dispenser User Manual WiFi Edition

Please read the instruction manual carefully before using the product

Safety Guide

1. It is not recommended to use this device for pets under three months old.
2. When children use this product, please use it under the accompany of their parents.
3. Do not immerse the charging base in water, as this will damage the control panel and other electronic components.
4. Please keep the device placed horizontally; do not tip it over to avoid damage.
5. If this device malfunctions or has damaged accessories, do not attempt to repair it yourself. Please contact your dealer or customer service for resolution.
6. When not using the product or before cleaning it, please be sure to unplug the power cord.
7. If the device's power plug gets wet, please turn off the power at the socket and do not attempt to unplug the power plug.

Notice

1. Before first use, please clean the product. For cleaning guidelines, refer to P10.
2. It is recommended to use purified water to extend filter life and maintain water quality.
3. The normal operating ambient temperature for this device is 0 ~ 40°C. Do not place the device in direct sunlight or areas where the ambient temperature is not suitable.
4. Do not allow pets to chew or swallow any accessories. If you are concerned about the power cord, please purchase a cord protector (hard plastic protector) from a hardware store to protect it.
5. If you encounter product usage issues, please contact your dealer or customer service for resolution. Do not attempt to disassemble or modify the device yourself, as this may cause safety accidents.
6. When traveling or on a business trip for an extended period, please be sure to check the remaining water level in the device.
7. Please read and comply with all important instructions listed on the device and packaging.

Packing List

After opening the product packaging, please confirm that the pet device is intact and check the checklist to ensure all accessories are complete.

Water Tank	Accessories
	<ul style="list-style-type: none">① Water Outlet Pipe② Power Adapter③ Power Cord④ Water Pump⑤ Filter Element⑥ User Manual

*In order to provide better products, we will regularly improve our products. If the product image is different from the actual product, please refer to the actual one.

Product Image

Front View: Shows the device with a water tank, pump, and filter element. Labels: Drinking Tray, Water Outlet Pipe, Filter Element, Water Pump, Water Tank, Charging Base, Anti-slip Mat.

Bottom View: Shows the base of the device. Labels: Water Tank, Anti-slip Mat.

Button Instructions

Power Button:
1) Long press the button for 4 seconds; the device will beep twice and power on.
2) Long press the button for 4 seconds; the device will keep twice and power off.
3) 15 seconds after work ends, the device will automatically enter low power mode. In this mode, long press any button to wake up the device.
Note: Connecting the power adapter can also wake up the device.

Cleaning & Filter Replacement:
1) Cleaning Reset: Double-click the button; the device will beep twice, indicating successful cleaning reset.
2) Filter Reset: Double-click the button; the device will beep twice, indicating successful filter replacement reminder reset, and the filter replacement reminder countdown will restart.
Note 1: If both cleaning and filter replacement reminders appear simultaneously, double-click the reset button, the device will first reset the cleaning reminder, and then the filter replacement reminder.
Note 2: The cleaning reminder countdown starts after resetting on the device, defaulting to a reminder after 7 days (cannot be set to 7-30 days).
Note 3: The filter replacement reminder countdown starts after resetting on the device, defaulting to a reminder after 30 days (can be set to 7-30 days).
Note 4: After the filter replacement reminder is reset, the filter replacement reminder will restore to default values.
Note: When battery-powered, network pairing is suspended within 5 minutes of first power-on.

Indicator Light Color	Indicator Light Signal	Device Status
White	Flashing: Battery Powered/Device On/Off Intermittent: Network Connection Failed/Device Network Connection Solid On: Device Normal/Network Connection Successful/Charging Complete	When set to the front of the device, the device dispenses water for 30 minutes.
Yellow	Flashing: Water Shortage Reminder Solid On: Low Battery	When connected to power adapter, only applicable when connected to power adapter. When connected to power adapter, the device will dispense water for 30 minutes.
Red	Flashing: Smart Mode Solid On: Device is charging	When set to the front of the device, the device dispenses water for 30 minutes.

Note: When the device malfunctions, water shortage reminder, filter replacement reminder, cleaning reminder, the AIO will push anomaly alerts.

Factory Reset:
Long press the button for 4 seconds; the device will sound for 4 seconds, the device will restore factory settings, network pairing information will be cleared, and water dispensing mode, cleaning reminder, filter replacement reminder will restore to default values.
Note: When battery-powered, network pairing is suspended within 5 minutes of first power-on.

Installation Instructions

01 | Cleaning the Device
① Remove relevant accessories and clean the drinking tray, filter tray, water tank, etc., with clean water. When cleaning, do not let water contact the charging base; wipe with a cloth or wet wipe.

02 | Installing the Water Pump
① Place the filter tray onto the water tank.

04 | Install the Filter Tray
① Place the filter face up onto the filter tray.

05 | Install the Water Pump
① Place the concave part at the bottom of the water pump with the cotton filter with the protrusion at the water pump installation position in the water tank.

06 | Install the Drinking Tray and Water Outlet Pipe
① Place the drinking tray onto the filter tray, then attach the water outlet pipe, and finally align the hole at the bottom of the water tank with the anti-misinsertion slot on the charging base.
Note: If the water tank is not aligned, it will protrude and be unstable after installation.

07 | Plug-in Use
① Place the assembled device on a level surface, and finally power the device with a DC5V power adapter.

折页尾页

Maintenance Instructions

1. For your pet's health, it is recommended to clean the device regularly.
2. When the water tank begins to get dirty and has slippery timescale, it is recommended to clean it.
3. It is recommended to clean the water tank, water pump, and filter element once every 7 days.
4. The filter element needs to be replaced regularly, recommended not to exceed 30 days.

Instructions for Use

01 | Assembly
① Complete water filling and assembly of the device according to the installation instructions.

02 | Connect Power
② Connect the 5V/1A power adapter to the device and plug it into an outlet; the device will automatically power on.

03 | Device Network Pairing
③ For details, please refer to the Smart Life APP Download and Operation Guide below.
④ Use your mobile phone to scan the QR code above to download the APP, and log in.
⑤ Enter the APP homepage, click "Add Device".
⑥ Enter the device search page, automatically search for devices, then click on the device you want to add.
⑦ According to the search results, click "Add Device".
⑧ Enter the 2.4GHz Wi-Fi connection settings, enter the password, then click "Next".
⑨ Enter the device connection page, automatically search for devices, then click "Add Device".
⑩ Enter the "Device Cleaning" page to set the filter replacement time.
⑪ Enter the "Device Cleaning" page to set the device cleaning time.
⑫ Enter the "Settings" page to manage information notification settings.
⑬ Enter the "Settings" page to manage information notification settings.

Simple Troubleshooting

Problem & Solution

Q1: Can I wash the button part with water when cleaning the device?
A: No, the button part contains precision instruments internally and cannot be directly immersed in water for cleaning. If it encounters water droplets or slight splashes, wipe it dry immediately.

Q2: How do I know if the device battery is running low?
A: You can check the device indicator light. When the indicator light turns red and flashes quickly, the device needs to be charged.

Q3: How do I know when the device can start network pairing after Wi-Fi is turned on?
A: You can check the indicator light. When the indicator light is flashing white slowly, the product is in network pairing mode. At this time, you can search for the device via the relevant APP to perform network pairing.

Q4: Can I control the device using the APP when it's battery-powered?
A: Yes, but you need to wake up the device first (long press the power button for 1 second or plug in the adapter to wake up the device), otherwise any commands from the APP will be invalid.

Q5: Why doesn't water dispense immediately when my pet is near the device?
A: The pet needs to be directly in front of the device's water outlet, and within the sensor's detection range. Data needs to be transmitted for analysis, so there is typically a 1-3 second delay.

Q6: Why does water dispense when a person walks past or approaches the device?
A: This sensing function does not differentiate between living species; it is effective for any moving object.

Q7: Why is there still water in the tank, but it's not dispensing?
A: The water pump has a certain height. If the water level is too low, it cannot cover the lowest water level of the pump. Therefore, please ensure the water level covers the entire pump when using.

Q8: Can I use another adapter to charge my device?
A: To ensure the safety and effectiveness of electronic components, our device's input specifications are limited to 5V/1A. It is recommended to use the original adapter for charging.

Cleaning Instructions

01 Before disassembling for cleaning, please remove the device from the charging base.

02 Water Pump Cleaning and Charging Base Wiping
① Step One: Remove the filter cotton and detach the outer cover on the side of the water pump.
② Step Two: Use tweezers to remove the impeller; disassemble the water pump according to the steps below, then clean it.
③ Step Three: Use a brush to clean the water pump with the filter element, rinse briefly with clean water and shake dry.
Note: The bottom of the impeller is a magnetic structure; align it with the central shaft during installation.

03 Charging Base Wiping
④ Remove the water outlet pipe and drinking tray, water tank, etc., in clean water and clean with food-grade detergent.

04 Remove the water outlet pipe and drinking tray, water tank, etc., in clean water and clean with food-grade detergent.

05 Rinse the water tank, drinking tray, filter tray, water outlet pipe, etc., in clean water and clean with food-grade detergent.

Daily Water Refill Instructions

01 | Assembly
① Remove the assembled device tray assembly from the water tank.
② Hold a container and add purified water (3L).
Note: Do not exceed the MAX line.

02 | Cleaning
③ After adding water, clean the device tray assembly with a cloth or wet wipe.

03 | Wiping
④ Wipe the surface of the charging base with a cloth or wet wipe.

04 | Drying
⑤ After wiping, ensure the device tray assembly is completely dry before reassembling it into the water tank.

05 | Reassembly
⑥ Reassemble the device tray assembly into the water tank.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.