

USER MANUAL



Operation without remote control:

Long press "Ⓢ" ① 1.5S to turn on/off and the product will be in standby mode. When it is powered on, short press "Ⓢ" ① to switch among 10 vibrations.

Operation with remote control:

Long press "Ⓢ" ① 1.5S to turn on/off.

Short press "Ⓢ" ② to switch among 10 modes and short press "Ⓢ" ③ to pause vibration when operating with remote control.

Note: The light flashes while charging and it will be on when fully charged.

SPECIFICATION

Material :	Silicone
Size :	120x92MM
Function :	10 mode vibration
Charging time :	90mins
Using time :	60mins
Waterproof :	IPX7
Remote control distance :	10 Meter

PRODUCT DESCRIPTION

The sensory curved shaft provides G-spot stimulation of knee shaking, while the butterfly base ensures external teasing. No matter when and where, this unique wearable vibrator can stimulate your going in and out.

SAFETY

1. Don't share it with others for your health.
2. Stop using it if you feel uncomfortable.
3. Stop using it if you find the head of the product is not smooth enough or broken.
4. Keep it from children's reach.

CLEANING AND STORAGE

1. Please clean it thoroughly before and after using.
2. Warm water and medicinal alcohol can be used to clean this product, but warm water is highly recommended.
3. Please Naturally air dry and avoid direct sunlight.
4. Please Store it in a dust-free place.

ATTENTION

1. Please charge it before using.
2. Please use good quality personal lubricant. Something (Massage oil, hand cream or cleaning solution etc.) containing hazardous substances cannot be used as lubricant.
3. Once the battery has been fully charged, unplug the toy's DC plug.

12X7cm

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.