


Bladeless Fan



SKJ-CR101P, SKJ-CR101PL, SKJ-CR101FP, SKJ-CR101FPL,
SKJ-CR101, SKJ-CR101L, SKJ-CR101F, SKJ-CR101FL,
SKJ-CR100P, SKJ-CR100PL, SKJ-CR100FP, SKJ-CR100FPL,
SKJ-CR100, SKJ-CR100L, SKJ-CR100F, SKJ-CR100FL

Please read carefully before using the product and keep it properly

1: Precautions



warn

To avoid fire, electric shock, personal injury

Be sure to comply with the following requirements

Others, please follow the relevant national and local electrical regulations

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

2. Please use a separate outlet according to the current / voltage of the fan. Do not use a multi-purpose socket for simultaneous use with other electrical devices.

3. If the fan does not work due to a damaged power cord, turn off the power and ask a qualified person for repair.

4. Do not move the fan when you pull the plug out of the socket.

5. Do not pull out the plug by the cable. Pull out the plug and do not grip the cable.

6. Do not operate the fan with a damaged cable or connector. Please contact customer service to replace or repair the cable if the cable is damaged.

7. Do not stretch or energize the cable. Keep the cable away from the heat source.

8. Do not run the cable under carpets, do not cover it with carpets or similar covers. Route the cable outside the traffic area to avoid tripping the cable.

9. Turn off all controls before pulling the plug and pull the plug out of the socket if you are not going to use the device for a long time.

10. Do not place any objects on the air inlet or outlet. Make sure that the ventilation openings are free of dust, lint, hair and other obstacles that could impair the air flow.

11. The fan should be set up dry on a horizontal platform and should not be near heat sources, corrosive air and moisture. The fan should be kept a distance of 150 mm around to ensure good air circulation.

12. Do not use the fan outdoors or on a wet surface.

13. Do not immerse the fan, power cord, or plug in water or other liquids to avoid danger. The use of an extension cord is not recommended unless it has been tested by a qualified person.

14. Please do not use an air cleaner or similar product right next to the fan.

15. Do not use any cleaning agents or lubricants for this fan and pull out the power plug before cleaning, transporting and servicing the device.

16.The appliance is only to be used with the unit provided

17.If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person to avoid a hazard.


Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2: product description




 The pictures in the instruction manual are for reference only, and the actual product in the box shall prevail.

Basic parameters


product name	Bladeless fan	Product number	SKJ-CR101
Rated voltage	12V DC	Air volume gear	4th gear
rated power	24 W	Timing	1-4h

3: Remote control function introduction




When using the remote for the first time:

- 1: Connect the fan to the power supply first;
- 2: Then long press the remote control timing button for 5 seconds to pair the remote control with the fan;
- 3: After the pairing is successful, the fan will beep three times.

 On standby	When the host is in the standby state, press the on-standby button to start the operation; When the host is in the running state, press the on-standby button to stop running and enter the standby state.
 Plasma	Press this button to turn on the plasma, the green light on the display flashes twice, and the fan makes two beeps; Press it again to turn off the plasma, and the fan will beep twice. Plasma can purify the air.
 Air volume key	Press the "+" button on the remote control, the fan air volume will increase, Press the "-" button on the remote control, the fan air volume will decrease.
 shaking his head	Press the shaking button on the remote control to achieve 1 to 4 shaking angles. (The shaking angle is 30 degrees - 60 degrees - 90 degrees - 110 degrees - off, cycle in turn)
 Ambient Light	Press the ambient light button on the remote control to adjust the brightness of the light from 1 to 4 levels. When pressing the 5th time to turn off the ambient light, the fan makes two beeps.
 timing operation	Press the timer button on the remote control to realize the timer standby function of 1 to 4 hours. Press once for 1 hour, press again for 2 hours, and so on; Press the 5th time to cancel the timer, and the fan will make two beeps.

4: Installation location description



Installation location

Please place the fan in a horizontal position, please do not place the fan in an unstable place, such as a slope, with a soft surface to prevent the fan from falling over and causing damage or failure.

During use, it is necessary to avoid blocking the air inlet. Please use it away from the place with curtains to avoid objects blocking the air inlet and causing the fan to fail to work.

Do not place objects within 30 cm in front of the air outlet to reduce the blowing effect of the fan.

5: Display touch operation instructions



When the fan is connected to the power supply and enters the standby state, the display (above) will run a circle and display the screen after 20 seconds.

On standby operation:

After the fan is connected to the power supply, tap the display to start the fan;

Press and hold the display screen for 2 seconds in the running state, the display screen will be off, and the operation will be stopped.

Air volume gear:

Press the display screen, the fan 1-2-3-4 will cycle in turn, and the screen will turn off after 20 seconds when there is no operation.

Shaking operation:

Press and hold the screen for 1 second to turn on the shaking head, and press and hold the screen again for 1 second to turn off the shaking head.

(The shaking angle can only be set by the remote control)

Display gear map (below):

(air volume gear, timing time, shaking gear)



1st gear

2nd gear

3rd gear

4th gear


6: How to install battery

Before using the remote control

Insert the batteries into the remote control before using it.

How to install battery

- 1: Open the battery cover of the remote control;
- 2: Insert two new AAA (No. 7) dry batteries;
- 3: Close the battery cover of the remote control.



Note: Please insert the battery with the correct orientation.

※If the remote control is not used for a long time, please remove the battery.

Follow local ordinances or regulations when disposing of used batteries.

7: Care and Maintenance

When performing maintenance, be sure to unplug the power supply first.

During maintenance, please do not soak or splash water on the fan, it may cause the machine to get water and damage it.
Please do not use banana water, gasoline, alcohol, bleach or metal objects to wipe the fan surface, which may cause the fan surface to discolor and deteriorate.

object surface

Please gently wipe the fan surface with a dry soft cloth;

If the surface of the fan is dirty, it can be diluted with neutral detergent and then wiped with a soft cloth;

On the fan surface, wipe it clean and then wipe it with a dry soft cloth.

air inlet air outlet

Please use a soft brush or a vacuum cleaner to clean the dust at the air inlet and outlet. Too much dust may affect the use of the fan. Please clean it in time when there is less dust.

remote control

Please wipe the surface of the remote control lightly with a dry soft cloth.

If it will not be used for a long time, please remove the button battery inside the remote control.

Power Adapter

Please clean the power adapter with a dry soft cloth.


How to keep

The fan can be put in a plastic bag after maintenance.

Please avoid places with vibration and electrical appliances with cooling/heating function;

Please avoid placing it in direct sunlight, high temperature and humidity;




Please keep it out of the reach of children.



8: Aromatherapy function (optional)

This product can be added with aromatherapy liquid, and the aromatherapy gas can be blown out with the operation of the fan.

How to add aromatherapy liquid:

	
1: Move the decorative cover outwards (as shown in the picture), and remove the decorative cover;	2: Take out the aromatherapy tank upwards;
	
3: Aromatherapy liquid is added to the sponge in the tank;	4: The aromatherapy tank is installed in the fan, and the decorative cover is closed.

9: Charging function (optional)


This product has a charging function and can run for about 150 minutes in a fully charged state.

1. When it is detected that the remaining power is less than 10%,
Green light on the display every five minutes (as shown in the picture)
Flashes three times, the fan makes three beeps,
until low power shutdown.
2. When the fan is in the standby charging state, the display will light up green, and the screen will turn off after 5 minutes of charging.



3. Power display:

How to replace the battery:



- 1: Move the decorative cover outwards (as shown in the picture), and remove the decorative cover;
- 2: Take out the fixing piece with a Phillips screwdriver;
- 3: The fan tilts to take out the battery;
- 4: Put back the new battery and install the fixing plate, then cover the decorative cover to complete the installation.