


ENJOX

Yami

User Manual



- ① Charging Port
- ② Indicator Light
- ③ Button
- On/Off
 - (hold for 3 seconds)
 - 2 power on vibrations
 - 1 power off vibrations
- Vibration
 - (one tap to cycle through preset vibrations)

Package List

- 1 * Bluetooth Bullet Vibrator
- 1 * USB Charging Cable
- 1 * User Manual
- 1 * Quick Setup Guide
- 1 * Storage Bag

Specifications

Materials	Body-Safe Silicone
Battery	Li-Ion Rechargeable
Charging	70 Minutes
Use Time	up to 210 Minutes
Standby	up to 120 Hours

Charging

Turn off the device before charging. The cable can be plugged into any USB port or USB/AC power adapter to start charging. It will take approximately 1.5 hours to fully charge.

Push the pin firmly, but slowly into the charging port. Stop pushing when you see the indicator light glow.

The Indicator light will stay on while charging. Once it fully charged the solid red light turn off. If you're unsure whether it's fully charged, you can view the battery indicator in the app.

Reminder

Under no circumstances should you use Yami anally. We take no responsibility if used anally. Yami is not designed for anal use. It does not have a flared base and may be hard to remove when inserted anally. Not only is it dangerous, but anal use voids the warranty. If you are interested in an anal toy, you are recommended to shop for our anal plug products.

Warning

DO NOT boil in water (the battery may explode or water could leak into the toy).

Keep away from extreme heat or cold.

Make sure your toy is recharged at least once every six months.

DO NOT use the toy while charging.

Cleaning & Care

Clean your device before and after each use.

Clean with warm water and a mild soap (or a sex toy cleaner).

Dry thoroughly before storing.

Lubricant

To avoid issues, **only use water-based lube**. DO NOT use silicone or oil-based lubricants.

Before insertion, generously apply lube to the product and yourself.

Water based lube may dry out, so you may need to reapply.

App

You can find out **Enjox Remote** in Apple App Store or Google Play Store.

Or check out the download links here. Our software gets constantly updated.

App download:

www.enjox.com/sex-app/download

If you have any feedback or need any additional assistance, use the contact form at www.enjox.com/contact . Someone from the Enjox team will normally reply within 12-24 hours.

Warranty Terms & Conditions

ENJOX warrants this product for a period of ONE (1) YEAR, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a defect and notify ENJOX during the warranty period, ENJOX will, at its discretion, replace the product free of charge.

The warranty covers product parts but does not cover appearance damage caused by accident, misuse or use other than as intended. Disassembling the product will void the warranty.

Visit www.enjox.com/warranty for detailed warranty and product return information.

FAQs

1. Toys cannot be searched in Enjox Remote app.

Please add and search for toys directly in Enjox Remote app. DO NOT search for toys and pairing in the Bluetooth settings of your phone.

2. Automatic disconnection after connecting the toy.

Please close the Enjox Remote app and reopen it.

3. Long-term unused, unable to turn on the power.

You need to charge it. We recommend charging at least every 6 months.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.