

PANEL DESCRIPTION

- 1.POWER/VOLUME;
- 2.LED;
- 3.INPUT AUDIO;
- 4.DCIN 5V;
- 5.USB/TFCARD;
- 6.PREV/REC;
- 7.PAUSE/PLAY.TWS;
- 8.NEXT/M.PRI;
- 9.MODE/LED POWER;
- 10.ECHO;
- 11.MIC.VOL;
- 12.MIC.IN;
- 13.DIGITAL MP3 PLAYER;

USE INSTRUCTION

- 1.Connect the sign power cables according to the back panel connection instruction;
- 2.To sure the correct the Voltages, insert power cable, turn on the power switch button;
- 3.Adjust function keys to your satisfied best sound effect;

PRODUCT EQUIPMENT LIST

1.Speaker;	2.Power cable;
3.Remotecontrol;	4.User manual;
5.Wired mic;	

IMPORTANT SAFETY MEASURES

Before using this machine, please read all the safety and operating instructions meanwhile, please observe all the indications about safe operation;



- 1.Protection of electric power cable :Be aware of the electric power cable and outlet on the machine DO NOT lengthen the electric shock. DO NOT pull or drag the power supply line;
- 2.Ventilation :The speaker must be put in ventilated place DO NOT put disk on it or cloth to cover it the distance away from the wall should not be less than 10 centimeters DO NOT put this set on the bed;
- 3.Case Dismantling:DO NOT dismantle the case if one touches the inner components, he will probably get serious electric shock;
- 4.Unusual smell when you find unusual smell and smoke, cut power supplies immediately and pulls out the plus from the outlet on the wall Contact the sell shop or nearest repairing center;


Attention: This speaker applies to AC 110~220V 50Hz-60Hz power supply Use standard power supply, Please be sure for the correct power supply before use it;

PRODUCT FEATURES

- 1.High output power;
- 2.With Karaoke function;
- 3.The treble is clear, natural and bass is powerful;
- 4.Compatible to DVD/VCD/CD/TAPE/Audio/MP4/AUX;

REMOTE CONTROL

- 1.Standbystate;
- 2.Mode conversion (Media player/AUX/FM) ;
- 3.Mute;
- 4.Play/pause in video mode, for FM mode, to the next channel with short press. for FM mode, automatic search channel with one press. the channel will automatic saved in the system;
- 5.(fast rewind) for FM mode, previous song with short press, for FM mode, manual search channel;
- 6.(fast forward) for audio. short press. for FM mode manual search channel forward which has signal with long press;
- 7.For audio mode, change EQ adjustment with short press;
- 8.Vol - volume reduce;
- 9.Vol + volume increase;
- 10.Repeated a song in audio mode;
- 11.USB/SD;
- 12.0-9 Directly select the channel which has saved in the system Already;



CAUTION

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF WARNING FOR PORTABLE DEVICE

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.