




Remark : The EUT and the transmitting antenna are in the center of the turntable. The distance between the EUT and the receiving antenna is 3m.



Remark : The EUT and the transmitting antenna are in the center of the turntable. The distance between the EUT and the receiving antenna is 3m.