



EN
The device is safe to use as long as it is used correctly and in accordance with the instructions given in this user manual. Proper use also includes compliance with the Quick Start Guide and the warnings listed here. Risk of injury due to fire/inflammation! Do not extinguish the product with water. Do not throw the product into fire.

DE
Das Gerät ist sicher im Gebrauch, sofern es ordnungsgemäß undentsprechend den Anweisungen in dieser Bedienungsanleitung verwendet wird. Zur bestimmungsgemäßen Verwendung gehört auch die Beachtung des Quick Start Guide sowie der hieraufgeführten Warnhinweise. Verletzungsgefahr durch Brand/Entzündung! Lösche das Produkt nicht mit Wasser. Wirf das Produkt nicht ins Feuer.

CN
请遵守并根据本说明书中的说明操作,即可轻松使用该产品。正确使用还包括遵守快速入门指南和此处列出的警告。由于火灾/着火造成的受伤风险!不要用水扑灭产品。不要将产品扔进火中。

J
当取扱説明書の規定および指示に従って使用することで、製品の安全性を保持することができます。正しいご使用のために、本文書の注意事項やクイックスタートガイドを参照してください。火災/炎上による負傷の危険性!水での鎮火はしないでください。製品を火に投げ入れないでください。

 **Charging / Laden**
充电 / 充電

 **Flashing light: battery is charging**
Blinken: Akku lädt
闪烁: 电池正在充电 / 点滅: 充電中

 **Light on: battery is charged**
Leuchten: Akku geladen
亮起: 电池已充电 / 点灯: 充電完了



1-2h




2h


 **On & off / An & Aus**
开&关 / オン&オフ

 3 Sec




Continuous use
Dauereinsatz
連続使用 / 連続使用 >1h






Use / Benutzung
使用 / 使用



Cleaning / Reinigung
清洁 / クリーニング



Storage / Lagerung
存放 / 保管



EN
Do not use the toy on irritated or damaged skin. Stop using the toy if you experience pain or feel unwell during use. Do not use the toy if it is:

1. unusually hot.
2. damaged or deformed.
3. discoloured.

DE
Benutze das Toy nicht bei gereizter oder verletzter Haut. Brich die Anwendung ab, falls während der Anwendung Schmerzen und/oder Unwohlsein auftreten. Nimm das Toy nicht in Betrieb, wennes:

1. ungewöhnlich warm ist.
2. mechanisch beschädigt oder deformiert ist.
3. verfärbt ist.

CN
不要在受刺激或受损的皮肤上使用本玩具。如果在使用过程中发生疼痛和/或不适, 请取消使用。在以下情况下不要使用玩具: 1. 温度异常, 2. 玩具损坏或变形, 3. 变色。

J
過敏であったり傷ついた肌におもちゃを使用しないでください。使用中に痛みや違和感を感じた場合には使用を中止してください。次の場合にはおもちゃを使用しないでください。1. 異常に熱を帯びている場合、2. 機械的に損傷していたり、改造されている場合、3. 着色されている場合。

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.