


B90

注明：普通纸质印刷



USER GUIDE

Model : B90

Functional features

1. The sound box adopts reasonable acoustic design with outstanding sound quality;
2. BT audio transmission and handsfree call function;
3. BT self timer function enables you to listen and shoot at the same time;
4. FM radio function;
5. Voice prompts for various working states;
6. Support TF card playing and flac/wav/mp3 and other format files;
7. Support the corresponding status functions of digital display;
8. Support clock and alarm functions (alarm clock 1/alarm clock 2);
9. The alarm clock rings 3 times, with an interval of 1 minute. Snooze mode;
10. Built in large capacity lithium battery for power supply, long endurance.

Buttons and interfaces introduction

Play/pause button

Press once-Play/Pause; Press and hold for 3 seconds to ON/OFF;
In BT Mode:
Double click: connect back the last call; BT disconnected: Short press-connect back;

Outgoing call: Press once to cancel; Incoming call: Press once to answer; Double click: refuse to answer the phone.

Volume up

Press once-Volume up; Press and hold for 3 seconds-Next track.
Clock Setting Mode: Press once-time plus; Press and hold the time continuities added.

Volume down

Press once-Volume down; Press and hold for 3 seconds-Previous track.
Clock Setting Mode: Press once-time reduced; Press and keep time continuity reduced.

Mode key

Double click-mode switch;
In BT Mode:
Device connected: Press once-take a picture (need to open the camera connected to the phone); Press and hold for 3 seconds disconnect the phone and re-pair;
Talking on line: Press and hold for 3 seconds to choose the call hearing and talking via callphone or this machine;
In FM mode: Press and hold for 3 seconds to scan and store FM channels.

Clock key

Clock Mode: Press once-with display mode (clock/alarm 1/alarm 2); Press and hold for 3 seconds-enter (clock/alarm 1/alarm 2) setting mode;

Setting Mode: Press once-switch hour/minute/alarm switch; Press and hold for 3 seconds-set setting, return to display mode;

Alarm Bell: Press once-turn off the current Bell; Press and hold for 3 seconds-turn off the current Bell, turn off sleep mode;

BT/TF Mode: Press and hold for 3 seconds-enters clock mode.

TF Card Slot

TF card file system support: FAT and FAT32;

MICRO USB Socket

Charging Interface: DC5V 500mA;

BT, let your music start from here

1. After power on, double click the mode key to switch to BT mode. When leaving the factory, B90 automatically enters BT pairing mode, and the display screen alternately displays "BT" and "-BT".
2. Turn on the mobile phone, iPad, PC or other electronic devices that can be connected to the BT headset, turn on the BT function and search the BT device number "B90" for pairing. After the connection is successful, the display shows "-BT" and you can start playing music.

Multimedia makes your music limitless

TF Card playback:
1. Format TF as FAT32 before using it, copy the FLAC/WAV/MP3 music file to the TF Card Directory, complete the copy;
2. When the machine is turned on, the TF card is inserted into the slot of the machine, and the machine automatically plays the music of the TF card. Listen to FM radio station: turn on the machine, double-click the mode key to switch to FM mode, and press the mode key for the first time to enter the full-automatic channel search. After the channel search is completed, the first local radio station found will be played automatically. Long press the volume key to select your favorite radio station and listen to wonderful programs.

Clock to make your time more efficient

Clock setting:
1. When the machine is powered on, when the TF card is not inserted into the machine, the machine will automatically enter the clock display mode, and the display screen will display "12:00" : "1 second閃烁时为时钟显示界面；
2. Long press the clock key for a long time to enter the clock setting mode, and the hour bit on the display flashes for 1 second;
3. Press the volume up / down button to increase or decrease the number of hours to be set;
4. The short time clock key switches to the minute setting mode. At this time, the display screen shows that the minute bit flashes for 1 second;
5. Press the volume up / down button to increase or decrease the number of minutes to be set;
6. Long time clock key saves the set time and returns to the clock display mode. Alarm setting:
1. In the clock display mode, the display screen displays "12:00" : "when it flashes for 1 second, it is the clock display interface.
2. The short time clock key switches to the alarm 1 display interface, and the short time clock key switches to the alarm 2 display interface again;
3. Press the long time clock key to enter the alarm setting mode. The display shows that the hour bit flashes for 1 second, and the alarm icon flashes at the same time;
4. Press the volume up / down button to increase or decrease the number of hours to be set;
5. The short time clock key switches to the minute setting mode. At this time, the display screen shows that the minute bit flashes for 1 second;
6. Press the volume up / down button to increase or decrease the number of minutes to be set;
7. The short time clock key switches to the alarm switch setting mode, and the display shows "OFF";
8. Press the volume up / down key to set it to on, the display screen displays "ON", the alarm icon is on for a long time, set it to off, and the display screen displays "off", the alarm icon flashes for 1 second;
9. Long time clock key saves the set alarm time and returns to the alarm display mode;
10. After the alarm time is set, the alarm will wake up whether the machine is turned on or off. When it rings, the short time clock key will turn off the current alarm, the long time clock key will turn off the current alarm, and the snooze mode will no longer ring. The alarm can only ring again the next day.

Charging, excellent power management

Charge: When charging the machine: the battery icon flashes for 1 second; When the machine is full: the battery icon is on for a long time; When the charging cable is unplugged: the battery icon goes out.
Standby: BT mode: when BT is not connected, it will enter the clock mode after 5 minutes;
FM mode and TF card mode: the music will enter clock mode after 5 minutes' pause; Entering the clock mode will further reduce the power consumption to the optimal level and increase the local endurance time.

Technical parameter

1. Output power: 3W THD:<10% 2. Sensitivity: 83dB+/-3dB
3. Signal to noise ratio: >90dB 4. Charger Parameters: DC5V 500mA
5. Frequency response: 120Hz-20KHz 6. BT parameters: BT V5.1+EDR

Precautions for use

1. It is recommended that you fully charge the product before using it for the first time;
2. Remind you that the playing time of this machine is related to the volume of the songs played;
3. Remind you not to use this machine in high temperature, humid and dusty environment;
4. Remind you that there may be compatibility differences depending on the BT host device you are connected to (the BT host may not support the call function and self timer function);
5. Remind you that if the TF card fails to respond, please confirm whether the TF file system is in FAT32 format or whether the audio file is in flac/wav/mp3 format;
6. When you are reminded that the battery of this machine is low, a prompt tone will remind you to charge in time.

Warning: This machine can not be used when charging higher than 5V DC charger, will damage the machine!

正面

背面

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.