



Installation

Step 1:Disassemble the hanging plate of the lamp. (fig.1)




Step 2:Twist the bottom of the fan blade counterclockwise and lock it into place to make it firm and safe.(fig.2)




a:Wooden ceiling

If you have a wooden ceiling,use wood screws with flat washers. (fig.3)




b:Concrete ceiling


If you have a concrete ceiling,use screws with lock washers. (fig.4)



Step 3:Use the auxiliary mounting tool S-hook to hang the ceiling fan with light under the ceiling.(fig.5)



Step 5:Remove the S-shaped hook and snap the 7-shaped hole of the ceiling fan light holder onto the cross-hanging plate. (fig.7)




Step 4:Wiring(fig.6)


- Connect the black live wire marked "L" on the receiver to the live wire (typically black)on the socket box.
- Connect the white neutral wire marked "N"on the receiver to the neutral wire (typically white)on the socket box.
- Connect the ground wire(bare wire)from the base of the ceiling base with the ground wire (bare wire)of the socket box.



Step 6:Rotate the ceiling fan and snap the screws into the 7-shaped holes. (fig.8)



Step 7:Tighten the 4 screws to complete the installation. (fig.9)



Aipun

Ceiling Fans Lights



User Manual

Specification

Product Name	Ceiling fans lights
Input Voltage	90-260V
Bulb LED	Led light source
LED	40W/54W
Color Temperature	3000K/4000k/6500k
Reversible	Yes
Wind Speed	6 wind speeds
Warranty Time	2 Years

Packing List

Ceiling fan light	1
Remote Control	1
Remote Control Wall Bracket	1
S-hook(Auxiliary Mounting Tool)	1
Accessory Pack	1
User Manual	1

Remote Control



App Operation



1.APP Download:Scan the QR code and select the

APP version to download.

2.Pairing After turning off the power of the fan light, then turn on the power,click the "PairCode"button on the APP within 5 seconds, and hear the beep, then the pairing is successful.

3.After the pairing is complete, you can control the device with the APP.

Note:APP connection method is Bluetooth.

Care and cleaning

- Wipe the fan regularly with a soft dry cloth. Do not use harsh cleaning agents or materials as they may damage the device.
- To prevent the blade from bending during cleaning, please support the blade from pressure.
- Keep ceiling fan or fan blades free of water, otherwise it may cause fire or electric shock, resulting in property damage.
- Due to the long-time work of the fan, the screw connection may become loose, please check the support connection, bracket and blade attachment regularly to make sure they are safe.

Warm Tips

If your remote control does not control the fan and lights, please follow the steps below to undo the fault. (Note: The sensing range of the remote control is within 10M)

Step 1: Replace the battery of the remote control.

Step 2: Try pairing the remote with the ceiling fan light.

- > turn off the main switch that controls the ceiling fan light and turn it on again.
- > press and hold the SETUP button of the remote control panel simultaneously within 5 seconds.
- > if you hear a beeping sound, the code is matched successfully.

Precautions

1. In order to avoid possible electric shock, make sure to cut off the power supply of the box or circuit breaker before wiring the power supply.

2. All wiring must be in accordance with the requirements of local electrical codes.

Consult a qualified electrician for Make sure the hot, neutral and ground connections are correct.

3. If you do not have sufficient electrical knowledge, please have the fan installed by a licensed electrician.

4. The ceiling fan light stand is firm and can support at least 66 lbs(30 kg).

5. Mount the fan light at least 7.5 feet (2.3 meters) above the floor or ground.

6. Make sure to use proper connectors and electrical tape for all wire connections.

7. Before operating the ceiling fan, all set screws must be checked and fixed.

ADDITIONAL SERVICES

We usually solve the following problems for customers.

1. Defective item replacement service.

2. Professional answers on use.

3. Remote control and APP do not work.

4. Installation instructions.

Welcome to contact us.

Submit "Order NO.",



Contact Seller

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.