

ST-2025 M A N U A L

KARAOKE SPEAKER



OPERATING INSTRUCTION

All the instructions should be read carefully before operation and follow the instructions.

- ◆ The speaker should be situated away from heat sources such as radiators, and not exposed to moist air or water.
- ◆ Place the unit on a stable place to prevent it from being fallen down.
- ◆ The speaker should be only connected to a power supply described in the operating instructions.
- ◆ The user should not attempt to repair the speaker if you are not professional.
- ◆ Disconnect the power cable from the outlet & switch off before cleaning the unit. Please only use soft cloth, no harsh abrasives or chemicals to clean, as they will damage the appearance.
- ◆ The power cable of the speaker should be unplugged from the outlet and power switch should be off when left unused for a long period of time.

-2-

PACKING LIST

1. Speaker1pc
2. Microphone2pcs
3. User Manual1pc
4. Stereo Audio1pc
5. USB Charging Cable1pc




SchematicDiagram

-3-

-4-

SPEAKER DESCRIPTION



SchematicDiagram

OFF/ON


1. "OFF" means Power off, "ON" means Power on, speaker will enter into the play mode which same as last time.
2. Charging: Insert out power to "DC 5.0V", then the built-in battery can be charged.

Play Mode

1. Insert the audio equipment to the "LINE", and the speaker can play music from mobile phone, MP3, computer and other audios.
2. MP3 function
TF card/U disk: Insert TF card to "TF", it will play music from TF card. Insert U disk, it will play music from U disk.

-5-

MICROPHONE DESCRIPTION



SchematicDiagram

1. Just press and hold the wireless microphone's power switch to turn on the microphone, the microphone is blue light and it will automatically connect to the speaker, and you can start singing.
2. When you sing, you can adjust the "VOL" button. You can increase the sound by sliding up the button and decrease the sound by sliding down.
3. When singing, you can adjust the "ECH" button to achieve the reverb effect you need.
4. When the blue light of the wireless microphone is flashing, it indicates that the microphone's battery is low and needs to be charged.
5. You can use the DC-5V USB cable to charge, when charging, the microphone light is red, when the battery is fully charged, the light is off.

-6-

Button Function

1. Model:
The mode button is mode conversion (Bluetooth, TF card, USB flash drive, AUX).
2. Music from:
Pressing the original music button can
 - 1. Left press "I", it would be a song before.
 - 2. Right press "II", it would be a song after.
3. Press "II" to pause or play;
4. Press "I" for the next song.
5. Click "I" for the next song.
6. Volume knob:
Rotate to the left decreases the volume, turn to the right increases the volume.
7. LED:
Switch on the default RGB breathing light mode, short press to switch the light color, continuous short press to switch the light color can turn off the light, Press again to turn on the breathing light.

Instructions For Use

As you power on, Bluetooth mode is the default. You could search for the blue tooth device name ST-2025 on your phone for connection. It will be converted to TF card mode when you insert the TF card. It will be converted to USB mode when you insert the U disk. It will be converted to LINE mode when you insert the 3.5MM audio cable. When insert the TF card and USB at the same time, press the MODE button to convert the mode.

Singing Instruction

When the speaker is turned on, the wireless microphone is connected to the speaker by default after turning it on. Just turn on the wireless microphone power switch "ON / OFF" and you can sing in any mode of the speaker. When you sing, you can adjust the volume of the speaker according to your personal preference to achieve your desired singing effect. When the blue light of the wireless microphone is flashing, it means the microphone battery is too low and needs to be charged.

-7-

Note

1. Please use the 5V/2A charger to charge, do not play music while charging.
2. When the microphone is turned on, Do not point the microphone straight to the speaker to avoid howling.

Product Parameters

Power output: 15W+15W
Frequency: 100HZ---18KHZ
Drive unit: 3IN*2
S/N: ≥80dB
Lithium battery: 7.4V-2600mAh
Materials: Plastic
Gift Box size: 300*152*185mm
Quantity/ctn: 10pcs/ctn
Carton size: 87,5*33,5*50CM

MADE IN CHINA

-8-

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction