

RE-H616

Manual Book

CE, CB

ISO9001:2015, ISO14001:2015

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. End - Users must be provided with transmitter operation conditions for satisfying RF exposure compliance.'

This means the distance from the antenna to the human body, is not the radiator.

# PRODUCT SPECIFICATION

## Dimensions



## Specification

Name of Product: Advanced Massage Chair  
Voltage: AC220V,50/60Hz  
Power: 160W

# CONTENT

	Page
Content	1
Important Safety Instructions	2-3
Name of Components	4-5
Remote Control Instructions	6-7
Smart Key	8
Preparation Before Use	9
Trouble Shooting	10
Voice Control Function	11
Product Specification	12

# IMPORTANT SAFETY INSTRUCTION

Please read details in this booklet carefully and pay special attention to the "Important safety instructions". To ensure proper use please keep this booklet for your reference.  
(All information presented is as accurate as possible, but is subject to change without notice, please check with the product. Our company reserves the right of final explanation.)

## WORK ENVIRONMENT

- Please do not use it in a moist environment to avoid the danger of an electric shock.
- Please do not use it in the heavy-dusty or caustic environment in order to avoid mechanical failure of eroding.
- Please do not use your chair if the room temperature is higher than 40 C.
- Please do not leave it outdoors. Please do not expose this machine to strong light, ultraviolet rays, sunshine or in close proximity to a heater.
- Please use your chair where there is enough space and good ventilation.

Please use and place it on the level of ground. This massage chair is intended for household use only.

### **Caution:**

Please do not use the machine immediately after the surrounding temperature changes sharply. Wait 30 minutes for the machine to reach the room temperature, then use it.

## PEOPLE WHO ARE NOT SUITABLE TO USE THIS PRODUCT

- If you are pregnant or have any health issues please consult your medical practitioner before using your chair.

### **⚠️ WARNINGS:**

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Service and Repairs must be carried out by a suitably qualified person.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

## SAFETY ITEMS

- Please check your voltage is suitable before use.
- Please do not plug/unplug the power plug with wet hands.
- To avoid electric shock or short circuit do not spill liquid on the machine.
- Importantly, do not use this chair if some parts of your seat have moved.
- Please do not use in conjunction with other medical instruments or an electro-thermal blanket to avoid injury or inefficacy.
- Please do not use your chair within an hour after having a meal.
- Please do not place valuable things or heavy objects on this product to avoid mechanical failure and damage.
- Please check that there is no person, pets and obstacles near the working massage chair to avoid any injury or mechanical problems.
- Please never put hands or feet into the slots so as to avoid any injury.

# VOICE CONTROL FUNCTION

NO.	ASK	ANSWER	NO.	ASK	ANSWER
1	Hello robot	Hello, Master	14	Tap massage	Ok, Tap massage
2	Turn on massage/ Start massage	Ok, Turn on the massage	15	Kneading massage	Ok, Kneading massage
3	Turn off massage/ Stop massage	Ok, Turn off the massage	16	Knocking massage	Ok, Knocking massage
4	Refreshing program	Ok, Refreshing Program	17	Finger Pressure massage	Ok, Finger Pressure massage
5	Comfort program	Ok, Comfort Program	18	Kneading and knocking	Ok, Kneading and knocking
6	Sleeping program	Ok, Sleeping program	19	Turn on Air Pressure	Ok, Turn on Air Pressure
7	Recovery program	Ok, Recovery program	20	Turn off Air Pressure	Ok, Turn off Air Pressure
8	Neck & shoulder Program	Ok, Neck & shoulder Program	21	Turn on foot scraping	Ok, Turn on foot scraping
9	Back & waist Program	Ok, Back & waist Program	22	Turn off foot scraping	Ok, Turn off foot scraping
10	Stretching program	Ok, Stretching program	23	Turn on heating	Ok, Turn on heating
11	Sport program	Ok, Sport program	24	Turn off heating	Ok, Turn off heating
12	Quick program	Ok, Quick program	25	Zero gravity	Ok, Zero gravity
13	Deep program	Ok, Deep program			

Problem	Problem	Solution
Can't start the chair	<ul style="list-style-type: none"> <li>* Check the power plug is connected with socket</li> <li>* Check it is switch on</li> <li>* Check the fuse</li> </ul>	<ul style="list-style-type: none"> <li>* Check the socket and make sure it works effectively</li> <li>* Turn on the chair</li> <li>* Change the fuse if it has melted</li> </ul>
The remote control doesn't work properly	<ul style="list-style-type: none"> <li>* Check the plus is connected to the PCB box</li> <li>* Check if it is connected properly</li> </ul>	<ul style="list-style-type: none"> <li>• Insert the plug in the receptacle securely</li> <li>• Check and make you have a proper connection</li> </ul>
The massaging hands don't work	<ul style="list-style-type: none"> <li>* Check whether the chair is on/off</li> <li>* Check if the time is up</li> <li>* The chair may have been working for too long causing the temperature protector to automatically turn the power off.</li> </ul>	<ul style="list-style-type: none"> <li>• Turn on the chair</li> <li>• Use it after half an hour's rest</li> </ul>
The backrest and footrest can not incline normally	<ul style="list-style-type: none"> <li>* The backrest or footrest may have an interference with an obstruction</li> <li>* Check the power cord for a disconnection</li> </ul>	<ul style="list-style-type: none"> <li>• Move chair from obstruction</li> <li>• Insert the plug in the receptacle securely</li> </ul>
The shoulder position can not be detected		<ul style="list-style-type: none"> <li>• Move your back close to the massage hands, head close to the pillow</li> </ul>
The massage function suddenly stops	<ul style="list-style-type: none"> <li>* Power is off</li> <li>* The time is up</li> </ul>	<ul style="list-style-type: none"> <li>• Turn on the power</li> <li>• Use it after half an hour's rest</li> </ul>
The massage motion suddenly stops, causing the massaging hands to return to the top position	<ul style="list-style-type: none"> <li>* Mechanical failure because of excess weight</li> <li>* The time is up</li> </ul>	<ul style="list-style-type: none"> <li>• Contact us for further information</li> <li>• Use it after half an hour's rest</li> </ul>
The buttons on the remote control are not working correctly		<ul style="list-style-type: none"> <li>• Cut off the power and restart</li> </ul>


- Please check and make sure all the parts are in good condition and are firmly connected before use.
- Please cut off the power immediately if water or other liquid has been spilt on the remote control or massage chair (especially PCB box)
- Please cut off the power immediately when the covering cloth is broken (i.e. the built-in mechanism is exposed) and contact us for information.
- Please cut off the power immediately if any abnormal phenomenon occurs, and contact us for information.
- The time function can only stop the mechanical operation of your chair, please remember to turn off the power switch.
- During a storm please turn off the power switch and disconnect the power line, please unplug the power plug SD card or U disc gently.
- Please do not press, twist or pull the electrical wire forcibly.
- If damage occurs, contact us for inspection/repair information.
- Please do not use this product if the sockets have loosened.

## INSTALLATION AND MAINTENANCE


- Please don't disassemble this product or touch the inner parts to avoid injury.
- Only our service agents can repair this product under warranty, please do not disassemble and repair this product by yourself

## CAUTION

- Please locate the backbone at the center of the chair, otherwise it may cause discomfort.
- Please do not try to control the massaging balls to massage your head. That might not be very comfortable.
- Please ensure that the body is located in the right position while the massager is working. If the massaging balls go down, do not try to force them to return.
- Please be careful not to fall asleep during your massage.
- If sickness or pain is felt during use, stop using the massager and consult a doctor immediately.
- Please do not use the massager more than 30 minutes each time.




## Remote controller guidance



- 1/ Connect the remote control in position 2.
- 2/ Connect the Power.

## The leg assembly

- 1/ Connect the air hose and cable in position 3
- 2/ Put the Legrest in position 2 and Lock up.




## ATTENTION

Please place this product on the level ground  
As this product is very heavy, we suggest using carpet to avoid damaging the floor.  
Take all products parts and accessory case from the package.


### 1. Movement

a. Short distance movement: push the backrest backward until you are balancing the machine on the cast/wheels, to move the massage chair.



### 2. Blue-Tooth Connection


First Step: Turn on massage chair  
Second Step: Turn on Blue-tooth function of Mobile phone, and then search for Massage chair Blue-tooth devices(RE-M08).  
Third Step: Play Music or Video on your Mobile Phone.



# SMART KEY

# NAME OF COMPONENTS

## Smart Key



Clockwise rotation: massage speed up  
Counter-clockwise rotation:Slow down the massage speed

Long Press 3 seconds: to turn on/off  
Short press: Pause

Calf rising


Calf falling

Back up


Back down

USB charge

Voice switch



(Picture1)



(Picture2)

1/ Pillow	2/ Shoulder	3/ Back Cushion	4/ Speaker	5/ Smart Key
6/ LED Light	7/ Footrest	8/ Armrest	9/ Base	10/ Rear Cover
11/ PCB Box	12/ Switch	13/ Caster		

# REMOTE CONTROL INSTRUCTIONS



## ON / OFF

Press the power button to turn on the machine and press again to turn it off.



## AUTO MODE

Cyclically press this key to select different automated programs. Total 10 sets auto massage programs.



## MANUAL MODE



you can change the massage motion by keep pressing this button.



## SHOULDER POSITION ADJUSTMENT



Press this button to adjust the highest position that the mechanical hands/rollers reach during your massage. There are 2 options; Auto Adjustment

This massage chair has a scan function: when you start a program (such as Recovery), the mechanical massaging hands will scan your shoulder position for a few seconds. Please note: to avoid an error in the scanning process (scanning the incorrect shoulder position) Sit up straight when you first set your massage program. Manual adjustment. After auto body scan, if you think the massage rollers can not reach your desire neck position, please adjust massage rollers using this button in the process of massage programme in 15 minutes, then massage rollers can reach as far as the position as you have set.




## HEATING

Press this button to turn on/off heating function increase or decrease temperature by



## AIRBAG

Press this button to turn on/off all of the airbags



## FUNCTION SELECTION

Press "Menu" into menu bar, you can adjust airbag intensity, Massage rollers Speed, etc.



## LEG UP

Hold this button to rise the leg rest. if you release the button, it will stop.



## LEG DOWN

Hold this button to get the leg rest back. if you release the button, it will stop.



## BACK UP

Hold this button to rise the backrest, if you release the button, it will stop



## BACK DOWN

Hold this button to tilt-back this chair, if you release the button, it will stop.



## ZERO-GRAVITY

Press this button once, this Massage Chair will get into Zero Gravity condition. Press this button twice, this Massage Chair will get into Normal condition.



## FOOT ROLLERS

Press this button to turn on/off the foot rollers



## SETTING TIME

Press this button to change working time, 15 minutes, 20 minutes and 30 minutes



## FUNCTION PAUSE

During the massage process, press this key, the massage chair will stop working, press again, will resume working.

# REMOTE CONTROL INSTRUCTIONS