

<h1>A98 PRO</h1> <p>Dongguan Togran Electronics Technology Co., Ltd Add: No.110, Shijie Shidian Mid Rd, Shijie Town, Dongguan City, Guangdong Province, China 523200 Tel: +86 769 8630 8806 Fax: +86 769 8630 8826 Email: info@dareu.com Web: www.dareu.com</p>	<p>DAREU A+</p> <p>User Manual</p>	<p>What's in the box</p>	<p>Product views</p>	<p>Parameter</p> <p>Keyboard type: 98% layout Connection: wired + 2.4G + BT Cable length: 1.8m Operation distance: <10 meters (Wireless mode) Keycap: PBT Double Shot and Dye-sublimation Switch: Hot-swap switch Key conflict: N-Key rollover Backlight: RGB Battery: 4000mAh Charging time: approx. 7.5 hours Weight: 1100±10g Dimension: 388*139*37mm Compatibility: Win 7/Win 8/Win 10/Mac OS/Android and so on</p>	<p>Basic information</p> <p>3 height adjustable keyboard feet.</p>	<p>Basic information</p>																					
<p>How to Connect</p> <p>BT</p> <p>BT 1-Switch button to this position; 2-Turn on the device BT and search keyboard; 3-Pairing and connection; *In BT mode, we can choose to connect three different devices at the same time. Switching methods as following: ① Default this BT channel, connect the first BT device. ② Press this key combination to connect a second BT device. ③ Press this key combination to connect a third BT device. *In BT mode, if can't search the keyboard or want to connect to another devices, press Fn+Q for 5 seconds, the indicator light flashes quickly. Then pair it for use.</p> <p>A: Connect with the cable and use.</p>	<p>How to Connect</p> <p>BT</p> <p>BT 1-Switch button to this position; 2-Turn on the device BT and search keyboard; 3-Pairing and connection; *In BT mode, we can choose to connect three different devices at the same time. Switching methods as following: ① Default this BT channel, connect the first BT device. ② Press this key combination to connect a second BT device. ③ Press this key combination to connect a third BT device. *In BT mode, if can't search the keyboard or want to connect to another devices, press Fn+Q for 5 seconds, the indicator light flashes quickly. Then pair it for use.</p> <p>A: Connect with the cable and use.</p>	<p>Key shortcuts</p> <p>Switch backlight effects</p> <table border="1"> <tr> <td>FN+F1 = Backlight effects (7 modes)</td> <td>FN+F1 = Backlight color (Mixed color/blue/green/yellow/purple/white)</td> </tr> <tr> <td>FN+F2 = Brightness+ (0%-25%-50%-75%-100%)</td> <td>FN+F2 = Brightness- (00%-75%-50%-25%-0%)</td> </tr> <tr> <td>FN+Esc (5 seconds) = Reset</td> <td>FN+Esc (5 seconds) = Reset</td> </tr> <tr> <td>FN+F3 (5 seconds) = Switch for Win/Mac system</td> <td>Then: Fn+Opción: Alt = Command</td> </tr> </table> <p>Multi-media function</p> <table border="1"> <tr> <td>FN+F1 = Brightness-</td> <td>FN+F2 = Brightness+</td> <td>FN+F5 = Search</td> <td>FN+F6 = Switch input method</td> </tr> <tr> <td>FN+F7 = Previous</td> <td>FN+F8 = Play/Pause</td> <td>FN+F9 = Last</td> <td>FN+F10 = Mute</td> </tr> <tr> <td>FN+F11 = Volume-</td> <td>FN+F12 = Volume+</td> <td></td> <td></td> </tr> </table>	FN+F1 = Backlight effects (7 modes)	FN+F1 = Backlight color (Mixed color/blue/green/yellow/purple/white)	FN+F2 = Brightness+ (0%-25%-50%-75%-100%)	FN+F2 = Brightness- (00%-75%-50%-25%-0%)	FN+Esc (5 seconds) = Reset	FN+Esc (5 seconds) = Reset	FN+F3 (5 seconds) = Switch for Win/Mac system	Then: Fn+Opción: Alt = Command	FN+F1 = Brightness-	FN+F2 = Brightness+	FN+F5 = Search	FN+F6 = Switch input method	FN+F7 = Previous	FN+F8 = Play/Pause	FN+F9 = Last	FN+F10 = Mute	FN+F11 = Volume-	FN+F12 = Volume+			<p>Switch replacement</p>	<p>How to use driver</p> <p>Driver interface</p> <p>Download driver from DAREU's official website (www.dareu.com) and install it on computer. (Software only supports Windows systems.) *Picture is for reference only.</p>	<p>How to use driver</p> <p>Button introduction</p>	<p>How to use driver</p>	<p>FCC Caution</p> <p>§ 15.19 Labelling requirements. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>§ 15.20 Information to user. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>§ 15.105 Information to the user. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p> <p>* RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>
FN+F1 = Backlight effects (7 modes)	FN+F1 = Backlight color (Mixed color/blue/green/yellow/purple/white)																										
FN+F2 = Brightness+ (0%-25%-50%-75%-100%)	FN+F2 = Brightness- (00%-75%-50%-25%-0%)																										
FN+Esc (5 seconds) = Reset	FN+Esc (5 seconds) = Reset																										
FN+F3 (5 seconds) = Switch for Win/Mac system	Then: Fn+Opción: Alt = Command																										
FN+F1 = Brightness-	FN+F2 = Brightness+	FN+F5 = Search	FN+F6 = Switch input method																								
FN+F7 = Previous	FN+F8 = Play/Pause	FN+F9 = Last	FN+F10 = Mute																								
FN+F11 = Volume-	FN+F12 = Volume+																										