

BATTERY CHARGING

- Insert USB-C charging cable to an AC charger (not included) or a computer USB CHARGING PORT.
- Insert the USB-C end into USB CHARGING PORT.
- The INDICATOR LIGHT lights up RED while the unit is being charged. Once the battery is fully charged, the light will turn BLUE.
- When charging with the earphone powered off, the earphone will automatically power on and start searching for a pairing device as soon as the USB-C chord is detached from the charging port.
- Battery charging time is approximately 2 hours.

INSIDE THE BOX

- | | |
|---------------------------------------|-----------------------------|
| - 1 x Earbud Unit | - Carry Case |
| - AKT1 Challenge Coin | - Type-C USB Charging Cable |
| - 3 Pairs of Foam Eartips (S,M,L) | - Cable Cinch |
| - 3 Pairs of Silicone Eartips (S,M,L) | - User Manual |

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

THE AKT1 STRIKEPRO HTBTEARBUDS OPERATE DIFFERENTLY THAN TYPICAL BT EARBUDS OR EARPLUGS, AND ESPECIALLY DIFFERENT FROM EARBUDS FOR MUSIC LISTENING AND ENTERTAINMENT. THEY ARE FIRST OF ALL HEARING PROTECTION DEVICES WITH THE PRIMARY FUNCTION OF PROTECTING YOU FROM HEARING LOSS.

THE HEARING AUGMENTATION IS STATE OF THE ART DIGITAL SOUND ENHANCEMENT WITH THE RESULT OF VERY NATURAL HEAR THROUGH CAPABILITIES, ALLOWING YOU TO MAINTAIN NOT ONLY MORE ACCURATE SITUATIONAL AWARENESS, BUT INCREASED AWARENESS AND FOCUS ON THE TASK AT HAND.

THE BT FUNCTIONALITY IS STATE OF THE ART USING BT 5.0 WITH BETTER CONNECTIVITY, A WIDER BAND FOR MUSIC LISTENING AND QUALCOMM CVC NOISE CANCELLATION. DURING PHONE CALLS, YOU WILL NOTE BETTER VOICE RECOGNITION, AND MORE ACCURATE SOUND RECREATION. FOR MUSIC LISTENING, YOU WILL NOTE THAT THE LATEST BT VERSION ENHANCES CLARITY AND BANDWIDTH SIGNIFICANTLY. THE COMBINATION OF SOUND ISOLATION FROM ENVIRONMENTAL NOISE AND ABSOLUTE DESIGN CONTROL OF THE BUD ITSELF WITH ACOUSTICS IN MIND AND WITH EVERY DESIGN DECISION.

WE SINCERELY BUILT THESE WITH THE USER IN MIND AND MADE EVERY DECISION WITHOUT COMPROMISE. WE THINK YOU WILL FIND THAT TO BE EVIDENT IN USE.

TEAM AKT1 SPORT

MODEL : STRIKEPRO HTBT

FCC ID : 2A5PL-STRIKEPROHTBT

BLUETOOTH DID : D054382

AKT1

SPORT

TM

AKT1

SPORT

TM

FOAM TIP FITTING PROCEDURE

ALWAYS FIT AND SECURE EARTIPS WITH THE UNIT TURNED OFF.



- Mould the soft earhook to fit around your ear as shown.
- Select the proper size ear tip to fit your ear canal. This ear tip should form a complete seal blocking out sound. This is critical to achieve the highest NRR rating and protect your hearing.
- Compress the foam tip by rolling between your fingers, as much as possible.
- Quickly insert compressed foam tip into the ear canal before it expands and seals the ear canal.
- Hold in place for approximately 10 seconds to insure the ear tip expands and seals the ear canal.
- Test this with the headphone turned off. Clap your hands and listen to the sound level. If the ear buds are the correct size and properly inserted, outside sound should be significantly muted. If not, take the foam tip out of your ear canal and repeat step 2 - 3.

WHILE IN USE

BLUETOOTH INSTRUCTIONS

FOR CALLS

- Tap the POWER/BLUETOOTH BUTTON once to pick up and end calls.

- Go to Bluetooth settings on your device. Turn Bluetooth on and connect earphone by choosing "StrikePROHTB".

- Once connected, the INDICATOR LIGHT will illuminate STEADY BLUE and your earphone is connected and ready to use.

- If bluetooth connection is not detected in 5 minutes, the INDICATOR LIGHT will flash blue every 3 seconds showing that the earphone is in "hearthrough only" state. In this state, hearthrough is still active and if you want to connect to a bluetooth device again, double-tap the POWER/BLUETOOTH BUTTON to re-activate pairing search.

FOR MEDIA

- Tap the BLUETOOTH BUTTON once to play/pause music.
- Tap VOLUME UP/DOWN BUTTON once to increase/decrease media volume.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

HEARTHROUGH INSTRUCTIONS

- The default sound level upon powering on the unit is set at safe sound level and provides protection from loud external sounds while delivering natural hearing.

- Tap the HT/VOLUME UP/DOWN button to increase/decrease the volume in increments. 8 volume increments are provided above initial power on level to provide hearing augmentation. Please beware of sound levels when volume is increased.

- Tap the HT/VOLUME UP/DOWN button to increase/decrease the volume in increments. 8 volume increments are provided above initial power on level to provide hearing augmentation. Please beware of sound levels when volume is increased.

POWERING ON/OFF

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETOOTH BUTTON to activate Siri/Bixby/ Alexa etc... platforms.

POWERING ON/OFF

- Press and hold the POWER/BLUETOOTH BUTTON for 3 seconds and the INDICATOR LIGHT will flash RED 3 times. Your earphones are now turned off.

- Press and hold the VOLUME UP/DOWN BUTTON for 2 seconds to skip to the previous/next track.

- Press and hold the POWER/BLUETO