


Product Specification

Top Operating Panel



- ① Press the power switch or press the key to turn off the indicator
- ② Press and hold to increase the volume, and press and hold the next song
- ③ Long press to reduce the volume and short press the previous track
- ④ White Noise/Bluetooth mode switch key
- ⑤ Light cycle key
- ⑥ Tap to pause/hold to set the white noise time
- ⑦ Essential oil lid
- ⑧ Charging port

Specification

Product Name: Colorful aromatherapy sleep speaker
Product Color: Silver gray
Product Size: 90mm×100mm
Battery Specification: 1500mAh
Bluetooth Version: V5.3
Material: ABS

Playing Time: About 4-6 hours
Charging Time: 4-5 hours
Transmission Distance: 10m
Charging Port: Type-C
Output Power: 5W
Input Power: 5W

* Depending on personal usage, it may be slightly above or below the specified time.

Operation Procedure

1. Turn it on

Press and hold the power button until you hear the prompt tone or see the indicator light on, indicating that the speaker is on. The speaker defaults to white noise. It contains seven kinds of sounds, namely: white noise, running water, burning sound, rain sound, music sound, surf sound, bird sound.

2. Switch modes

Press the mode switch button to switch Bluetooth mode in white noise.

3. Bluetooth pairing

Search for the speaker pairing name in your Bluetooth device. SY810 Click Connect, and the key indicator is steady on. The pairing is successful.

4. Volume adjustment

Press and hold the plus or minus sign through the volume of the speaker to increase or decrease the volume. Short press the previous or next track.

5. Lighting adjustment

Press and hold the light button to turn the light on or off. Press the light button to switch lights until you like the light.

6. Play adjustment

Open your favorite music app. Play through the volume of the speaker. Tap to pause play. Long press the white noise time setting, according to your needs to set the time, respectively, 5 gears: 0 minutes, 30 minutes, 60 minutes, 90 minutes, 120 minutes.

7. Add essential oils

Turn the lid to the left to open, then gently pull up. Then drizzle the white cotton with essential oil. Soak the cotton until it's soaked. Don't drop too much. To avoid missing too much. Then put the essential oil cover on, align with the bayonet and rotate to the right.

8. Charge

Plug one end of the charging cable into the charging port of the speaker. Connect the other end to a power adapter or USB port on your computer. The speaker is then charged. The indicator on the speaker is steady red while charging. Full red light off.

Matters Needing Attention

During the entire connection process, note:

1. Ensure that the Bluetooth function of the mobile phone is normally turned on and can be found.
2. Ensure adequate speaker power and stable connection.
3. When the connection encounters problems, you can try to restart the phone and the speaker or check whether the speaker Settings are correct.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.